Miele Fridge Freezer 3r}pj Bracket Fixing

The fridge freezer's hinge bracket fixing¬ will clash with the Howdens Handleless Kitchen's metal cabinet profile.

In order to fit the appliance as per the supplied instruction manual the appliance's 4 x hinges need to be changed. (One of the hinge bracket's fixing holes has been modified to a slot to allow the fixing of the appliance to the cabinet with the screws supplied.)

With the fridge freezer unpackaged and out of the cabinet:-

1- Carefully remove the hinges' plastic trim covers.

2- Supporting the door, carefully remove each door assy by loosening the inner and removing the outer hinge screws.

3- Remove the hinges from the doors and fit the supplied modified hinges. (1 x Upper & 1 x Lower hinge per door)

4- Carefully refit the doors to the appliance and fasten hinge retaining screws.

5- Replace plastic cover trims.

6- Return the 4 x original hinges to the Howdens Depot.

Before

After

Upper hinge part number- 7187841
Lower hinge part number- 7187831