



## **MODIFYING EXISTING PRODUCT FOR USE WITH 12MM LAMINATE**

**EXISTING FLOORING ACCESSORIES CAN BE USED WITH 12MM FLOORING IF FITTED WITH D-SECTION (MOD0717)**

**D-SECTION MUST BE CUT TO SIZE AND THE FITTING TRACK ATTACHED. IF USING SCREWS, PILOT HOLES MUST BE DRILLED INTO THE D-SECTION AT THE LOCATIONS REQUIRED ALONG THE FITTING TRACK.**

**APPROPRIATE FITTINGS MUST BE USED FOR THE INTENDED SUBFLOOR. IF USING SCREWS THEY MUST BE LONG ENOUGH TO SCREW THE TRACK AND D-SECTION INTO THE FLOOR AT THE SAME TIME.**

**THIS SOLUTION WILL ALLOW THE USE OF EXISTING PRODUCT WITH 12MM FLOORING FITTED WITH UNDERLAY OF 2MM (SDH0900), 3MM (SDH0915), AND 5MM (SDH0909) THICKNESS.**

