


## Coloured backboards

	Heritage Stone - 3m x 600mm x 7mm	<b>UK</b> WKP1097
	Heritage Stone - 1m x 700mm x 7mm	<b>UK</b> WKP1098
	Titanium - 3m x 600mm x 7mm	<b>UK</b> WKP1197
	Titanium - 1m x 700mm x 7mm	<b>UK</b> WKP1198
	Heritage Blue - 3m x 600mm x 7mm	<b>UK</b> WKP1297
	Heritage Blue - 1m x 700mm x 7mm	<b>UK</b> WKP1298
	Dark Blue - 3m x 600mm x 7mm	<b>UK</b> WKP2197
	Dark Blue - 1m x 700mm x 7mm	<b>UK</b> WKP2198
	Lime - 3m x 600mm x 7mm	<b>UK</b> WKP4297
	Lime - 1m x 700mm x 7mm	<b>UK</b> WKP4298
	Burgundy - 3m x 600mm x 7mm	<b>UK</b> WKP5597

	Burgundy - 1m x 700mm x 7mm	<b>UK</b> WKP5598
	Charcoal - 3m x 600mm x 7mm	<b>UK</b> WKP5797
	Charcoal - 1m x 700mm x 7mm	<b>UK</b> WKP5798
	Gloss Cream - 3m x 600mm x 7mm	<b>UK</b> WKP5897
	Gloss Cream - 1m x 700mm x 7mm	<b>UK</b> WKP5898
	Gloss White - 3m x 600mm x 7mm	<b>UK</b> WKP5997
	Gloss White - 1m x 700mm x 7mm	<b>UK</b> WKP5998
	Olive - 3m x 600mm x 7mm	<b>UK</b> WKP6097
	Olive - 1m x 700mm x 7mm	<b>UK</b> WKP6098

Technical Information	
Material	Chipboard

Care & Installation	
Care and maintenance	<p>Use backboard sealer strips to finish off the edges</p> <p>Please note: a non-combustible splashback is required when installing a backboard behind a hob</p> <p>Avoid impact and scuffs with sharp or heavy objects to reduce the risk of damage</p> <p>Wash with mild soap or detergent, using plenty of warm water. Do not use an abrasive cleaner.</p> <p>Do not use: Scouring compounds, steel wool or harsh scrubbing brushes</p>

### Key information

**F** = Forest Stewardship Council (FSC®)

**P** = Programme for the Endorsement of Forest Certification schemes (PEFC™)

**UK** = UK Manufactured



**HOWDENS** JOINERY CO. MAKING SPACE MORE VALUABLE

Issue Date: 3 January 2017 12:30 PM

The company has a policy of continuous product development and reserves the right to change any products and specifications at any time.