

Moisture Barrier Paper Installation

WRK 3597

Some kitchen appliances such as Dishwashers, Washing Machines, Tumble Dryers, etc can produce heat and humidity. To minimise the Adverse effect that this can have on a Solid Wood Worktop it is necessary to apply the Moisture Barrier Paper to the underside of the worktop above the appliance.

Before applying the Moisture Barrier Paper, the worktop must first be oiled as specified in the Worktop Installation Instructions and should be clean and dry. The adhesive should be applied evenly to the paper side and fixed to the underside of the worktop above the appliance. Excess adhesive can be wiped away with a damp cloth.

It is also necessary to apply the Moisture Barrier Paper if the worktop is to be fitted directly onto exposed brickwork. It is important to ensure that the brickwork is dry.

The adhesive should be dry before final installation of the worktop.

Moisture Barrier Paper Adhesive: Do not ingest. Avoid prolonged contact with skin. In case of contact with eyes, mouth or nose wash with clean water and obtain medical attention.