

# SDH3220 Pre-Finished Oak 3 strip (W207mm)



Pre-Finished Fast Fit Oak 3 strip	<b>F</b> SDH3220
Pack of 2	<b>P</b> SDH3090
Solid Oak threshold strip (970mm)	<b>F</b> SDH3021
Solid Oak threshold strip (L2.1m)	<b>F</b> SDH3023
Solid Oak ramp strip (L970mm)	<b>F</b> SDH3031
Solid Oak L section (L970mm)	<b>F</b> SDH3041

Construction	
Construction	Engineered
Surface layer	2.5mm European Oak Veneer, AB Grade, Veneer source: European producer
Substrate	Pine Grade 3 (9mm)
Backing	Pine Grade 3 (2.5mm)
Finish	Lacquered

Technical Information	
Range	Engineered Flooring
Locking system	Click System
Finish	Lacquered
Glue / resin	Glue U-F - Resin 1206, 1274, Hardener - 2505, 7500 Casco-Nobel Sweden
Moisture content	7% +/-2%
Impact resistance	STN 492120 - max 1mm
Abrasion class	STN 492120 - 0.062G/1000 revolutions
Reaction to fire	Dfl - s1

Technical Information	
Level of use of according to EN13329*	N/A
Suitable for underfloor heating detail	Yes - Electric and radiant if installed as per the instructions (note must not exceed 27 degrees)
Thermal conductivity	0.14 W/mK
Effect of castor chairs	N/A
Resistance to staining	EN 13442 Grade ≥4
Slip resistance	EN 14342: 2005 + A1:2008 and CEN/TS 15676:2007
Formaldehyde emission	Class E1
Laying detail	Must be laid as a floating floor (see instructions)

Dimensions & packaging	
Product dimensions metric	W207mm xL2,200mm x T14mm
Quantity	7 Full planks or 6 full plank and 2 halves
Product packed dimension	H105mm x W2,020mm x D225mm
Volume coverage / pack size	3.18 m/sq
Product packed weight	25.6kg



The mark of responsible forestry

## Key

**F** = FSC®

**P** = PEFC™

**UK** = UK Manufactured

† = Subject to availability



**HOWDENS JOINERY CO.** MAKING SPACE MORE VALUABLE

Issue Date: 7 December 2016 11:09 AM

The company has a policy of continuous product development and reserves the right to change any products and specifications at any time.

## Care & Installation

### Care and maintenance

Floor mats are recommended for use at front entrance to the property.  
Felt pads & castor cups are recommended under chairs and heavy furniture.  
Move furniture carefully to avoid damaging under chairs and heavy furniture.  
For general cleaning use soft broom or vacuum cleaners suitable for hard floors.  
Regular cleaning with a well wrung out cloth/mop is advised  
Do not use steam mops or cleaners  
Do not leave any water on the floor, wipe up any spills immediately  
Do not use cleaning agents such as wax, polish or oil  
Direct sunlight may have an effect on the colour of the floor over a period of time  
Sand back and re-lacquer up to 3 times  
Use the floor exclusively under the recommended conditions in the instructions  
We recommend that floor mats are used at entrances to the property where timber flooring is installed. This will help avoid abrasive particles damaging the surface.  
Self-adhesive pads and castor cups should be fitted to furniture to avoid scratching where applicable. Note: Heavy scratching could break the seal on the flooring causing damage  
General cleaning of the floor should be done using a soft broom or vacuum cleaner. Do not use abrasive cleaners, steel wool or scouring pads, as they will damage the floor  
For full details please see the fitting instructions supplied with the flooring

### Fitting instructions

For full details please see the fitting instructions supplied with the flooring

### Important notes

Remove all previous floor coverings.  
A room temperature of 18° C - 24° C, a relative humidity of about 45-60% should be maintained.  
Moisture test must be carried out for all mineral based substrates (2.0 CM % for cement screed and 0.5 CM % for sulphate screed).  
Sealed packs must be stored for at least 48 hours where they are to be laid. Do not open packs until you are ready to install the flooring. Packs are to be laid flat on the floor with at least 50cm between packs and walls. Packs should be stored in a room with a minimum temperature of 18°C.  
Must leave 15mm expansion gap around the entire floor including cabinet legs, radiator pipes and door frames.  
Do not install cabinets over the floor.  
The maximum area without additional expansion joints is 8m of the boards width x 20m of length.  
If laying over a stone/mineral sub-floor, lay SDH0910 - Howdens Damp Proof Membrane (at least 0.2mm thick PE foil) first as a "trough" (i.e. lay over the floor and extend ends and sides up the walls for a few centimetres) or SDH0931 Paintable Damp Proof Membrane.  
For timber based sub-floor, lay Bitumen Moisture Barrier Paper.  
Suitable with Use SDH0900 Foam Underlay & SDH0909 High Performance Underlay (XPS) not with underfloor heating.  
For full details please see the fitting instructions supplied with the flooring

