

NORSOUND[®]

Specialist acoustic seals

FITTING INSTRUCTIONS

NOR710 PERIMETER SEAL - FITTING INSTRUCTIONS:

NOTE - Removal of door is NOT necessary when fitting this product.

1. Remove NOR710 from packaging.
2. Ensure the door is secured OPEN.
3. Now, ensure the frame edge at both jambs and at the head are free of dust & grease.
4. Carefully peel off the protective backing to expose the adhesive edge.
5. Line-up then locate the end of the adhesive edge along the door FRAME.
6. Ensure the tip of the non-adhesive back blade is just in contact with the door STOP.
7. Gradually locate the NOR710 along both jambs and the head ensuring it remains straight.
8. Once fitted, trim any excess with a sharp knife, blade or scissors.

NOR850 DOOR-BOTTOM SEAL - FITTING INSTRUCTIONS:

NOTE - The door MUST be removed from its frame prior to fitting this product.

1. Remove NOR850 components from packaging.
2. Measure the width of the door then cut the aluminium carrier and the black seal insert to suit.
3. On the bottom of the door, measure and mark out the position of a 30mm wide, centrally located rout.
4. Using a router, carefully cut a rebate to a depth of 7mm.
5. Fit the aluminium carrier into the rebate and secure with the screws provided.
6. Now slide the black seal into the carrier.
7. Carefully position an end-cap over the end of the unit and secure with the pins provided.
8. Repeat step #7 to secure the remaining end-cap.

