

# Quick Fit Latch/Bathroom Bolt – Installation Guide



Fitting a Quick Fit latch or bathroom bolt is a quick and simple process. Using a 25mm drill bit, holes can be drilled for the latch/bolt and spindle.

**Step 1**



Using a 25mm drill bit, bore out to 75mm in depth

**Step 2**



Using the same bit, drill the hole for the spindle

**Step 3**



Insert the latch and spindle

The Quick Fit latch and bathroom bolt are supplied with a round strike plate as well as a traditional rectangular strike plate. This is designed to further reduce the installation time and improve the aesthetics of a door / frame. Use a 32mm drill bit for the round striking plate and centre align before screwing in.

The latch and round strike plate can easily be installed into the door and frame in less than 5 minutes.

