

Door slide replacement

Door slide replacement

This leaflet is for all 50:50, 70:30 & Full height fridge/freezers



- Remove and replace all slides on the door, even if some are not broken.
- Do not use power tools to fit the sliders
- Replace each slider one at a time, for ease of fitting



1

Unscrew and remove old sliders.

2

Locate slider into the retainer and align with décor door edge, (the tab on the slider gives the correct distance of **21mm**).



4 Positions

3

Fix slider to decor door.




4 Positions

3.9 x 13mm
x8 Screws



4

Carefully snap off the distance spacing tabs.



4 Positions

5

Open / close doors checking for correct function. Add cover trims.



4 Positions