




Important Installation Tips

Please Read...

1


Ensure
the tap is
connected
correctly

3 IN 1 tap



Please ensure correct connection positions to avoid any pressure build in the black feed pipe.

Dispenser




Please ensure correct connection positions as shown to avoid any pressure build in the black feed pipe.

2


Ensure
temperature
calibration and
vent installation
are correct

Set the drain valve as high as possible




Drain valve must be positioned vertically above the sink overflow level, to prevent waste water syphoning back through the Tundish.

Avoid air locks



The braided supply pipe must be above the drain level at all times to avoid any potential water spitting due to trapped air; clip the pipe if needed.

Always calibrate the temperature



Allow the tank to fully boil from cold then calibrate the boiling point using the dial on top of the boiler. More than one calibration may be needed to achieve the optimum setting. If water is spitting from the centre channel of the tap the calibration is set too high.

For more information search **ProBoil calibration** on **YouTube** or call 01489 773176 for technical support