

Tap Flow Restrictors










Fitting Information:

Flexi Tail Taps: 2 x TAP0018 (4l/m) placed inside the 1/2" hot & cold flexible connector)

Copper Tail Taps: 2 x TAP0017 (4l/m) Placed between the hot and cold copper tail pipes and compression fittings, swage on pipe to be minimal

The tap flow restrictors are connected to the pipes below the sink as illustrated below:



Issue: 02/11/09