

Glass

Take extra care when cleaning the glass for the first time, following the installation processes the glass surfaces will require an initial clean. Wipe the glass with a clean, soft and grit-free cloth with a mild, non-abrasive, non alkaline cleaning solution. Rinse immediately with a clean damp cloth to remove any excess water from the glass surfaces. A squeegee may be required at this point also.

For routine cleaning, use a mild soap solution on a lukewarm damp cloth. Uniformly spray the cleaning solution or apply it with a clean, soft, grit-free damp cloth and rinse thoroughly. Dry the glass surface with a clean, grit-free cloth or a squeegee.

- Excessive use of water may damage the product.
- Do not allow any metal or hard parts of the cleaning equipment to contact the panel surfaces.
- Do not use excessive pressure whilst cleaning the glass.

Panel

Take extra care when cleaning the panels for the first time, following the installation processes the panel surfaces will require an initial clean. Wipe the panels with a clean, soft and grit-free cloth with a mild, non-abrasive, non alkaline cleaning solution. Rinse immediately with a clean damp cloth to remove any excess solution or water from the panel surfaces. The cloth should be almost dry to the touch.

- Excessive use of water will damage the panel.
- Do not allow any metal or hard parts of the cleaning equipment to contact the panel surfaces.

Frame

- The door frames should be wiped down with a clean, non-abrasive damp cloth as needed.
- Occasional use of a mild detergent and warm water solution may be necessary to shift stubborn dirt and stains.
- Under no circumstances use solvent or harsh detergents, bleach, scourers or any other abrasive cleaner on frame. If residue from glass cleaning does come in contact with these surfaces rinse immediately with clean warm water on a damp cloth.
- Excessive use of water may damage the frame over time.

Tracks

- Wardrobe tracks should be kept free of dirt and dust with regular brushing or vacuum cleaning.
- Regularly check and adjust the sliding doors where necessary to prevent scraping damage to the track.
- Occasional use of a mild detergent and warm water solution may be necessary to shift stubborn dirt and stains.
- Under no circumstances use solvent or harsh detergents, bleach, scourers or any other abrasive cleaner on the track. If residue from glass cleaning does come in contact with these surfaces rinse immediately with clean warm water on a damp cloth.
- Excessive use of water may damage the track over time.