

# Super Matt Surface Cleaning Guide

## SMCG01

Follow the information below for how to clean a Super Matt surface.



**It is important that surfaces are cleaned following the Howdens cleaning guide instructions below. Other cleaning products and processes should not be used. We recommend that marks or stains are removed as soon as possible.**

### General cleaning - Soapy water



**Items required:**

Soapy water, clean water, clean non-abrasive cloth, paper towel or microfibre cloth for drying.

**Cleaning Method:**

Use mild warm soapy water and a clean non-abrasive cloth.

Wet the cloth using the mild soapy water and squeeze out excess water.

Clean all areas required.

Using clean water, wipe all cleaned areas to remove any soapy residue .

It is important to dry immediately (using a soft paper towel or microfibre cloth) to provide a streak free finish.

**Recommendation**

Clean, Rinse, Dry.

Cleaning is best carried out in sections i.e. 1-2 frontals at a time or specific areas of a worktop.

### General cleaning - Super Matt Cleaner



**Items required:**

Unika Super Matt cleaner GAR0366, clean cloth.

**Cleaning Method:**


Follow cleaning guidelines on the reverse of the product.

Spray directly onto surface. Wipe over with a clean damp cloth and allow to dry.

**Recommendation:**

Cleaning is best carried out in sections i.e. 1-2 frontals at a time or specific areas of a worktop.

### Specialist cleaning - Melamine Sponge



**Items required:**

Melamine sponge, warm water.

**Cleaning Method:**

Ensure sponge is free from debris to prevent scratches.

Wet sponge under warm water.

Squeeze out excess water.

Rub sponge gently on affected surface area until marks are removed.

Start with a light pressure and increase as required in order to remove the mark.

It is important to dry immediately (using a soft paper towel or microfibre cloth) to provide a streak free finish.

Sponge can be rinsed, cleaned and used again. **Note:** After several uses the sponge will become worn and should be replaced.

Sponge can also be cut into smaller shapes for hard to reach areas.

**Recommendation:**

Use for more localised stubborn marks/stains.