

Kitchen Installation Manual



Section pages

Introduction.....	page 4
Supplied products	page 4
Guide - Hints and tips	page 5
Care and maintenance information	page 5
Cabinet installation fittings.....	page 6
Additional installation components.....	page 7
Cabinet overview	
Standard cabinet options	page 8
Handleless Profile System.....	page 8
Decor units	page 8
Standard height tower cabinet options (2112mm, including legs)	page 10
Midi tower units.....	page 11
Extra tall tower cabinet options (2292mm, including legs)	page 12
Planning dimensions	
Standard cabinets	page 14
Deep wall cabinets.....	page 15
Handleless Profile System.....	page 16
Cabinet corner - Standard wall.....	page 17
Cabinet corner - Deep wall	page 18
Section 1:	
Base cabinets.....	page 19
Section 2:	
Handleless Profile System	page 43
Section 3:	
Adapting a standard rigid cabinet to Handleless	page 71
Section 4:	
Drawer assembly and installation	page 77
Section 5:	
Wall and tower cabinet installation	page 103
Section 6:	
Decor accessories	page 119
Section 7:	
Worktops and backboards	page 131
Section 8:	
Door fixing and finishing touches	page 139
Section 9:	
Level H contract kitchens	page 145
Section 10:	
Integrated handle design	page 149
Section 11:	
Appliance tower configurations	page 159
Section 12:	
Midi tower and other appliance applications	page 211
Section 13:	
Curved units	page 233
Section 14:	
Inclusive kitchens	page 239
Section 15:	
Other useful assembly guides	page 247
Index	page 267

Introduction

This manual has been produced to give information on how to effectively install a Howdens kitchen. It contains not only installation information, but also assembly details on some products and components such as drawer boxes, corner base cabinets and other specific product items where assembly is required.

The manual is a complete guide to the assembly and installation of the kitchen and we would encourage you to keep this for reference when installing Howdens kitchens in the future. Your Howdens depot will be able to advise you on any installation queries you may have, but please refer to this manual in the first instance.

Whilst you may have installed many kitchens in the past, please ensure you are familiar with the basics of installation before starting the build.

One main point to note is the new Linear style of kitchen which can be created using new and existing components. Please refer to the linear **section 3**.

Howdens also have a handleless profile system enabling the opening of the slab doors and drawers whilst maintaining the clean lines and linear look of the handleless frontal. The handleless profiles are simple to fit and are covered in **section 2**.

Handleless profiles secure to the front of the base cabinets and the sides of the cabinets in larder/appliance tower applications.

Handleless profiles are supplied in specific lengths and should be cut down to the appropriate size to fit to the cabinet run. The planning section of this manual shows examples of the different profile applications and the principles for installation, which can be applied to your cabinets. It also covers the profile packs and fittings provided with them.

Supplied products

Cabinets are supplied with a fittings pack which contains the fittings required for installation.

NOTE: There may be some additional items in the pack such as worktop fixing brackets which will not be required for this handleless kitchen installation.

Handleless for the various applications are packaged separately and are supplied with the fittings required for installation.

Appliance towers are supplied in a standard format and will require modification depending on the appliance you are using. Follow the appliance tower section 6 of the manual for the different configurations and adjust the cabinet accordingly.

If you are installing a solid timber or solid surface worktop (such as granite), please refer to the separate installation instructions for these worktop types which are available from your Howdens Depot.



Recycle packaging in a safe environmentally friendly way.



Handleless Profile System ONLY



Choking hazard, keep away from young children.




Panels can be multi-drilled, use only correct hole location.



Protective eye wear required.




Beware of sharp edges on handleless profiles.



Secure to wall (additional fittings may be required).

Worktop Storage: Laminate and timber worktops should be stored flat on bearers. For Quartz/Granite worktops, follow the information supplied in the specific product installation manuals.




GENERAL NOTES:

- If fitting plinth drawers to base cabinets, these must be fitted before cabinet installation.
- The appliance tower back panel must be removed from the cabinet before installing an appliance. The back panel is only required behind a cupboard area, as the aperture for the appliance must not be enclosed due to ventilation.
- When adjusting the feet on base cabinets, ensure the thread is not extended too high.
- When routing laminate worktops, care should be taken not to burn the laminate. Always ensure the tooling is not blunt and the wheel bearings are moving freely.
- When cutting handleless profiles, ensure tooling is not blunt so as not to damage the profile.


Guide - Hints and tips




Installation should start in a corner, working out along the walls. Base cabinets should be installed first, followed by tower cabinets and finally wall cabinets. Worktops, doors, door handles, drawer fronts, plinths, pelmets and cornice are best fitted at the end of the installation.



Whilst the room is empty, check the position of the plumbing and electrical points.



You may need to remove skirting boards along the length/walls of the cabinets for some installations.



It is important that all cabinets are installed both plumb and level before starting.



Be aware of concealed plumbing and electrical wiring when drilling into walls.

IMPORTANT:

Before fixing any cabinets to the wall, ensure the construction of that wall is capable of taking the weight of the loaded cabinet and the appropriate fixings are used. If in any doubt, please consult a professional.

IMPORTANT:

When fitting granite or quartz worktops, a metal bar should be fitted to support any unsupported spans. This may be where an appliance has been fitted between cabinets, where a gap has been left in a breakfast bar application or where the cabinet front support rail has been cut to accommodate a sink or hob. The metal bar can be fitted directly under the profile, or under the MDF worktop support rail where applicable. Please refer to the granite/quartz installation guides for details of the metal support bars and fitting method.

Glue:

When using PVA wood glue, wipe away excess glue with a clean damp cloth.

NOTE: EXCESSIVE USE OF GLUE IN PANEL HOLES MAY CAUSE SPLITTING.



IMPORTANT: When tiling up to the curved wall cabinet, ensure sufficient gap is left to enable the door to open correctly.





Ensure this installation manual is retained for future use.



QR code

Some areas of installation now have a QR code referenced against them. Scan the QR code using your smart device to access a document or short animation/video giving an overview of the assembly of that particular component.

NOTE: During transit, standard and deep wall cabinet shelves have been secured in the base of the cabinet with retaining clips. Before installation, remove the shelves from the cabinet by removing the clips. These clips can be discarded. Shelf pegs have been supplied in a separate fittings pack.



Care and maintenance information

General cleaning instructions

Use a damp cloth and wipe dry to remove any smears. For stubborn marks, such as grease deposits, use a damp cloth pre-soaked in a warm weak soapy solution and wipe dry.

Do not use strong aggressive household cleaners (diluted or undiluted) as these may adversely affect the finish coating and may invalidate the guarantee.

Please see the Howdens care and maintenance guide which is available from your local depot or on [Howdens.com](https://www.howdens.com)

Storage of timber doors

Care should be taken with the handling and storage of product, as environmental changes will affect the performance due to the timber based substrate.

Ensure the product is handled with care and stored horizontally, on a flat, level and dry surface. Avoid storing or installing the product where moisture or temperature changes are prevalent.

Do not store product in garages, containers, or vans and do not fit or store in rooms that have wet trades such as plastering, which are not yet fully dry.


Cabinet installation fittings

The fittings shown on these pages are standard fittings that may have been supplied with the cabinet pack for installation. Other fittings may be shown in this manual for specific cabinet types. These will be referenced at the appropriate stages.

NOTE: Wall fixing screws have not been supplied due to different wall types requiring different fixings.


NOTE: In addition to the wall fixing brackets, cabinets must be secured at the bottom of the cabinet through the back rail. See wall cabinet fixing for more information.

Wall and base cabinets




Additional installation components


Screws and fixings




45mm or 50mm CSK screw




30mm CSK screw




25mm CSK screw




13mm Flange head screw




12mm Pan head screw



EURO screw




14mm screw




6 x 22 Wooden dowel

Deep wall cabinet shelf fixings




Concealed shelf peg housing




Concealed shelf peg


Hinges




110° Kitchen hinge



170° Kitchen hinge



Slimline hinge




Integrated soft close hinge


Brackets and joints




90° Die cast bracket




Larder bracket




Spring clip - Female




Spring clip - Male




Spring clip - Female




Spring clip - Male




Stable door stop




Worktop connector bolts




Steel jointing plate



Steel jointing plate




Long steel jointing plate




Worktop fixing bracket


Caps




Screw cover cap




Bumpons (x2)




KD block




Hinge hole cover cap



5mm Cover cap



Corner cover cap




Self-adhesive cover cap

Cabinet overview

Standard Cabinet Options


The following six pages show Howdens cabinet options and configurations.

Wall




Base

Note: Shallow depth base cabinets (290mm) available in handleless cabinet options, (**).




Handleless Drawer Unit Frontal sizes

(For use with handleless profile system)




Decor Units




NOTE: Glass doors are not available in all ranges.



Cabinet overview






Note: Installing a sink?
Make sure you use a dedicated Sink Base cabinets for easier installation, (ask depot for details).



Cabinet overview

Standard Height Tower Cabinet Options (2112mm, including legs)



Cabinet overview

Single Oven with 3 Drawers	Single Oven x2	Single Oven with Warming Drawer	Single Oven with Warming Drawer & Microwave	Single Oven with Warming Drawer & Microwave	Single Oven with Warming Drawer & Microwave	Single Oven with Microwave	Single Oven with Microwave (no fascias)	Single Oven with Compact Oven	Single Oven with Compact Oven (no fascias)
page 172	page 172	page 178	page 178	page 178	page 178	page 176	page 176	page 176	page 176

38cm Microwave Single Oven (LAMONA)	38cm Microwave Warming Drawer (LAMONA)	Microwave with Fridge/Freezer	Microwave with Compact Oven	Microwave/ Compact Oven with Warming Drawer
page 194	page 195	*	page 187	page 189

*For integrated handle (back chamfer door) configurations will change from a 991mm to a 945mm door with fascia.

NOTE*: Push to open can also be used on these doors



Midi Tower Units

Double Oven	Single Oven	Single Oven with Warming Drawer	Microwave	Compact Oven	Microwave with Warming Drawer	Fridge or Freezer	Larder
page 215	page 217	page 219	page 221	page 221	page 223	page 225	page 227


Cabinet overview

Extra Tall Tower Cabinet Options (2292mm, including legs)









Note: For tall towers a 180mm top box is used above the standard larder/tower.












*For integrated handle (back chamfer door) configurations will change from a 991mm to a 945mm door with fascia.



Cabinet overview

Single Oven with 3 Drawers	Single Oven x2	Single Oven with Warming Drawer	Single Oven with Warming Drawer & Microwave	Single Oven with Warming Drawer & Microwave	Single Oven with Warming Drawer & Microwave	Single Oven with Microwave	Single Oven with Compact Oven
							
page 172	page 172	page 178	page 178	page 178	page 178	page 176	page 176



38cm Microwave Single Oven (LAMONA)	38cm Microwave Warming Drawer (LAMONA)	Microwave with Fridge/Freezer	Microwave with Compact Oven	Microwave/ Compact Oven with Warming Drawer
				
page 194	page 195	*	page 187	page 189

Full Height Fridge/Freezer (50/50 split)	Full Height Fridge/Freezer (70/30 split)	Corner Larder Tower 1000mm	Corner with Larder Tower 300, 400, 500, 600, 1000mm
			
page 202	page 202		


Planning dimensions - Standard cabinets

CONSIDERATIONS


- Use **25mm screws** when fitting **12mm decor ends**.
- When standing up tall tower units, an additional ceiling height of **50mm** will be required.




Wall hanging brackets, see **page 105**.



Wall fixing rail




Base cabinet fixing bracket




Planning dimensions - Deep wall cabinets

CONSIDERATIONS


- Use **25mm screws** when fitting **12mm decor ends**.
- When standing up tall tower units, an additional ceiling height of **50mm** will be required.




Some deep wall cabinets use standard wall fixing method.




Concealed wall hanging brackets, see **page 108**.



Wall fixing back rail



Base cabinet fixing bracket







Planning dimensions - Handleless Profile System


CONSIDERATIONS

- Worktop height is elevated by 30mm compared to other kitchen ranges, due to the profile application.
- Tower applications require a 30mm spacing on each side to allow for the profile fitting.
- Wall unit doors will require a push to open magnetic catch.
- Base and tower cabinets are supplied pre-notched for profiles.


- When standing up tall tower units, an additional ceiling height of **50mm** will be required.




Wall hanging brackets, see **page 105**.




Wall fixing rail



Base cabinet fixing bracket



Soft close piston




Planning dimensions - Cabinet corner

Standard wall cabinet


Always plan your kitchen/start the installation from a corner.
Movable centre uprights are fitted to the cabinets to give flexibility to the configurations.
Ensure consideration is given to cabinet alignment and lighting.

NOTE: 600mm corner wall and adjacent cabinet can be replaced using a 631 L shape wall as required.


931 Corner




1031 Corner



1131 Corner



1231 Corner




Planning dimensions - Cabinet corner

Deep wall cabinet


Always plan your kitchen/start the installation from a corner.
Movable centre uprights are fitted to the cabinets to give flexibility to the configurations.
Ensure consideration is given to cabinet alignment and lighting.

NOTE: 700mm corner wall and adjacent cabinet can be replaced using a 731 L shape wall as required.


931 Corner




1031 Corner



1131 Corner




1231 Corner




Section 1

Base cabinets



Pre-build - Cabinet leg	page 20
Pre-build - Alternative cabinet leg	page 22
Pre-build - Cabinets	page 23
Pre-build - Corner base cabinet centre upright fixing	page 24
Pre-build - Deep wall cabinet	page 25
Corner base cabinet - Asymmetrical fillet	page 26
Corner base cabinet - Symmetrical fillet	page 27
Corner base cabinet	page 28
Connecting and levelling	page 30
Wall fixing	page 30
931 Corner base cabinet	page 31
Blanking panel application guide	page 33
Sink base unit	page 34
Built-under oven housing	page 36
Built-under oven housing drawer	page 37
Built-under oven housing - Leg conversion kit	page 39
Hob separator plate	page 40





Section 1 - Base cabinets

Pre-build - Cabinet leg


Alternative leg style shown on page 22.

Leg Locations




Leg Pack:
 x4 Leg Top
 x4 Leg Base
 x4 Glide
 x2 Cover Cap
 x2 Plinth Clips


1 Push top into cabinet base.



2 Knock in the 3 dowels to secure. **NOTE:** Dowels should be flush with the surface once secure.










3 Screw in leg base and adjust. **NOTE:** Leg has a nominal height mark at 170mm and can be adjusted +/- 22.5mm.



4 Adjustment of the cabinet back legs can be made from inside the cabinet.

Fit cover caps to the cabinet holes once adjustment is complete.





Section 1 - Base cabinets

Pre-build - Cabinet leg



Plinth clip

Lay the plinth face down with the bottom edge against the run of cabinet legs. Mark the positions of the leg onto the back of the plinth using a pencil.


NOTE: In a run of units, plinth clips are not required to be fitted on every leg.

Position the plinth clip bracket to the plinth, aligning the notch with the pencil mark and secure using the screws provided.



NOTE: Use the plinth clip to space the bracket from the top edge. When fitting a return plinth turn the bracket 180 degrees so the clip, when fitted, is towards the bottom of the panel and clips do not clash when fitting to the same leg. Fit the clip into the bracket, slotting into place.



Turn plinth bracket 180 degrees so clip can be fitted to the bottom of the bracket



Return plinth




NOTE: Additional plinth clip/bracket can be positioned at the bottom of the leg, (43mm from bottom edge), if required in return application

Fitting legs to wall cabinets



When using the leg in a shallow base unit application (ie. fitting to a wall cabinet), the plastic location dowels will require removing.


- 1 Remove the plastic location dowels.



- 2 Position the legs in line with the other leg positions in your cabinet run.


Pilot drill and secure through the three fixing holes in the leg top with screws.





Section 1 - Base cabinets

Pre-build - Alternative cabinet leg



Cabinet leg

Fit the leg boss to the cabinet aligning the plastic lug with the hole.


NOTE: Make sure the flange of the leg boss overlaps the cabinet side panel.

Firmly tap the centre plastic pin in the leg boss to expand the plastic lug and secure the leg boss.

NOTE: Screws can be used, however are not required and therefore not supplied.


Fit the leg section, pushing into the leg boss, then screw on the foot section.

NOTE: Legs can be cut down using a hacksaw, if required.




1

Push into base




2

Knock in dowel.
Ensure the lip of the leg overlaps
the base and side panel joint.




3

Push in leg section



4

Screw in foot section



Tower pull-out 5th leg fixing


For extra stability and support fit a 5th leg to the front central position of the cabinet base panel.

Use the information below to secure the leg.

NOTE: We recommend the additional leg is secured to the cabinet before the pull-out accessory is fitted.



1


Remove the plastic location dowel.



2


Position the leg centrally and secure in line
with the other leg position.






Section 1 - Base cabinets

Pre-build - Cabinets




Worktop fixing brackets

Support the end panel before knocking in the fixing bracket.



Worktop fixing bracket




Base cabinet, wall fixing brackets


Brackets should be fitted to each end of the cabinet and in alignment with the access holes drilled in each end of the back rail.

Once the cabinet is secured to the wall, lock the bracket in place using a screw through the round hole.


NOTE: Cover caps are provided to blank the access holes.



16mm Flange head screw




Fixing bracket




Mid shelf support, 800/900/1000mm cabinets

Shelf pegs have been supplied for centre fixing, as shown. This is to prevent shelf deflection.

If an additional peg is required at the back of the cabinet a 5mm hole will need to be drilled before locating the shelf peg. This should be done for Level H compliance.




Metal shelf barrel peg



Section 1 - Base cabinets


Pre-build - corner base cabinet centre upright fixing




NOTES: Remove the transit rail from the cabinet. The centre post has not been pre-fitted into the cabinet to allow for different corner door size applications.

Application example

1000mm Cabinet




600 Door position




400 Door position

800mm Cabinet




500 Door position




300 Door position

Assembly


1




Fixing positions for the centre post fixing have been pre-spiked into the cabinet rail and part pre-drilled in the underside of the base panel. Select the holes required and drill through using a 5mm bit.



2




Screws x4
(45mm)



Fit the new centre post to the cabinet and secure in place using the screws supplied.


NOTE: Make sure the upright is flush with the front edge of the cabinet.

Centre post x1



Section 1 - Wall cabinets









Pre-build - Deep wall cabinet




Concealed wall cabinet hanging brackets are supplied in the fittings pack.

NOTE: Power tools must not be used when fitting the brackets.

Some deep wall cabinets use standard wall fixing method.




For securing the deep wall cabinet to the wall, see **page 108**.



Section 1 - Base cabinets

Corner base cabinet - Asymmetrical fillet










800/900/1000mm Hi-line and drawer-line corner cabinets

Fit two fixing blocks to each side of the fillet top and bottom locating into the groove on one side and flush with the edge on the other.


Position the fillet to the cabinet centre upright and secure.

NOTE: For corner cabinets using different door sizes, remove the transit rail at the front of the cabinet and replace with the centre post supplied with the cabinet.

NOTE: If a run of base cabinets is to include a 'fitted' or 'freestanding' appliance, adjust the height of the cabinets to suit the height of the appliance.




NOTE: For integrated handle kitchen corner base cabinet fillet fixing, please refer to **page 150**.




Mark the wall 231mm from corner for 800 cabinets, 181mm from corner for 900 cabinets and 131mm from corner for 1000 cabinets. Position cabinet against wall up to the mark.

Level side to side and front to back by turning the adjustable ends of the feet as necessary.


DO NOT FIX TO WALL AT THIS STAGE





Section 1 - Base cabinets

Corner base cabinet - Symmetrical fillet



800/900/1000mm Corner cabinets


Fit two fixing blocks to each side of the fillet top and bottom locating into the groove on one side and flush with the edge on the other.

Position the fillet to the cabinet centre upright and secure.






NOTE: For corner cabinets using different door sizes, remove the transit rail at the front of the cabinet and replace with the centre post supplied with the cabinet.

NOTE: If a run of base cabinets is to include a 'fitted' or 'freestanding' appliance, adjust the height of the cabinets to suit the height of the appliance.

- 1 Fit two fixing blocks each side of the fillet top and bottom.
NOTE: In a corner application where two single cabinets are being used, the fixing blocks on both sides of the fillet should be positioned aligning with the edge.




- 2 Position the fillet to the cabinet centre upright and secure.
Fit the adjoining cabinet and secure fillet to the side fixing through the KD blocks.







Level side to side and front to back by turning the adjustable ends of the feet as necessary.

DO NOT FIX TO WALL AT THIS STAGE



Section 1 - Base cabinets

Corner base cabinet




800/900/1000mm Hi-line, drawer-line and larder corner cabinets

Position the cabinet you require to turn the corner and run at right angles to the first cabinet. Place the cabinet against the wall and line up with the corner fillet as shown in the diagram. Use the straight edge and a spirit level when adjusting the feet to continue the level. After levelling and positioning a number of cabinets in this direction, connect together, but not more than a run of 2.5M. Do not connect to the corner cabinet. Fix the cabinets to the wall, see **page 30**.


Fix with 2 countersunk screws through the 2 KD blocks on the back of the fillet into the end panel of adjacent cabinet.

NOTE: The cabinet is correctly positioned when an 18mm distance is achieved as shown.

Asymmetrical



Symmetrical






Corner larder

Fit the top section of the larder to the base section. Secure up through the front rail of the base cabinet with screws, and at the back with the worktop fixing brackets as shown.


Once the corner larder is in place, secure to the wall at the top using the larder brackets.

NOTE: If you are fitting cornice to the kitchen, do not secure the brackets to the exposed side of the unit. The bracket should be fixed to the cornice once fitted. The fillet will require cutting down for full height corner larder tower units.


IMPORTANT: To reduce the risk of damage to cut edges due to moisture ingress (where they are exposed to moisture) all raw edges must be sealed using a suitable moisture resistant sealant, such as waterproof varnish or silicone.




40mm CSK screw




30mm CSK screw




Larder bracket



12mm Pan head screw




16mm Flange head screw



Section 1 - Base cabinets

Corner base cabinet





931 Corner base cabinet

Place corner base cabinet tight into the corner. Level carefully ensuring that all 7 feet are adjusted correctly. Once it has been positioned it can be left until the cabinets on both sides are fixed to the walls. For assembly instructions, see **page 31-32**.

NOTE: The service void on the 931 corner cabinet is now between 66-72mm.


NOTE: See **page 33** for blanking panel application.





Section 1 - Base cabinets

Connecting and levelling








Place second cabinet up against the first. Adjust the cabinet to continue the level already set-up. Take care not to push cabinets closer to the corner than the mark on the wall. Do not connect to each other at this stage. Continue the run of cabinets on this wall until the first tower cabinet is reached or until the base cabinet run is complete.

Do not install open corner cabinets at this stage.

Having levelled a number of cabinets we recommend that the first few be connected together at this stage. Do not connect more than a run of 2.5m at a time.


Mark and drill 2 holes through the adjacent cabinet end panel only, away from hinges, drawer runners etc, using a 2.5mm drill bit. Then bradawl a starter hole and connect using the 30mm countersunk screws, to achieve a flush joint between cabinets. Take care not to force the cabinets out of line whilst drilling.

NOTE: For handleless profile installation, see **Section 2**.




30mm CSK screw

Wall fixing



Base cabinets


Secure the cabinet to the wall fixing through the bracket using appropriate wall fixing screws. Once secure fit a cover cap over the holes in the rail.



600 Built-under oven housing and floor mounted wall units

For built-under oven appliance cabinets, screw through the back rail.

NOTE: Wall fixings are not supplied.
Only use fixings suitable for the wall construction.



Section 1 - Base cabinets

931 Corner base cabinet






Illustration shows additional shelf pack fitted.

Assembly


- 1 Remove transit rail from the cabinet.




- 2 Remove small cabinet.




- 3 Lay the large cabinet on its back edge and fit cams.



- 4 Fit dowels, cams and cam studs to the small cabinet, turning cams to lock studs in position.
NOTE: Glue dowels into position.







Section 1 - Base cabinets

931 Corner base cabinet


- 5** Fit the small cabinet to the large cabinet aligning the dowels with glued dowel holes and cam studs with cams.

NOTE: Make sure all cam studs are secure.




- 6** Fit the feet (x7) to the underside of both cabinet sections, see **pages 20-21** for additional information.

Push top into cabinet base.




Knock in the 3 dowels to secure.

NOTE: Dowels should be flush with the surface once secure.



Screw in leg base and adjust.

NOTE: Leg has a nominal height mark at 170mm and can be adjusted +/- 22.5mm.






Mid shelves

Fit the shelf sections together using the cams, studs and dowels.

NOTE: Shelf components and fittings are supplied as an additional pack.


Fit the shelf pegs into the cabinet then position shelf.









Section 1 - Base cabinets

Blanking panel application guide







Assembly

- 1 Fit the blanking panel to the base and wall unit using suitable fixings.



Drill blanking panel.



52.5mm*


*Cut panel down by 52.5mm for the 900 corner base unit application.

105mm*

*Cut panel down by 105mm for the 800 corner base unit application.


205mm*

*Cut panel down by 205mm for the 631 corner wall unit application.



Section 1 - Base cabinets

Sink base unit



Scan the QR code with your smart device to access a digital copy of the kitchen installation manual

Important Notes:


A space saver plumbing kit & flexible connectors for taps must be used. Any access holes for pipework should be slotted to ensure panels can be removed with minimum disturbance to plumbing. Fittings supplied but not detailed in this leaflet are for installation purposes.

Assembly shown is for the 800/1000 sink bases.

This leaflet is a guide for installation and plumbing/panel cutting, details may vary depending on the sink & positioning of pipework


PRE-BUILD

1. Remove the transit rail from the top of the cabinet (800 & 1000 sink base only)
 2. Remove the loose panels from the cabinet (shelf, lower back panel & rail)
 3. Fit the legs to the cabinet following the kitchen installation manual (800 & 1000 sink base have 5 legs)
 4. If you are fitting drawers into the cabinet, remove the centre rail (800 & 1000 sink base only). Cut the rail in half and carefully work loose
- Note:** The mid shelf will not be required in a drawer application and should be discarded.



Assembly


- 1 Position the cabinet, level and secure to the wall in the positions shown. Connect to any adjacent cabinets.



IMPORTANT:

Ensure the middle leg is correctly adjusted to support the base panel.


- 2 Position the worktop and install sink & plumbing kit following the instructions supplied (see important notes above).




If pipework runs through the side of the cabinet, cut a slot for access.


Note: Plumbing kit shown is for pictorial purposes only (see important notes section).

- 3 Secure the worktop using the brackets and screws. **Note:** If using solid surface worktops (quartz/ganite), bracket and screw fixings are not suitable. A silicone fixing will be required in this application.



- 4 Fit the cams and dowels to the lower back panel.






Section 1 - Base cabinets


Sink base unit

- 5** Fit the lower back panel locating the cams onto the studs.




- 6** Measure for the dimensions of the pipework from each side of the cabinet. Mark and cut the slotted holes in the rail.


Important: Any access holes for pipework must be slotted to ensure panel can be removed with minimum disturbance to plumbing




- 7** Fit the rail to the top of the lower back panel aligning the dowel holes with dowels.




- 8a** **Drawer application only**
Fit the runners to the side panels of the cabinet in the positions shown.





Top drawer front fixing positions will require re-spiking




- 8b** **Shelf application (no drawers)**
Fit the shelf pegs/stud then position the mid shelf into the cabinet.
NOTE: Not required in drawer application.




Shelf Peg x4 (cabinet side panel)
Shelf Stud x1 (front upright)





Section 1 - Base cabinets

Built-under oven housing



Standard option shown

NOTES:


THIS GIVES INFORMATION FOR STANDARD AND LOW BUILT UNDER OVEN HOUSINGS
When fitting an oven below a hob, please consider the minimum required clearance for ventilation between the two appliances.
Check oven and hob matrix before fitting.

Drawer Option

Follow the leaflet supplied with the drawer box for the standard BUOH with drawer combination


Assembly

1. Fit legs
2. Fit bottom fascia brackets
3. Install cabinet
4. Remove transit rail
5. Fit worktop and top fascia brackets (if applicable)
6. Fit worktop
7. Fit appliance
8. Fit fascia(s)




Leg Positions

Leg Position (Low & std option with no drawer)
Note: These dimensions are also applicable when using the BUOH drawer ACK1259




Leg Position (Low & std option at the end of a run)
Note: These dimensions are also applicable when using a BUOH drawer ACK1258




See leaflet provided with BUOH drawer for installation applications.

Standard Option

Side View




Fascia (115mm) - Bracket fixing positions




Low Option


Side View




Top Fascia (45mm) - Bracket fixing positions




Bottom Fascia (67mm) - Bracket fixing positions





Section 1 - Base cabinets

Built-under oven housing drawer





IMPORTANT NOTES:



Please ensure there is sufficient clearance for the drawer to open once flooring has been installed

Assembly


- 1 Fit legs to the inner sides of the cabinet.



- 2 Fit runners to the inner sides of the cabinet.



Fit cabinet into place and adjust legs as required





Section 1 - Base cabinets



Built-under oven housing drawer

Assembly



- 3** Unlock and remove the brackets from the drawer.
Cut plinth section to length. Fit brackets to lower fascia (plinth) section.
NOTE: The height dimension of the bracket has not been given, as this will be determined by the height the cabinet has been set at. Once the cabinet is in position, the drawer can be fitted.
Offer the fascia up to the drawer to determine the height of the brackets.
Bracket fixing holes are slotted to allow for up and down adjustment.




- 4** Fit clips to upper BUOH fascia (115mm).
NOTE: The height dimension of the bracket has not been given, as this will be determined by the Appliance being fitted and the frontal configuration/alignment.
Offer the fascia up to the drawer to determine the correct fitting position.




- 5** Fit the fascias to the drawer box, locking into position.



- 6** Fully extend runners, then fit the drawer onto the runners.
Push the drawer back into the cabinet.




Scribe the bottom edge of the plinth front when fully extended if required.





Section 1 - Base cabinets

BUOH - Leg conversion kit





Runner fixing

Measure and mark runner fixing positions. Secure runner into place using the screws provided.




Leg rail assembly


- 1 Fit the rails to the underside of the cabinets using the dimensions below as a guide.




- 2 Assemble the drawer following the instructions, see **Section 4**.



- 3 Mark and fit brackets to the back of drawer front. Secure the front to the drawer box then fit the drawer to the runners.





Section 1 - Base cabinets

Hob separator plate



Ventilation of the hob is critical to both the safety and performance of the product.
Please see the specific Hob ventilation requirements contained within the Hob installation manual.

IMPORTANT NOTE:


When fitting a hob into a worktop, a heat resistant separator plate is required to isolate the underside of the hob (unless above an oven).

Separator plate may not allow use of internal storage drawer sets.


Assembly

Fitting depth depends upon worktop thickness and hob protrusion depth.



FRONT VIEW




- 1 Mark cabinet depths **X** and cut out section.
X +6mm for the bracket positions.



- 2 Cut the 6mm board supplied to the internal width of the cabinet. Fix the panel in place using brackets and screws (3.5 x 13mm) provided.
NOTE: Follow the diagram below for number of brackets and fixing locations.






Section 1 - Base cabinets


Hob separator plate

700mm, 800mm, 900mm, 1000mm hi-line cabinets



Notch out the plate around the centre rail.

800mm, 1000mm Double drawer line cabinets




Two additional brackets are required to fix the plates in place.


Prepare cabinet and plate(s) → Remove plate(s) → Fit worktop and hob → Fit plate(s)

Induction hobs ventilation

Induction hobs need ventilation channels
SIDE VIEW (Timber/Laminate worktop application)




When fitting a timber or laminate worktop, router the underside as shown to a depth of 3mm.



Induction hob & granite / solid surface worktop

PLAN VIEW (Granite worktop application)




When fitting granite worktops, the front rail of the cabinet will need to be routed (3mm in depth) at set intervals to allow for airflow (as above timber / laminate worktop method is not possible).

NOTE: Do not router the full length of the front rail, as this is required as support for the granite worktop.

Depending upon application a granite support bar may need to be fitted if front rail is reduced in size (and strength) significantly.

Gas hobs



Cut out as necessary for gas pipe connection etc.

Section 2

Handleless Profile System




Profile overview	page 44
Fittings packs overview	page 45
Before you begin	page 46
Worktop profile	page 47
Drawer profile	page 49
Worktop profile corner return	page 50
Drawer profile corner return	page 51
End tower profile	page 52
Mid tower profile	page 53
BUOH profile	page 54
Built under application	page 54
Internal corner piece	page 55
End caps	page 55
Appliance infill application	page 56
Island applications	page 57
External corner post	page 58
Base decor panel - cutting application	page 60
Drawer application	page 61
Standard drawer application	page 63
Other appliance applications	page 64
HL base cabinet for sink application	page 64
Securing worktops	page 65
Appliance at the end of a run	page 66
Push to open	page 67
Sink base unit	page 68

IMPORTANT: Any exposed chipboard edges should be sealed using a suitable waterproof varnish or Howdens GAR0021 (Soudal Silirub), this will help avoid moisture ingress around wet and high humidity areas.

Please see **Section 3** for adapting a standard rigid cabinet using the handle-less jig. This will also cover the spacer rails to elevate the worktop.

Scan the QR
code with your
smart device to
access a short
installation
animation






Section 2 - Handleless Profile System

Profile overview - Inc. codes and dimensions


Scan the QR code with your smart device to access a short installation video



End Tower Profile

Length: 1942mm (GPT**04)
2122mm (GPT**06)


Profiles are part of a range sales code which include fittings.



Mid Tower Profile

Length: 1942mm (GPT**03)
2122mm (GPT**05)

Profiles are part of a range sales code which include fittings.




Drawer Profile

Length: 3000mm (GPT**02)

Profiles are part of a range sales code which include fittings.





Please note: Dummy drawer profiles are not available in Handleless.



Worktop Profile

Length: 3000mm (GPT**01)

Profiles are part of a range sales code which include fittings.






Infill has an adhesive strip which secures it to the profile

Appliance Tower Infill

Length: 452mm (GPT**14) - Pair
602mm (GPT**13) - Pair

Fits behind oven fascia to help secure the appliance* in a tower application and fill the gap.

*Screw fix the appliance through the infill and into the profile/cabinet in a tower application only



BUOH Profile (vented)

Length: 600mm (GPT**07)




Profiles are part of a range sales code which include fittings. In-line profile joint connector supplied in profile SKU carton.

This profile is only required for standard BUOH. The low BUOH can use the worktop profile.


3 End Cap Types

Caps fit to the end of the profiles to cover the cabinet cut out.



Note: When cutting worktop and drawer profiles to length, allow 2mm each side for end cap thickness.



External Corner Pieces



Internal Corner Pieces







Section 2 - Handleless Profile System

Fittings packs overview - Inc. codes


Fittings packs are required to install the profiles

Fixing bracket kit - Used to secure all profiles to cabinets
(HYH8461)


Brackets x6 and Screws x24 (per pack)




x12 (4x30mm)



x12 (3.5x20mm)






Brackets clip into profiles



Larger mid profile application

In-Line profile joint connector - Used to secure two profiles together in a long run
(HYH8462)


Brackets x1 and Grub Screws x4




Joining two profiles

Drawer profile external return bracket - Used to secure the drawer profile on an external corner
(HYH8463)

Bracket x1, Grub Screws x2
& Wood Screws x2




x2 (3.5x13mm)




Bracket secures to the side of the cabinet

Worktop profile external return bracket - Used to secure the worktop profile on an external corner
(HYH8464)

Bracket x1, Grub Screws x2
& Wood Screws x2




x2 (3.5x13mm)



Bracket secures to the side of the cabinet

Laminate worktop fittings pack - Used to secure timber based worktops to the cabinet
(HYH8466)



x6



x6 (3.5x25mm)



x6 (3.5x20mm)



Section 2 - Handleless Profile System

Before you begin




The handleless cabinet installation is the same as any other Howdens kitchen. Please follow the other sections of this installation manual for all aspects of cabinet leg fixing, wall fixing and alignment.


IMPORTANT NOTE: When cutting profiles, a sharp cutting blade should be used. Care should be taken when handling the profiles due to sharp edges.

Base cabinets must be perfectly level and secured to the wall before the profiles are fitted. Measure the length of the cabinet run and cut the worktop/drawer profiles accordingly.


Note: Cabinet alignment should be made at the top front cut out.



Only cut the worktop and drawer profiles to length when you have measured and checked the correct lengths required. Profile, caps and corner return applications need to be taken into consideration.



When setting out tower and larder cabinets, these require a 30mm space between them for the profile to be fitted.






Section 2 - Handleless Profile System

Worktop profile - Length 3000mm

Scan the QR code with your smart device to access a short installation video




Follow the step-by-step guide for worktop profile application



A flush alignment of the worktop profile to the front of the cabinet is important. For this reason, we recommend cutting a small 100mm section of profile and using this to position the brackets.



- 1 Cut a small section of profile & fit bracket 'clicking' into place.

IMPORTANT: Please be aware of sharp edges when cutting profiles. Profiles must be cut using a sharp blade.




- 2 Position the bracket to the inside edge of the cabinet, ensuring the profile is square and flush with the front and top edges. Once in position, clamp the bracket in place and secure to the side of the cabinet using the screws. **Note:** Brackets are only required every 600mm in a run. For cabinet widths 700-1000mm, an additional bracket should be fitted to the front rail.

Clamp bracket




Use a square to ensure the profile is vertically aligned before securing


Secure bracket



Additional bracket fixing



Before securing profiles, seal the exposed cabinet edges at the front using the colour matched sealant GAR0021 or a proprietary silicone.








Section 2 - Handleless Profile System

Worktop profile - Length 3000mm

Scan the QR code with your smart device to access a short installation video





Brackets positioned every 600mm min



- 3** Cut profile to length and clip onto the fitted brackets. End caps should be considered when cutting profiles, as these would reduce the profile length overall by 4mm if fitting each end (2mm each end).
- *Note:** If planning an external corner return, the front worktop profile will require an additional 10mm added to the length. For internal corners, use the corner fillet to determine profile length.

Measure for profile

+10mm*



Cut & secure profile

IMPORTANT: Please be aware of sharp edges when cutting profiles. Profiles must be cut using a sharp blade.





Image shows profile 2mm short for end cap



Section 2 - Handleless Profile System


Drawer profile - Length 3000mm

Scan the QR code with your smart device to access a short installation video




Follow the step-by-step guide for drawer profile application

- 1 Cut profile to length and fit the brackets to the approximate locations on the profile. End caps should be considered when cutting profiles, as these would reduce the profile length overall by 4mm if fitting each end (2mm each end).
***Note:** If planning an external corner return, the front drawer profile will require an additional 10mm added to the length. For internal corners, use the corner fillet to determine profile length.



- 2 Position the profile to the cabinet cut out and align with the front edge. Move the brackets along the profile to their final locations against the cabinet side panels (see below for position examples). Secure brackets to the cabinets using the screws provided.



Note: Brackets are only required every 600mm in a run. For cabinet widths 700-1000mm, a bracket should be positioned over the centre post.




Section 2 - Handleless Profile System

Worktop profile corner return

Scan the QR code with your smart device to access a short installation video




Follow the step-by-step guide for returning your worktop profile around the side of the cabinet





- 1 Measure and cut the return section of the worktop profile.
Note: Allow for the 20.5mm dimension of the corner piece.



Note: Image shows side panels & corner posts. See island applications and external corner post for side panel/post fitting.






- 2 Fit the brackets to the back of the return profile and slide along. Secure using the grub screws.
Note: Position approximately 50mm in from each side. For island returns, 3 brackets may be required.



- 3 Fit the external worktop corner piece to the front end of the return profile.
Position the return section to the cabinet, aligning the external corner piece into the worktop profile.
IMPORTANT: Ensure the return profile is level with the top of the cabinet.
Mark the fixing holes. Pilot drill then secure the brackets to the cabinet side panel using the screws.



Use a square to ensure the profile is vertically aligned before securing






Section 2 - Handleless Profile System

Drawer profile corner return

Scan the QR code with your smart device to access a short installation video



Follow the step-by-step guide for returning your drawer profile around the side of the cabinet




- 1 Measure and cut the return section of the drawer profile.
Note: Allow for the 20.5mm dimension of the corner piece.

Note: Image shows side panels & corner posts. See relevant page for fitting application.

- 2 Fit the drawer profile brackets to the back of the profile in the positions shown. Use grub screws to secure.





Note: Position approximately 50mm in from each side. For island returns, 3 brackets may be required.



- 3 Fit the external drawer corner piece to the front end of the return profile.
Note: Dimensions shown are for guidance for bracket positions. Position the return section to the cabinet aligning the corner piece into the drawer profile.

IMPORTANT: Ensure the return profile is level.

Mark the fixing holes. Pilot drill, then secure the brackets to the cabinet side panel using the screws.





Section 2 - Handleless Profile System


End tower profile - 1942mm and 2122mm

Scan the QR code with your smart device to access a short installation video




Follow the step-by-step guide for end tower profile application

- 1 Fit the brackets to the approximate locations on the profile as shown.



2

Fit the profile to the side of the tower. Pilot drill the fixing holes and secure brackets to the side using the screws provided.




Fit two spacer rails to the adjoining decor end, using screws and fixing blocks to secure. Position the decor end to the side of the tower. Pilot drill fixing holes and secure the decor end panel through the cabinet and into the spacer rails.

Note: Ensure decor end is stepped forward by 20mm to allow for door alignment.

x2 Screws (3.5x20mm)

3





Section 2 - Handleless Profile System



Mid tower profile - 1942mm and 2122mm

Scan the QR code with your smart device to access a short installation video




Follow the step-by-step guide for mid tower profile application



- 1 Fit the brackets to the approximate locations on the profile as shown.



2





Fit the profile to the side of the tower. Pilot drill the fixing holes and secure brackets to the side using the screws provided.



Fit two spacer rails to the side of the tower and secure using screws (pilot drill fixing holes). Fit the adjoining tower and pilot drill fixing holes. Secure through the cabinet and into the spacer rails.

3





Section 2 - Handleless Profile System


BUOH profile - 600mm

Scan the QR code with your smart device to access a short installation video




On a standard built under oven housing installation, a specific profile which has slots for venting is required. This profile should be secured to the adjacent profiles in the run using the profile joint connector. Secure the connector to the profile using the screws provided.


Note: The sections of profile should be connected before fitting onto the brackets.



For the low BUOH application, the top 45mm fascia will require a different dimension to the one shown for non handleless kitchens (See below).



Note: Profile joint connector (x2) and screws (x8) supplied with BUOH profile




Built under applications



Built under appliances require a rail (RKC0071) to secure the appliance under the worktop

Dishwashers and built under fridge/freezers use the worktop profile above them.


NOTE: Rails (RKC0071) are required to be fitted in these built under appliance applications to enable the appliance to be secured at the top and to help avoid appliance tilting. Secure rails using the fixing bracket kit.



Side view of dishwasher application




Secure the rail using the brackets & screws



If the appliance has been lowered, the plinth may need to be cut to allow free movement of a dishwasher door in some applications. The plinth will need to be cut in all built under fridge/freezer applications by 30mm*.

Note: Iron on edging should be used for the exposed raw edges of the plinth.

*Based on Lamona product applications, may differ for other manufacturers appliances.




Fit rails (front & back). Back rail is required to stop appliance tilt/movement.



Section 2 - Handleless Profile System


Internal corner piece

Cut the profiles to the required length and use the internal corner pieces to join.



End caps

Fit the caps to the ends of the profiles and clip into place.








Section 2 - Handleless Profile System


Appliance infill application - 452mm and 602mm

Once the tower appliance has been fitted, position an infill section behind each side edge. Infills are provided in two lengths depending on your appliance (452mm and 602mm). These infills are compatible in the configurations shown below.

Note: Other configurations can be achieved by cutting down and using x2 infills where required. Infills are supplied as a pair.



Once in place, secure the appliance to the tower. Pilot drill the holes through the appliance and aluminium infill and into the profile and cabinet edge. Screw fix appliance as in a standard installation.







Section 2 - Handleless Profile System

Island applications




Below are some examples of set island size applications which can be achieved using standard pan drawer widths.

***Note:** Dimensions based on using an 18mm frontal with 2mm door bumpers.
For thicker frontals, increase the overall dimension accordingly.
Decor ends can also be used to achieve an end application.




Cabinets would require spacing apart by 100mm to achieve a larger island in this application.

Note: Worktop join also required.



950 Breakfast Bar

If using a breakfast bar at full width, the end panels used will need to be trimmed and edged to 841mm as shown below








Section 2 - Handleless Profile System

External corner post

Cut the fixing rails to the dimensions shown.
Fit the fixing rails to the post(s), using 40mm screws to secure.




For island applications where specific depths are required, follow the methodology below for working out the size of the end /corner post panel assembly.



Assemble the end panel/external corner posts, making sure measurements are checked before cutting panels. To secure the end panels to the external corner post use 30mm screws to secure through the fixing rails.

Note: Make sure the decor end panel profile aligns with the corner fillet profile.

Fit additional fixing rails to the back of the end panel securing with 40mm screws. Only one fixing rail may be required.



Measure the cabinet side to find dimension 'Z'.

Minus 109mm from this dimension (this is the corner post dimension 51.5mm x2, +6mm for spacing). This dimension is the width of your end panel. Note: Typically the end panel will be a half height frontal, cut and re-edged to the required width.





Section 2 - Handleless Profile System

External corner post

Fit the end panel/external corner post assembly to the top and bottom of the cabinet side panels. Secure from the inside of the cabinet using 30mm screws. Drawers will need to be opened to secure the end assembly.




Note: We recommend that drawers/frontals are fitted to the cabinets before fitting the side panels to ensure alignment.





Base decor panel - Cutting application


Follow the step-by-step guide for using a decor panel in the middle of a run of cabinets




Cabinet jig (TLS0652)

Use for decor end modification

- 1 Establish the position of the front edge of the decor panel so when fitted it will align with the frontal.




- 2 Position the handleless jig onto the top of the decor panel, using the drawer profile notch.
Note: Jig will require clamping to the panel as jig pegs cannot be used in this application.




Use a router to cut the decor panel (30mm diameter collar and 12.7mm router bit).

- 3 Finish the back of the cut decor panel notch using edging as required.

Note: We recommend any raw edges are sealed using the colour matched sealant or waterproof varnish.



- 4 Fit the decor end to the cabinet run following the handleless installation manual.



When fitting a decor end between units with a drawer profile, the same principles shown in this leaflet will apply using the jig.
Note: The decor end in this application will need to be two sections and notched at the top and bottom as shown.



Section 2 - Handleless Profile System

Drawer application



See section 4 for Upgrade drawer assembly details

Drawer runner installation


NOTE: Push to open drawer kits are only compatible with upgrade anthracite drawer boxes.

3 Drawer


4 Drawer



Push to open kit
required for bottom drawer





LH/RH runner x1 (pair)
8x13mm or 18mm csk screws
(where supplied)




NOTE: Bottom runner positions
are not pre-drilled.

2 Drawer




LH/RH runner x1 (pair)
8x13mm or 18mm csk screws
(where supplied)








Drawer application


Drawer fronts




Drawer is reversible
(only one set of fixing holes shown for extra clarity)



Drawer adjustment



Drawer front removal





Section 2 - Handleless Profile System


Standard drawer application

See section 4 for Standard drawer assembly details


Drawer runner installation

NOTE: Push to open drawer kits are only compatible with upgrade anthracite drawer boxes.

3 Drawer




3 Drawer (or 4 drawer look)




Bottom two frontals are secured together using jointing plates HKC0062



Top Drawer




Middle Drawer




Bottom Drawer





2 Drawer



Top Drawer



Bottom Drawer



*If using soft close adapters on the runners add an additional 5mm




Section 2 - Handleless Profile System


Other appliance applications

Built under Ovens

Built under double ovens are not compatible with the handleless profiles due to alignment with frontals. Only single ovens within the BUOH cabinet can be fitted with the handleless profile.




Single ovens



Double ovens

Fridge freezer tower

Location tabs on fixing brackets will need to be removed. Brackets should be aligned flush with the front edge of the cabinet (47mm from front of profile)




Slider bracket may require packing out by 5mm to ensure a good seal on the appliance.


HL base cabinet for sink application

When using a HL base (pre-notched) in a sink cabinet application, the front rail will need to be removed. Follow the step-by-step below for modification.


- 1 Remove the centre upright screw and front rail from the cabinet
Note: Use a jigsaw to carefully cut each side.




- 3 Cut a profile fixing bracket in half as shown.



- 2 Cut a small section from the front rail and fit to the top of the centre post using the screw previously removed.
Note: Fit flush to the back of the post.



- 4 Fit the shortened bracket to the back of the profile and fit the profile as shown in the worktop profile section of this manual (page 12).



Note: For dedicated sink base applications, use the jig to router the profile cut out as shown in the cabinet modification section of this manual.



Securing worktops

Worktop fixing


Solid worktops

(Quartz & Compact Laminate)

- 1 Apply a silicone bead around all top edges of the cabinets and profile. Once in place, position the worktop.

Note: Use a suitable silicone for quartz worktops to secure the.


The GIR0021 should not be used in this application.




Timber worktops

(Solid Wood & Laminate)

- 1 Drill a 10mm hole in the front rail of the cabinet.
Note: Cabinet front rail has a 5mm holes already in place for cabinet sizes 300 - 600mm and pre-spiked holes for 700 - 1000mm cabinets.





- 2 Place the bracket over the 10mm drilled hole and secure to the top of the front rail using the screws.



- 3 Use a hand screwdriver to secure the worktop to the cabinets using the screws, through the drilled hole/bracket and into the underside of the top.

Note: Use the worktop fixing brackets at the back of the cabinet for worktop fixing.






Section 2 - Handleless Profile System

Appliance at the end of a run

If an appliance is being located at the end of a run, the profile will be required to run onto a decor end and and/or be returned to the wall. For return applications, the decor end will require cutting for the profile to locate into (see base decor end cutting).


Note: Both applications will require the decor end/assembly to be secured at the base and back to the wall using brackets. A wall batten is also required to support the worktop at the back.

Back to wall return




Decor end to be flush with adjoining frontals

(decor end will require cutting for profile to fit into. See base decor end cutting)




Note: A cut out should not be positioned at the end of a run.



Profile into the decor end



Decor end to be flush with adjoining frontals



Note: A cut out should not be positioned at the end of a run.





Section 2 - Handleless Profile System

Push to open (HYH8438)


IMPORTANT: When fitting push to open, the hinges and hinge plates supplied with the cabinet will need to be replaced with the **110° unsprung hinges and hinge plates** supplied as part of the magnetic catch pack. These should be fitted to the cabinet in the positions of the existing hinges and hinge plates.

170° unsprung hinges are also available for corner cabinet applications as part of pack HYH8436.


Adapter plate

- 1 Fit the adapter plate to the hinge plate positions on the opposite side of the hinged door. Use euro screws to secure.


NOTE: If your cabinet does not have hinge plate holes drilled, pilot drill and use two 13mm CSK screws. Adapter should be fitted flush with the front edge of the cabinet and 70mm up from the bottom of the side panel.




- 2 Fit the piston to the adapter plate pushing into place.



- 3 Use the adhesive magnet or screw on magnet, positioning to the back of the door in line with the piston.




- 4 Adjust the position of the piston by turning the end.



631/931 cabinet application



When using the push to open on a 631/931 cabinet application, the piston should be fitted into the bottom shelf front edge, 160mm in from the cabinet side. This is to avoid any clash with the adjoining door.



Side panel edge application

- 1 Carefully drill the front edge of the cabinet. **NOTE:** Drill hole should be a diameter of 10mm x 76mm in depth.

- 2 Fit the piston into the hole. Fit the magnet to the door as shown above.




For wall cabinets with a centre post, place the piston into the front edge of the base panel as shown.




Section 2 - Handleless Profile System

Sink base unit



2 Drawer Cabinet



2 Drawer Cabinet
HL/PTO



Scan the QR code with your smart device to access a digital copy of the kitchen installation manual




Important Notes:

A space saver plumbing kit & flexible connectors for taps must be used.
Any access holes for pipework should be slotted to ensure panels can be removed with minimum disturbance to plumbing.
Fittings supplied but not detailed in this leaflet are for installation purposes.
This leaflet is a guide for installation and plumbing/panel cutting, details may vary depending on the sink & positioning of pipework

- PRE-BUILD**
1. Remove the transit rail from the front of the cabinet (Release cams, cut the rail and remove, remove studs).
 2. Remove the loose panels from the cabinet (shelf, lower back panel & rail).
Mid shelf is for HL cabinet only
 3. Fit the legs to the cabinet following the kitchen installation manual (800 & 1000 sink base have 5 legs)
- NOTE: The mid shelf will not be required in a drawer application and should be discarded.**

Assembly


- 1** Position the cabinet, level and secure to the wall in the positions shown.
Connect to any adjacent cabinets.



IMPORTANT:

Ensure the middle leg is correctly adjusted to support the base panel.


- 2** Fit the profile trim to the cabinet run.
Position the worktop and install sink & plumbing kit following the instructions supplied (see important notes above).



If pipework runs through the side of the cabinet, cut a slot for access.


NOTE: Plumbing kit shown is for pictorial purposes only (see important notes section).

- 3** Secure the worktop using the brackets and screws.
NOTE: If using solid surface worktops (quartz/ganite), bracket and screw fixings are not suitable. A silicone fixing will be required in this application.



NOTE: Large screw shown is not supplied, due to different worktop thicknesses requiring different size fixings.

- 4** Fit the cams and dowels to the lower back panel.






Section 2 - Handleless Profile System


Sink base unit

- 5** Fit the lower back panel locating the cams onto the studs.




- 6** Measure for the dimensions of the pipework from each side of the cabinet. Mark and cut the slotted holes in the rail.

IMPORTANT: Any access holes for pipework must be slotted to ensure panel can be removed with minimum disturbance to plumbing




- 7** Fit the rail to the top of the lower back panel aligning the dowel holes with dowels.




- 8a** **Drawer application only**
Fit the runners to the side panels in the positions shown.


2 Drawer Unit (inc. Drawer Profile)



PTO 2 Drawer Unit (without drawer profile)




- 8b** **Shelf application (no drawers)**
Fit the shelf pegs/stud then position the mid shelf into the cabinet. **NOTE:** Not required in drawer application.




Section 3

Adapting a standard rigid cabinet to Handleless



Planning dimensions	page 72
Fittings packs overview	page 73
Cabinet modification	page 74
Worktop profile	page 75
Worktop profile corner return	page 76





Section 3 - Adapting a rigid cabinet to Handleless

Planning dimensions


CONSIDERATIONS

- Worktop height is elevated by 30mm compared to other kitchen ranges, due to the profile application.
- Tower applications require a 30mm spacing on each side to allow for the profile fitting.
- Wall unit doors will require a push to open magnetic catch.
- Base and tower cabinets are supplied pre-notched for profiles.
- Support bars should be used over unsupported worktop spans (over 700mm) when using granite, quartz or thin worktops.


- When standing up tall tower units, an additional ceiling height of **50mm** will be required.




Wall hanging brackets, see **page 105**.




Wall fixing rail




Base cabinet fixing bracket



Soft close piston







Section 3 - Adapting a rigid cabinet to Handleless

Fittings packs overview - Inc. codes


Fittings packs are required to install the profiles

Fixing bracket kit - Used to secure all profiles to cabinets
(HYH8461)


Brackets x6 and Screws x24 (per pack)




x12 (4x30mm)
Base cabinet application



x12 (3.5x20mm)
Larder cabinet application






Brackets clip
into profiles



Larder mid profile application

In-Line profile joint connector - Used to secure two profiles together in a long run
(HYH8462)


Brackets x1 and Grub Screws x4




Joining two profiles

Drawer profile external return bracket - Used to secure the drawer profile on an external corner
(HYH8463)

Bracket x1, Grub Screws x2
& Wood Screws x2



x2 (3.5x13mm)




Bracket secures to the side of the cabinet

Cabinet jig (TLS0652)

Cabinets are pre-notched for profiles, but a jig is available for any standard rigid base cabinets that require cutting.

NOTE: A straight edge would be required for cutting tower cabinets.




IMPORTANT: The modification of cabinets must be carried out by a trade professional who is proficient in using a router and a plunge saw. It is estimated that the base cabinet modification time would be approximately 15mins and a tower cabinet approximately 25mins.


Worktop

All handleless
base cabinets

Drawer

Handleless
drawer profile
cabinets only





Section 3 - Adapting a rigid cabinet to Handleless

Cabinet modification

Cabinets (base and larders) are factory prepared and should not require additional modification. However, should you need to modify a standard cabinet, follow the guide below for cutting the panels. If using a HL cabinet for sink base application, please see page 26 for cabinet preparation.

NOTE: Jig and straight edges used should be clamped in place.



Base cabinets

Fit the location peg to the top of the jig, then position the jig to the front of the cabinet.

NOTE: Due to the removal of a dowel position when routing, a screw will need to be fitted in the front rail (on both sides) before routing the cabinet sides and front rail. Router the front edge of the cabinet as required, then the front of the top rail, using a straight edge to ensure a straight cut.


On double base cabinets (with centre rail) we recommend using a base cabinet L bracket for additional support of the centre post to the underside of the top rail.

Plunge router
30mm collar
12.7mm Router bit





Worktop

All handleless base cabinets




Drawer

Handleless drawer profile cabinets only




Tower cabinets

For tower cabinet modification, use a straight edge and router to remove 17mm of the front edge of the side panels. This should be to a depth of 18mm.





Tower

All handleless towers



Apply edging to the raw cut edges as required






Section 3 - Adapting a rigid cabinet to Handleless

Worktop profile - Length 3000mm


Follow the step-by-step guide for worktop profile application

- 1 Cut profile to length and fit the brackets to the approximate locations on the profile. End caps should be considered when cutting profiles, as these would reduce the profile length overall by 4mm if fitting each end (2mm each end).

NOTE: If planning an external corner return, the front worktop profile will require an additional 9mm added to the length. For internal corners, use the corner fillet to determine profile length (see Internal corner piece).



- 2 Position the profile to the top of the cabinets and align with the front edge. Move the brackets along the profile to their final locations (see below for position examples). Pilot drill the bracket locations and secure brackets to the cabinets using the screws provided.



- 3 Fit the worktop spacer rails. **NOTE:** When returning a profile around the side of a cabinet, the spacer rails may need to move from the exact locations shown below.


30mm Worktop Spacer Rail

RKC0072

2400 x 30 x 40mm

Position front, middle and back.


If fitting a sink or hob in a worktop, use the timber rail to form a frame front to back to support the top.



Space rails will require moving/cutting around some appliance applications.


We recommend that fixing brackets are positioned every 600mm.

Back worktop spacer rail fixing (Side view)



NOTE: When fitting a sink to the worktop, the back worktop spacer rail may require positioning to the wall. Cabinet front rail will require cutting in a sink application.


*Silicone should be used for Granite/Quartz tops



Section 3 - Adapting a rigid cabinet to Handleless


Worktop profile corner return

Follow the step-by-step guide for returning your worktop profile around the side of the cabinet




NOTE: Image shows side panels & corner posts. See Island applications and External corner post for side panel/post application.


- 1 Measure and cut the return section of the worktop profile.
NOTE: Allow for the 20.5mm dimension of the corner piece. Fit brackets to profiles in the approximate positions.



- 2 Fit the corner piece to the front end of the return profile then position to the side of the cabinet, connecting the corner piece into the front profile.




- 3 Move the brackets along the profile to their final locations (see above for position examples). Pilot drill the bracket locations and secure brackets to the cabinets using screws provided.




Section 4

Drawer assembly and installation




Standard drawer box pack	page 78
Standard drawer box pack - HL cabinet application	page 80
Standard 700/800/900/1000 drawer box	page 81
Upgrade drawer box pack - Soft close and non-soft close	page 83
Upgrade drawer box pack - Non-soft close	page 85
Upgrade drawer box pack - Soft close	page 86
Upgrade drawer box pack - Stabiliser kit	page 87
Upgrade drawer box pack - Soft close 800/900/1000 drawer-line	page 88
Internal drawers	page 89
Internal drawer towers	page 91
Internal drawer towers - other applications	page 93
Shallow drawer box	page 95
Push to open drawers	page 96
900 5 Drawer chest	page 98
Under sink drawer	page 99
Plinth drawer adaptor kit	page 101

NOTE: Drawer fronts may not be spiked for chosen drawer box fixing. Follow the dimensions shown in this section for drawer front spike positions.










Standard drawer box pack



Assembly

Standard pan drawer box illustrated, standard drawer box similar.






Section 4 - Drawer assembly and installation

Standard drawer box pack


Drawer fronts

NOTE: Drawer fronts may not be spiked for chosen drawer box fixing. Follow the dimensions shown in this section for drawer front spike positions.




Drawer runner installation

NOTE: Only runner fixing holes shown on the panels for extra clarity.



Runner adjustment



For the assembly and fitting of the chosen drawer type, please refer to the assembly sheets supplied with the drawer pack.


NOTE: Instruction shown in this section is for the standard drawer adjustment only. For further types please refer to the assembly sheet supplied with the drawer pack.


Although drawer adjustment should not be necessary, if required follow instructions below.

If when assembled the drawer fronts are not equally spaced and aligned, they will need to be adjusted. This is done by moving the front of the drawer runner up or down on either or both sides of the cabinet as follows:

- Bradawl in the centre of the front slotted hole **B** and fix with a 12mm shallow head CSK screw (where supplied) or 13mm CSK screw.
- Take out front screw **A**.
- Try the drawer, adjusting the runner up or down until the drawer front correctly aligns.
- Finally bradawl and fix a 12mm shallow head CSK screw (where supplied) or 13mm CSK screw into locking position **C**. Secure screw **B**.


Drawer adjustment





Section 4 - Drawer assembly and installation


Standard drawer box pack - HL cabinet application




Drawer box

Drawer fronts and side panel



Fit runners to the side panels in required locations.
Fit drawer fronts to drawers.




If you are installing an internal drawer in a standard drawer application, follow the dimensions below.




800/1000 Drawer application






Section 4 - Drawer assembly and installation

Standard 700/800/900/1000 drawer box




Drawer box (160mm)




Pan drawer box (275mm and 356mm)



In order to maximise the efficiency in the loading capability of the drawer box, a drawer reinforcement catch (supplied) must be fitted as shown in this assembly leaflet. The catch will ensure that the drawer can be loaded to its full capacity whilst keeping the optimum functionality in opening and closing.






Section 4 - Drawer assembly and installation


Standard 700/800/900/1000 drawer box

Drawer fronts - 2 drawer application





NOTE: Only the spike positions to be used on the drawer fronts are shown for extra clarity

Drawer fronts - 3 drawer application





Drawer runner installation

700/800/900/1000
2 Drawer




900/1000 3 Drawer



Runner reinforcement catch and adjustment

Fit the runner reinforcement catch to the cabinet above the runner in the position shown. Secure using the 13mm CSK screws.





Although drawer adjustment should not be necessary, if required follow instructions below. If no adjustment is required, proceed to step d.


If when assembled the drawer fronts are not equally spaced and aligned, they will need to be adjusted. This is done by moving the front of the drawer runner up or down on either or both sides of the cabinet as follows:

- Bradawl in the centre of the front slotted hole 'B' and fix with a 13mm CSK screw. Do not fully tighten.
- Take out front screw 'A'.
- Try the drawer, adjusting the runner up or down until the drawer front correctly aligns. Secure screw 'B'.
- Finally bradawl and fix a 13mm CSK screw into locking position 'C'.

Drawer adjustment




Pan drawer only




Section 4 - Drawer assembly and installation

Upgrade drawer box pack - Soft close and non-soft close


Drawer box




500 Pan drawer box



300/800/900/1000 Pan drawer box




Under sink drawer



NOTE: Drawer box back panels will vary in height depending on the drawer box chosen.

Assembly

Generic pan drawer box illustrated, drawer box, 300, 500, 800, 900 and 1000 pan drawer box similar.



Scan the QR code with your smart device, to access a short installation video.



IMPORTANT:


When fitting the drawer base to the drawer box the base **MUST** be aligned to the front of the drawer sides, so it sits flush with the back of the frontal once fitted.

Scan QR code above for more details.


1

Fixing tube x2
13mm Flange head screw x2


Front fixing x2
16mm Flange head screw x4



2





3




4


13mm Flange head screw x9




5



6








Section 4 - Drawer assembly and installation


Upgrade drawer box pack - Soft close and non-soft close

Drawer fronts - Soft close



Drawer runner installation - Soft close upgrade







Section 4 - Drawer assembly and installation

Upgrade drawer box pack - Non-soft close

Drawer fronts - Non-soft close




Drawer runner installation - Non-soft close



NOTE: The soft close adaptor kit is not compatible with the upgrade drawer kit.


NOTE: Only runner fixing holes shown on the panels for extra clarity.




Section 4 - Drawer assembly and installation


Upgrade drawer box pack - Soft close

Drawer adjustment




Drawer front removal





Section 4 - Drawer assembly and installation



Upgrade drawer box pack - Stabiliser kit




IMPORTANT NOTES:

This covers the drawer stabiliser kit, generic installation instructions


- 1 Fit the LH and RH stabiliser brackets, (indicated LH and RH on stabiliser brackets viewed from the front).



- 2 Cut the connecting rod to length.



- 3 Fit the rod to the stabiliser brackets using the adaptors.





- 4 Fit the stabiliser tracks to the cabinet.
The stabiliser tracks are marked LH and RH, (viewed from the front).
Positioning of the stabiliser tracks are dependant up on drawer depth and configuration.

20mm minimum clearance

107mm (pan drawer)

171mm (deep pan drawer)












Section 4 - Drawer assembly and installation

Upgrade drawer box pack - Soft close


800/900/1000 Drawer-line

Not applicable for 1000 3 drawer cabinet.





Internal drawers




IMPORTANT NOTES:


This covers the drawer assembly, installation and application examples for deep and shallow drawers

Assembly


Deep drawer box




1 Assemble drawer box back and sides.




2 Fit base and secure with screws.




3 Push fit front onto drawer sides.




4 Screw fit rails into position.




Shallow drawer box




1 Assemble drawer box back and sides.




2 Fit base and secure with screws.




3 Remove one end cap from the drawer front by removing screws and fit handle. Replace end cap once fitted.



4 Fit drawer front.






Section 4 - Drawer assembly and installation

Internal drawers


Installation and application

NOTE: Drawers are only suitable for use in cabinets when used in conjunction with 155° hinges

Deep drawer spacing




Shallow drawer spacing






IMPORTANT: When using a shallow drawer above two pan drawers, follow the diagram for shallow drawer runner positioning (see below).

***IMPORTANT:** Internal drawer being positioned lower for induction hob applications. 89mm dimension can be 125mm with 418mm dimension being 408mm if more room is required above in induction hob/thin worktop applications.



Internal three drawer





Application examples



Drawers can be fitted in multiple combinations in the 600mm base units. Shown below are just some of the combinations which can be fitted.

NOTE: Drawers will need to be fitted around hinge positions.



DL - STD DRAWER





DL - DEEP DRAWER




HL - STD DRAWER




HL - DEEP DRAWER






Internal drawer towers



500 Standard and Tall
Internal Larder Tower




600 Standard and Tall
Internal Larder Tower


Specific internal drawer sales options (5 Drawer)

Follow the information below for how to create specific internal drawer larder tower configurations.
NOTE: Other combinations can be achieved by moving and adding drawer options.


500 Std and Tall* Tower Option 1



500 Std and Tall* Tower Option 2




*Tall tower sales options will be supplied with the 180mm top box and increased size top door.
 Drawer configurations remain in the same positions.




Section 4 - Drawer assembly and installation

Internal drawer towers


600 Std and Tall*
Tower Option 1 (split door)




600 Std and Tall*
Tower Option 2 (split door)




600 Std and Tall*
Tower Option 3 (Single Door)**




Option 1



Option 2/3**




**Option 3 specific dimensions are in bold text.



*Tall tower sales options will be supplied with the 180mm top box and increased size top door. Drawer configurations remain in the same positions.

NOTE: Due to the middle hinge plate fixing not being centrally drilled on the door, in some ranges the top drawer runner may require fitting to a different position. Deep and shallow drawers can be switched in location as required to avoid hinge locations.



Section 4 - Drawer assembly and installation

Internal drawer towers - other applications

Installation and application

NOTE: Drawers are only suitable for use in cabinets when used in conjunction with 155° hinges


Application examples

Drawers can be fitted in multiple combinations in the 600mm appliance tower units.


Shown below and on the following page are just some of the combinations which can be fitted to the tower units.

NOTE: Drawers will need to be fitted around hinge positions.

50/50 APPLIANCE TOWER - STD DRAWER





50/50 APPLIANCE TOWER - DEEP DRAWER




See following page for 70/30 tower applications.

Adjustment



Once drawer front is adjusted install cover cap.






Section 4 - Drawer assembly and installation



Internal drawer towers - other applications

Installation and application



NOTE: Drawers are only suitable for use in cabinets when used in conjunction with 155° hinges





70/30 APPLIANCE TOWER - STD DRAWER Right hand door opening




70/30 APPLIANCE TOWER - DEEP DRAWER Right hand door opening




70/30 APPLIANCE TOWER - STD DRAWER Left hand door opening




70/30 APPLIANCE TOWER - DEEP DRAWER Left hand door opening





Section 4 - Drawer assembly and installation


Shallow drawer box




Assembly

To fit the shallow drawer runners and feet to the cabinet, follow the fixing details shown below.


300 3 Drawer 600 3 Drawer 500 2 Drawer 600 2 Drawer 400 4 Drawer 500 4 Drawer




IMPORTANT: ALL DIMENSIONS ARE TAKEN FROM THE BOTTOM EDGE OF THE UNIT



**Pan drawer front
(300mm & 600mm Only)
spike positions**




Bottom edge



Section 4 - Drawer assembly and installation

Push to open drawers



Drawer size

300 std & 300 Pan
350/400/500/600 std
400 - 600 Pan
700 - 1000 std & Pan

Runner/ Mechanism

30kgs/L1
30kgs/L3
30kgs/L3
50kgs/L5


Max loading*

20kgs
30kgs
30kgs
50kgs


*inc. drawer
box & frontal
HYH4405
HYH4406
HYH4406
HYH4407

Runner loading weight and mechanism type information can be found on the components in the locations shown below

Runner



Mechanism




Assembly



NOTE: Do not fit the drawer front at this stage.

- 1 Ensure the cabinets are square, level and secured to the wall before fitting drawer boxes. Drawer boxes must also be square to ensure correct operation of the push to open mechanism.

Cabinet





Drawer box



NOTE: Ensure the front of the drawer base is flush with the front of the drawer box.

Flush


- 2 Fit the mechanisms to the drawer box both sides.




Drawer box mechanism
(LH & RH) x1 pair

Click into position.

- 3 Fit the latch to the drawer runners both sides.




- 4 Fit the drawer front to the drawer box and fit the central support bracket (700, 800, 900 & 1000 drawers) to the front of the base panel and back of the drawer front.



Click into position

Runner latch
(LH & RH) x1 pair



Section 4 - Drawer assembly and installation


Push to open drawers

5 IMPORTANT: The synchronisation rod will need to be cut (using a hacksaw) to the appropriate length before fitting. Follow the table for the correct size for the application.

Drawer	Size
1000mm	724mm
900mm	624mm
800mm	524mm
700mm	424mm
600mm	324mm
500mm	224mm
400mm	124mm


6 Fit the adaptors to each end of the synchronisation rod (not applicable for 300mm drawers). Fit the rod by clipping into both mechanisms.

NOTE: Rod design is different for the 300 drawer box






7 700, 800, 900 and 1000 Drawer Boxes
Fit the bracket to the centre of the drawer box using the screws to secure.


NOTE: For 800 sink drawers, the bracket is positioned the other side of the synchronisation rod.



Adjustment


IMPORTANT: A minimum gap of 2.5mm between the drawer front and the cabinet is required for correct push to open operation. Use the adjustment wheel on each mechanism and the adjustment tool (supplied separately), making sure the gap is parallel and identical on both sides of the drawer.





Section 4 - Drawer assembly and installation

900 5 Drawer chest




NOTE: In some installations a support bar will need to be fitted to the underside of the front rail (at the back behind the front fixing block). Use support bar **TLS1081** for this application.

Components Required:

900 HL Cabinet x1
275 x 897mm Frontals x2
160 x 297mm Frontals x3
RKM1811 (L. Oak) RKM1851 (N. Oak) RKM8811 (White) HCB1811 (L. Grey Oak) Runner Support Pack x2
HYH7096 Drawer Box (Full Ext. Soft Close) x2
HYH7030 Drawer Box (Full Ext. Soft Close) x3


Assembly

- 1 Measure and mark locations of the runner support rails and blocks on the underside of the front rail & inside face of the back rail.




If required position the support bar (TLS1081) under the front rail at the back.


Drill the back rail (inside face) for dowel locations (depth 14mm).




Drill the front rail from the underside for dowel locations (depth of 14mm).




- 2 Apply glue to dowel holes in the end of the rails and blocks then gently tap dowels into position. Fit the block and rail together, then fit the rail and block to the front and back rail aligning dowels with glued dowel holes. Secure the blocks using two screws through the centre holes.




- 3 Fit the runners to the cabinet sides and centre rails using the screws provided.





Section 4 - Drawer assembly and installation

Under sink drawer



Under sink drawer




IMPORTANT NOTE:

Frontal fixing, drawer runners and adjustment are identical to the upgrade drawer box.


Sink drawer can be lowered by 10mm if additional space is required for certain sink applications. If moving the drawer, drawer front fixing positions will also require adjusting.

Assembly




1




2





10 x 12mm FH



3





x4 f g



6 x 12mm FH


4






Under sink drawer


800mm Sink Drawer




1000mm Sink Drawer




Sink Drawer (front view)




Sink Drawer (Side view)






Section 4 - Drawer assembly and installation

Plinth drawer adaptor kit



Application



NOTE: The plinth drawer adaptor kit is to be used with your soft close drawer runner system, which is supplied separately. Shown below are some application examples.



Assembly


NOTE: Fit the legs to your cabinet, see **pages 20-21**, (these are supplied with the cabinet).

- 1 Mark and drill 5mm holes on both sides of the unit.





- 2 Fit brackets to the base. Secure with euro screws through the slotted holes. Ensure the distance between the brackets is correct, then spike and secure the brackets at the front with screws provided.

1000 2 Drawer
Fit brackets to the base. Secure with euro screws through the slotted holes.




Dimension 'A'
400 Drawer = 364mm
600 Drawer = 564mm






Section 4 - Drawer assembly and installation

Plinth drawer adaptor kit




- 3** Assemble the drawer following the instructions, see [page 78-102](#).



- 4** Fit runners to brackets.
NOTE: Runners are supplied within the drawer pack. Fixings for the runner to bracket are supplied with the adaptor kit.

NOTE: Use upper set of holes as a standard. Lower set can be used depending on your leg/plinth height. If lower holes are used, ensure this is reflected with the dimensions on the back of the drawer front (stage 5).




- 5** Cut a section of plinth dependent on the width of your cabinet and spike fixing positions. Plinth width example shown is for a 500 base cabinet.


NOTE: Fixings to secure the plinth front to the drawer are supplied in the drawer pack.

NOTE: Apply edging to the sides and top of the plinth using an iron.

NOTE: Cut the plinth height to accommodate for framed ranges (25mm less height).




- 6** Fit handle.




- 7** Fit plinth front to drawer, then fit drawer to the upright cabinet.
NOTE: For drawer front fixing and adjustment, see [page 78-102](#).

Install the cabinet.
 Scribe the bottom edge of the plinth drawer front if required.




Section 5

Wall and tower cabinet installation




Wall cabinets

Pre-build	page 104
Clearance dimensions	page 104
Standard corner wall cabinets - Fitting	page 105
Deep wall cabinets - Fitting (option 1)	page 108
Deep wall cabinets - Fitting (option 2)	page 109
Fixing and connecting	page 110
Shelf installation - Standard and deep wall cabinets	page 111
Hob wall cabinet - Modification for microwave housing application	page 112
Hob wall/Half-height wall/Bridging cabinet	page 113
500mm and 600mm bi-fold unit	page 114
Aventos flap-stay mechanism	page 116




Tower cabinets

Fixing to wall and connecting	page 117
-------------------------------------	----------




Section 5 - Wall and tower cabinets

Pre-build



NOTE: Wall fixing screws have not been provided with this unit due to different wall types requiring different fixings.

Carefully make 2 holes using a 2.5mm drill bit (so as not to split the back panel) through the pre-drilled back rail and through the back panel. Widen the holes using a 5mm drill bit from the inside of the cabinet.




NOTE: 700, 800, 900 and 1000mm tall wall units have a vertical rail as opposed to horizontal.

In addition to this, a heavy-duty suspension bracket is used to secure. This has been supplied with the cabinet.

NOTE: In addition to the wall fixing brackets, cabinets must be secured at the bottom of the cabinet through the back rail. See wall cabinet fixing for more information.

Clearance dimensions



For Handleless Profile System, see **Section 2**.


Measure and mark a line for wall cabinet positioning.


IMPORTANT NOTE: A minimum distance must be left between the worktop in which a hob is to be fitted and adjacent cabinets or extractor positioned above. Follow appliance manufacturer's guidelines for hob and extractor installation.

***NOTE:** When fitting 'extra tall wall' cabinets against a 'extra tall' appliance tower (with top box added), this dimension will be 1372mm.



NOTE: Check hob and extractor installation booklet for details.






Section 5 - Wall and tower cabinets



Standard corner wall cabinets - Fitting

631 corner wall left hand / right hand





Mark the wall 31mm from the corner. Using this mark as the start of the 631 corner wall cabinet, mark the length of the cabinet on the wall and additional cabinets, as required. Place suspension bracket within these marks. Mark hole positions through the plates, drill and plug the wall. Screw the suspension brackets securely to the wall.


NOTE: It is important that a **MINIMUM** distance of 20mm is left between the ceiling and the top of the cabinet so it can be hooked onto the suspension brackets.



NOTE: Make sure that the 631 corner cabinet is placed to its mark before mounting additional cabinets.



Standard corner wall left hand / right hand





Fit a standard cabinet into the corner and mark the length of the cabinet on the wall and additional cabinets as required. Place suspension bracket within these marks. Mark hole positions through the plates, drill and plug the wall. Screw the suspension brackets securely to the wall.

NOTE: It is important that a **MINIMUM** distance of 20mm is left between the ceiling and the top of the cabinet so it can be hooked onto the suspension brackets.

NOTE: If you are tiling the kitchen wall, allow for the tile thickness between the cabinet and wall.

NOTE: When tiling up to a curved wall cabinet, ensure a sufficient gap is left between the opening door and the tile to enable the door to open correctly.




Put the cabinet to wall making sure that the suspension bracket arms engage over the suspension bracket. Turn screw 'A' for vertical adjustment, clockwise to raise the cabinet, anti-clockwise to lower it. Turn screw 'B' for horizontal adjustment, clockwise to pull the cabinet towards the wall, anti-clockwise to push it away.

NOTE: Do not use power tools to adjust suspension brackets.




NOTE: Cabinets can fall off the wall if the suspension bracket is not properly engaged.

NOTE: In addition to the wall fixing brackets, cabinets must be secured at the bottom of the cabinet through the back rail. See wall cabinet fixing for more information.




Section 5 - Wall and tower cabinets


Standard corner wall cabinets - Fitting



Standard 'L' shaped corner cabinet




Deep wall 'L' shaped corner cabinet



Corner wall filler rail

Fit the filler rails together.

Measure, mark and drill 5mm holes for the filler rail and secure using 45mm or 50mm CSK screws. Position the cabinet 31mm from the adjacent wall, as shown.



'L' shaped corner cabinet



Hold the 'L' shaped cabinet in the corner and mark the wall, remove cabinet. Measure, mark and drill wall. Fix the suspension bracket and chipboard rail with wall fixing screws, see below.

Position the cabinet carefully to the marks. Turn screw 'A' for vertical adjustment, clockwise to raise the cabinet, anti-clockwise to lower it. Turn screw 'B' for horizontal adjustment, clockwise to pull the cabinet towards the wall, anti-clockwise to push it away.

NOTE: A heavy-duty suspension bracket is used to secure the corner cabinet. This bracket has been supplied with the cabinet and may visually look different to the image shown. Fitting dimensions are as shown.

Fix the cabinet to the wall by screwing through the back panel and into the chipboard rails with flange head screws, top and bottom.

Finally, secure the cabinet through the back panel at the inside bottom corners as shown. This is for additional support.







Wall fixing rail

The long wall bracket (RKC0135) can be used to hang wall cabinets on, where service pipes or electrical cables do not allow for a single bracket fixing.


NOTE: The cabinet will need to be cut at the top, so the wall bracket can run through as shown (10 x 90mm).

Secure the bracket using suitable wall fixing screws (not supplied).








Standard corner wall cabinets - Fitting





Position the adjoining cabinet to the edge of the rail as shown, then mark and drill fixing holes, secure using screws.




30mm CSK screw



Drill three pilot holes and fit the fillet to the filler rail using screws.





30mm CSK screw




Fillet fitting for 'L' shaped corner cabinet

Fit the fillet to the door using plate and screws. LH or RH door can be used depending on opening preference.


Only one handle should be fitted, to the door without the fillet attached, to avoid clashing.




13mm CSK screw




Steel jointing plate





Section 5 - Wall and tower cabinets

Deep wall cabinets - Fitting (option1)







Use fitting option 1 or 2 depending on the wall brackets supplied

Fixing to the wall and adjustment.




NOTE: Wall fixing screws have not been supplied due to different wall types requiring different fixings.


Some deep wall cabinets use standard fixing method.



Cabinet adjustment


NOTE: Do not use power tools when making adjustments.





Section 5 - Wall and tower cabinets

Deep wall cabinets - Fitting (option 2)







Use fitting option 1 or 2 depending on the wall brackets supplied

Fixing to the wall and adjustment.



NOTE: Wall fixing screws have not been supplied due to different wall types requiring different fixings.

Some deep wall cabinets use standard fixing method.




Cabinet adjustment

NOTE: Do not use power tools when making adjustments.




Secure cabinet to the wall through the drilled holes in the back panel rail. This will prevent the cabinet from being dislodged from the wall.



Section 5 - Wall and tower cabinets

Fixing and connecting



NOTE: Wall fixing screws have not been provided with this unit due to different wall types requiring different fixings.

NOTE: If connecting to a 631 corner cabinet ensure that this is still in the position marked. When all required suspension brackets have been fixed to the walls, continue mounting and levelling the run of wall cabinets. Mark and drill in 2 suitable places towards the front of the end panels, away from hinges, using a 2.5mm drill bit. Secure the cabinets together using countersunk screws supplied to achieve a flush joint between cabinets. Take care not to force cabinets out of line whilst drilling etc.





NOTE: When connecting decor cabinets, ensure the countersunk screws are fixed through the adjacent non-decor cabinet to give a hidden connection.

NOTE: Plate racks and open decor cabinets with thick back panels can be secured direct to the wall using suitable wall fixings. We recommend that four fixings are used (two at top/two at bottom) to secure.


NOTE: If gables and gable returns are to be included in the run of cabinets, refer to the assembly instructions supplied with the product. Ensure that all cabinets are in the correct order as planned.

With the cabinets positioned, levelled and connected, mark the wall through the previously drilled holes in the rear of the cabinet. Take the cabinets away from the wall then drill and plug the wall. Move the cabinets back into position and screw securely to the wall.

For Handleless Profile System, see **Section 2**.






30mm CSK screw




Mark and drill 2 holes through the adjacent cabinet end panel only using a 2.5mm drill bit. Then bradawl a starter hole and connect with countersunk screws.

For Handleless Profile System, see **Section 2**.





30mm CSK screw



Section 5 - Wall and tower cabinets

Fixing and connecting



30mm CSK screw




NOTE: Wall fixing screws have not been provided with this unit due to different wall types requiring different fixings.

Tall glass dresser unit with spice drawer


Fix to the wall by drilling 5mm holes in 4 places (where applicable we suggest that 2 of these holes are drilled behind the drawer). Mark, drill and plug the wall. Secure with wall fixing screws.

NOTE: Before fixing to the wall check that the worktop will fit between the wall cabinet and the base cabinet.

Connect by drilling 2.5mm holes through the adjacent non decor cabinet end panel only. Bradawl starter holes and connect using countersunk screws.






Drill 2.5mm







Shelf installation

Standard wall cabinets




Deep wall cabinets





Hob wall cabinet - Modification for microwave housing




NOTE: Dedicated wall cabinets are available. However, this instruction shows how a Hob Wall Unit can be adapted.


NOTE: The modified Hob Wall Unit is for the appliance housing.

Unit preparation

- 1** Remove the back panel from the unit discarding staples.






- 2** Remove the wall fixing rail.




Cabinet fixing

Secure the cabinet to the wall using the suspension brackets.
Secure through the adjoining cabinets and into the hob cabinet for additional fixing.


Application examples






Section 5 - Wall and tower cabinets


Hob wall/Half-height wall/Bridging cabinet




600mm Integrated microwave top unit




300/350/400/450/500/600/800mm Half height cabinet



1000mm Bridging cabinet



1200mm Half height cabinet



NOTES: When fitting two half height wall cabinets on top of each other, any gaps between cabinets can be filled with a suitable caulk or silicone filler. Two half height wall cabinets on top of each other will require a magnetic catch (push to open) fitted to the top cabinet.



Assembly

IMPORTANT NOTE:


There are two types of flap stay depending on the size of your door. Whilst the correct flapstay will have been provided for your chosen Cabinet type, the following applies:

x1 Flap stay A (HKE0054): 300 - 600mm doors and x2 for 1000 doors
x1 Flap Stay B (HKE0055): 700 - 900mm doors


- 1 Mark out the cabinet end fixing positions and secure the bracket using the screws.




- 2 Mark out the frontal and fit the bracket using the screws to secure.



- 3 Fit the door to the cabinet using the hinges.



- 4 Clip on the flap-stay to the brackets, clicking into position.





Adjustment setting number.

Adjustment

Adjust the tension in the flap-stay +/- to frontal weight (if applicable with handle fitted).


NOTE: A power driver with a PZ-2 bit can be used.





Section 5 - Wall and tower cabinets


500mm and 600mm Bi-fold unit



Assembly

IMPORTANT: Ensure the cabinet is level, plumb and secured to the wall before installing this product.


- 1** Using the template supplied spike runner fixing positions.




2

B RH Bifold support arm x1, HKC0039

C LH Bifold support arm x1, HKC0039





- 3** Lift the support arm and press piston onto the bracket pins.



- 4** Lay the doors face down and secure hinges.

NOTE: The joining hinge hole locations will need to be drilled in the top door.






Section 5 - Wall and tower cabinets

500mm and 600mm Bi-fold unit



5

Fit the door and cabinet plates.




NOTE: The plates are very similar in design. Make sure the correct plates are used.



Door plate x2




Cabinet plate x2




6

Fit the door assembly to the unit aligning the hinge and bracket arms with plates. Clip into place.




7





Adjustment



Up/Down




Left/Right




Up/Down




NOTE: To remove the top hinge and support arm from the plates, push the clip down on the plate to release as shown.





Section 5 - Wall and tower cabinets




Aventos flap-stay mechanism




HKE0069

Assembly


- 1** Using the dimensions below spike and pilot drill for flap-stay mechanism fixing positions.



- 2** Secure the flap-stay mechanism to each side of the cabinet.




Screw x6
(4x35mm CSK)





IMPORTANT:

- The arm of the flap-stay is spring loaded.
- Do not push the arm assembly down or leave in the down position.
- Remove mechanism before installing or removing the cabinet.


- 3** Fit the mounting plates to the back of the door using the screws shown.



DOOR ADJUSTMENT



- 4** Carefully raise the arms of the flap-stays to the upright position.
NOTE: Care should be taken when raising the arm as it is spring loaded.




Fit the door to the unit aligning the mounting plates with the flap-stay.


NOTE: Click the mounting plates into the arm as shown.


Finally fit the covers over the flap stays.

DOOR REMOVAL




DOOR TENSION ADJUSTMENT





Section 5 - Wall and tower cabinets

Fixing to wall and connecting



Larder





Place the first tower cabinet in position and level to bring it into line with the other cabinets. Fasten the right angled brackets to top of cabinet with 4x12mm pan head screws or 16mm flange head screws.

NOTE: Fit a 180mm top box to the larder tower cabinet to make it an extra tall tower, see **page 164** for fixing.

NOTE: If you have purchased cornice for the kitchen, do not secure the right angled bracket to the exposed side of the tower cabinet but secure to the cornice after fitting.

Mark, drill and plug the wall, see **page 30** and secure. Connect all tower cabinets with countersunk screws.


Where two tower cabinets fit side by side use 6x 30mm CSK screws.






Larder bracket

12mm Pan head screw


For Handleless Profile System, see **Section 2**.



16mm Flange head screw



For Handleless Profile System, see **Section 2**.




30mm CSK screw

Appliance towers


The appliance tower **MUST** be secured to the wall for extra stability using larder brackets and screws (supplied in the fittings pack). Wall fixing screws have not been provided with this unit due to different wall types requiring different fixings.

NOTE: Where applicable, secure the tower through the fixed back support panel.




Section 6

Decor accessories




Plinths

Fixing plinths.....	page 120
Return plinth.....	page 121
Plinth fixing with integrated dishwasher.....	page 122
Plinth sealer strip and plinth vent	page 122
Decorative plinth.....	page 123



Decor end panels and cornice / Pelmets / Thick decor end post

Fixing	page 127
Thick decor end post.....	page 129



Section 6 - Decor accessories

Fixing plinths




Plinth clip

Lay the plinth face down with the bottom edge against the run of cabinet legs. Mark the positions of the leg onto the back of the plinth using a pencil.

NOTE: In a run of units, plinth clips are not required to be fitted on every leg.

Position the plinth clip bracket to the plinth, aligning the notch with the pencil mark and secure using the screws provided.

NOTE: Use the plinth clip to space the bracket from the top edge. When fitting a return plinth turn the bracket 180 degrees so the clip, when fitted, is towards the bottom of the panel and clips do not clash when fitting to the same leg. Fit the clip into the bracket, slotting into place.







NOTE: Additional plinth clip/bracket can be positioned at the bottom of the leg, (43mm from bottom edge), if required in return application

Use fitting option 1 or option 2 depending on the clips supplied.

Inside corner - Spring clip option 1

Run the plinth into the corner and clip to all adjustable legs. Mark where the back of the plinth 'A' will join plinth 'B' at right angles. Make a mark of 60mm up on plinth 'B', and screw on the plastic part of spring clip with 2 pan head screws. Screw the spring clip onto the back of plinth 'A', 14mm from the end and 65mm up with 2 pan head screws.





Clip the plinth neatly back together.




Inside corner - Spring clip option 2

Run the plinth into the corner and clip to all adjustable legs. Mark where the back of the plinth 'A' will join plinth 'B' at right angles. Make a mark of 60mm up on plinth 'B', and screw on the plastic part of spring clip 10mm back with 2 pan head screws. Screw the spring clip onto the back of plinth 'A', 14mm to the screw hole centres and 65mm up with 2 pan head screws.


Clip the plinth neatly back together.





Section 6 - Decor accessories

Fixing plinths




Plinth clip use

Clips are provided to secure the plinth to the front legs of the cabinets.

When using narrow width cabinets in a run, a plinth clip on every leg is not required. We recommend clips are used at 600 - 1000mm intervals to ensure the plinth is secure.

Any clips left over should be retained and used for other applications, such as on an island installation, where additional clips may be required for other cabinets.




Return plinth



Measure, cut and shape the return plinth to fit the skirting board and floor if required. Iron the pre-glued edge banding onto the exposed end, (if applicable), of the front plinth. Mark the positions for plinth clips and fit to the plinths, see **page 120**.

NOTE: The plinth and return plinth clips fit one above the other on the same leg.


IMPORTANT: To reduce the risk of damage to cut edges due to moisture ingress (where they are exposed to moisture) all raw edges must be sealed using a suitable moisture resistant sealant, such as waterproof varnish or silicone.




Position the plinth clip bracket to the plinth, aligning the notch with the pencil mark and secure using the screws provided.

NOTE: Use the plinth clip to space the bracket from the top edge. When fitting a return plinth turn the bracket 180 degrees so the clip, when fitted, is towards the bottom of the panel so clips do not clash when fitting to the same leg. Fit the clip into the bracket, slotting into place.



Plinth




Turn plinth bracket 180 degrees so clip can be fitted to the bottom of the bracket



Return plinth




NOTE: Additional plinth clip/bracket can be positioned at the bottom of the leg, (43mm from bottom edge), if required in return application



Section 6 - Decor accessories


Plinth fixing with integrated dishwasher



When fitting a dishwasher, the plinth will need to be cut to allow for the door to open. Cut out a section of plinth using the dimensions given.

IMPORTANT: To reduce the risk of damage to cut edges due to moisture ingress (where they are exposed to moisture) all raw edges must be sealed using a suitable moisture resistant sealant, such as waterproof varnish or silicone.



Plinth sealer strip and plinth vent



NOTE: When fitting alternative plinth vents please refer to the installation instructions supplied with them.


Attach the plinth sealer strip by pushing onto the bottom edge of the plinth base edge. The strip can be mitred with a sharp knife at the corners.

Plinth sealer strip is to be used with the MFC plinths that are 15mm thick.




Where ventilation is needed under a cabinet, a plinth vent is supplied. Cut the plinth so as to bring the vent moulding into the centre of the cabinet that requires ventilation.

IMPORTANT: To reduce the risk of damage to cut edges due to moisture ingress (where they are exposed to moisture) all raw edges must be sealed using a suitable moisture resistant sealant, such as waterproof varnish or silicone.




Section 6 - Decor accessories

Decorative plinth




Straight Plinth application



Curved Plinth application

Profile options

NOTE: Only one profile design shown for installation in this leaflet



IMPORTANT NOTES:

Ensure packaging is disposed of in a safe environmentally friendly way

Decorative plinth should be 'dry fitted' first, before any glue/permanent fixing is carried out.

Cabinets should be fitted and levelled before installation of the plinth.

Plinth sections may require scribing to the contour of the floor.


Any cut edges should be sealed using a waterproof varnish to protect against moisture ingress - see sealant instructions for application.

The highest point of the plinth should be established first (Max height 180mm)
Ensure all dimensions are checked before cutting. Make sure tool blades are sharp.


When using fridge or freezer appliances behind the decorative plinth, a plinth vent should be used GIR0962.




Components supplied



Straight Plinth Section
3000mm x 180mm




Curved Plinth Section
332mm x 180mm



Plinth Rail
3000mm x 80.5mm



Curved Corner Post Plinth
180mm x 90mm



Support block fittings pack x2
(x6 fixing blocks & x18 screws per pack)
HKE0028




Chipboard Rail
3000mm x 55mm
(to be cut into sections for support blocks)

Plinth fixing principle


General application

Rail secured to the underside of the cabinets, with 'tongue' facing the front.



Dishwasher application


Rail reversed and positioned under adjoining rails to allow door opening clearance.



Sealing raw cut edges


Seal the cut edges of plinth rail using a waterproof varnish

Side View





Seal Plinth Groove

Ensure exposed plinth groove is sealed using a waterproof varnish



Side View





Section 6 - Decor accessories

Decorative plinth

Cutting the plinth


Follow the information below for the 'best practice' methods for cutting the plinth. **IMPORTANT:** Do not use unguided hand saws to mitre cut the plinth.



A SHARP BLADE MUST BE USED
BLADE MUST BE LARGE ENOUGH TO CUT IN ONE PASS
DO NOT CUT THROUGH THE PLINTH TOO QUICKLY TO AVOID VENEER BREAKOUT

Mitre cuts

Cut from behind at exactly 45° (veneer facing downwards)



Compound-angle Mitre saw recommended

Cutting along the length (for scribing)

Cut with the plinth facing upwards so the blade direction runs towards the material*




Table saw recommended

OPTION USE OF A 'SPOIL BOARD' WHEN MAKING CUTS TO REDUCE VENEER BREAKOUT

If scribing to an uneven floor, a jigsaw may be used with the correct blade to prevent breakout

*Ensure the bottom cut edge is sealed with a suitable sealant to prevent water ingress.

General installation




Please read through all the assembly stages before starting installation.
Before installation, ensure all cabinets are installed and level. Decor ends should be fitted flush with the base of the cabinets (unless 'down to the floor' application is being used).
NOTE: Decor ends should protrude the cabinet front by 20mm. Dry fit the components first before final installation.

1

Establish the highest point of your cabinets as your start point.

Highest point (max 180mm)




2





Please ensure all dimensions are checked before cutting panels

DECOR END ON TOP OF RAIL APPLICATION



DECOR END TO FLOOR APPLICATION
(can be used when appliances are at the end of a run)

Return plinth section secures directly to the decor end



Plinth Rail


3000mm x 80.5mm

Measure the width of the run and cut plinth rail (B) as required (45° mitre for return as required).

NOTE: If returning the plinth around the cabinets at each end, make sure the additional length is taken into account as shown below. If your decor end is coming down to the floor, the return rail does not need to be fitted.



The decor end can sit on top of the rail (flush with the bottom edge of the cabinet).


Alternative fixing shows the decor end running down to the floor. This would also be used when an appliance is being fitted at the end of a run.



Rail length

NOTE: Allow for decor end thickness at the side of the cabinet if returning the rail.







Section 6 - Decor accessories



Decorative plinth

Position the plinth (A) to the rail and mark for any scribing to the floor.
Cut the plinth as required, mitring the external & internal corners.



Remove the plinth & rail from the cabinet so they can be assembled for the final fit.



Cut the chipboard rail (C) into sections to form fixing blocks. Each section is 120mm in length.



Secure the plinth assembly together using silicone, aligning the groove in the plinth with the plinth rail (B). Fit fixing blocks as shown.

NOTE: Use silicone along the edge to protect.


Use clamps to hold the pieces together to ensure a firm bond.




Position the assembled plinth to the cabinets and secure in place using the screws.

NOTE: Use adhesive to join plinth on the mitred corners.


If your decor end is running to the floor, secure the plinth directly to the decor end.




For additional stability of the plinth on internal corners, wooden battens can be secured to the floor behind the plinth.



Removable sections (required in some appliance applications), should be cut in line with the door stile to give visual continuity. Screw into the adjoining cabinet each side to fix.






Section 6 - Decor accessories

Decorative plinth


Dishwasher application

Dishwasher applications require the rail to be positioned lower and reversed (flat edge towards the front). Secure to the adjoining rails each side.



When a dishwasher is being installed at the end of a run, the rail (B) should be secured to the end panel on the underside using a metal bracket.

Any cut/raw edges should be sealed using a waterproof varnish to protect against moisture ingress.



Curved plinth applications

The curved plinth (D) has been pre-assembled (plinth and rail).

Fit this to the corner of the cabinet and secure using screws.

NOTE: Plinth will require notching around the legs.

Measure for straight plinth return and fit as shown in this leaflet.





Care should be taken if scribing the curved plinth at the bottom.

Join plinth sections together using metal joining plates (HKC0020) as required.

When using the curved corner post plinth (E), use the metal joining plates (HKC0020) on the underside to secure to the adjoining plinth sections.

NOTE: If fitting the corner plinth section (E) with a curved decorative post, please see the QR code for a short installation video.




Plinth drawer application

Where a plinth drawer is being fitted, the section of rail needs to be reversed (flat edge towards the front) and positioned 3mm back from the front edge of the adjoining rails (once the plinth is fitted).

NOTE: This is to allow the 'push to open' functionality as required.

Notch the rail (B) around the legs.





Cut the plinth to the size of the cabinet, reducing the width by 2mm each side. Follow the kitchen installation manual for drawer front fixing details to fit the plinth to the front of the drawer box.


NOTE: Plinth may require scribing to the floor.



Plinth vent

Fit a decorative plinth vent, cutting into the plinth following the dimensions shown. **NOTE:** Plinth vents should be used where fridge/freezers are located.





Section 6 - Decor accessories

Fixing



In some installations the fitting of a decor end panel may be required. These will require cutting to size. Secure from the inside using countersunk screws.

NOTE: Fit the plinth, (if applicable, see **page 120**), before fitting decor end panel. Cornice fixing should be carried out after decor end panel is in place.

IMPORTANT: To reduce the risk of damage to cut panels due to moisture ingress (where they are exposed to moisture) all raw edges must be sealed using a suitable moisture resistant sealant, such as waterproof varnish or silicone.




NOTE: To finish the cabinet run at the top, a cut decor end can be used to create a thin cornice. Secure to the front of the cabinets using 25mm CSK screws.

NOTE: When using base and wall decor ends, pilot drill the decor end panel and secure to the side of the cabinet using 25mm CSK screws.

IMPORTANT NOTE:





When using a 12mm thick decor end, use 25mm screws.


For Handleless Profile System, see **Section 2**.



Carefully measure the pelmet and cut to the correct lengths. Only use 45° mitre joints at corners, if required. Fix with countersunk screws.


NOTE: If you are tiling the wall or fitting a full-height splashback then a gap should be left where the return pelmet meets the wall to accommodate the tile / splashback thickness.





Section 6 - Decor accessories





Fixing



Carefully measure the cornice and cut to the correct lengths. Only use 45° mitre joints at corners, if required.

Drill the cornice at suitable intervals, position the cornice on the top of the cabinet, (making sure the cornice lines up with doors, decor end panels etc). Screw into the cabinets using countersunk screws.


NOTE: If you are tiling the wall then a gap should be left where the return cornice meets the wall to accommodate the tile thickness.




25mm CSK screw

Alternative fixing method - Cornice screws


- 1 Position a small piece of cornice on top of the cabinet to determine the position of the fitting. Secure the fitting onto the cabinet using the screws provided. Gently tighten and check that the cornice is correctly positioned.



- 2 Position the fittings on all wall cabinets as required, see installation example below.




- 3 Once cabinets are secured to the wall, position the mitre bonded cornice sections and gently tighten all the fittings by hand, just enough to hold the cornice securely.




Installation example

We recommend one fitting is used above each door on a run of cabinets as shown below.


NOTE: All corners must be mitre bonded.





Section 6 - Decor accessories

Thick decor end post



Thick decor end post use examples

Important Notes:

Ensure packaging is disposed of in a safe environmentally friendly way

Note: Decor end post is supplied in one length and will require cutting. Ensure exposed cut ends are sealed to avoid any moisture ingress using a waterproof varnish or PVA.

Note: Pilot holes need to be drilled before fixing the screws.

Note: Edging strip must be used on exposed edges of the rails (shaker design).


Applications

Measure and cut the decor end post to the correct height.
Note: Use the installed base/wall/tower cabinet as a guide.

Cut the decor end panels to the correct size depending on your style application and secure together as shown in assembly A, B, C or D.


Note: When cutting multiple panels from a decor end, ensure panel efficiency is considered.

For application 'A', use the 'off-cuts' of decor end panels as blocks to secure/space the decor end from the cabinet.




Assembly A

Flat decor end style application (base shown)




Note: Quantity of KD blocks and screws dependent on the size of decor end being used.

Back Face



*nominal planning height.
Consideration must be taken for scribing to the floor as required




Section 6 - Decor accessories

Thick decor end post

Assembly B, C, D


For a framed decor end style application (base shown)






Note: Cross rails (top/bottom) can be secured to the decor end using screws or adhesive

Note: Drill through the decor end panel first before fitting the cross rails.

Cutting plan for options **B C**



Cutting plan for option **D**




Note: Make sure the pre finished edges of the cross rails face the inside of the panel

Decor end fitting

Fit the decor end to the side of the cabinet securing through the cabinet using screws.

Note: Decor end post/decor end may require scribing to the wall.




Section 7

Worktops and backboards



Worktop support bars - Application information (22mm Laminate worktops).....	page 132
Worktop planning recommendations (22mm Laminate worktops).....	page 133
Fixing	page 134
Cutting and fixing	page 135
Fitting sink unit.....	page 136
Undermount sink cradle.....	page 136
Fitting backboards.....	page 137

NOTE: This section covers laminate and timber worktops. For solid surface tops such as compact laminate and quartz, please see specific fitting instructions supplied with the product or contained in the Quartz installation manual available from your local depot.



Section 7 - Worktops and backboards

Worktop support bars - Application information


Metal support bars should be used over unsupported spans of worktops.

Follow the diagrams below for where support bars are required.


NOTE: Cut-outs for a sink or hob in the worktops must be supported by the cabinet front rail and/or support bar.

Support bars secure to the side panels each side.

Hi Line Base Cabinets





Drawer Line Base Cabinets



NOTE: For use on large drawer units where there is no centre upright or with a cut-out above

Appliance







Section 7 - Worktops and backboards




Worktop planning recommendations

When two appliances are to be positioned next to each other, decor end panels and support rails should be used for additional support. Where possible a unit should be positioned between the appliances for increased support of the worktop.

- The maximum unsupported overhang span of the worktop must never exceed 300mm
- The maximum unsupported span of the worktop must never exceed 600mm
- Cut-outs for hobs and sinks should never be closer than 60mm from the end edges of the worktop




Always try to finish a run with a supporting unit. Where a single panel is used, this will need to have the additional support of a wooden batten at the back and the metal support bar at the front. In addition to this the decor end panel should be secured to the wall using metal brackets.



The gap between the worktop and the hob should be as large as possible.

We recommend a gap of 5mm between the top of the oven and the bottom of the worktop.




Section 7 - Worktops and backboards

Fixing

IMPORTANT NOTE: Refer to the below information only for the installation of laminate worktops. If installing solid timber please refer to the separate cutting and installation instructions provided.

When routing laminate worktops, care should be taken not to burn the laminate. Always ensure the tooling is not blunt, and the wheel bearings are moving freely.



NOTE: Before fitting the worktop, drill through the part drilled holes in the front rail of the carcasses with a 5mm drill bit.

Granite/Quartz worktop fitting information is covered in a separate installation manual which can be picked up from your local depot.



Using a fine toothed saw, measure and cut the worktop to required size. If you are creating a mitre joint ensure that the male part of the worktop is correctly sized to accommodate the inset into the female part. Before cutting the worktop, stick a length of masking tape over the line and score the surface - this method helps prevent chipping. When a sawn edge is visible it may require planing smooth before applying pre-glued edge banding.

NOTE: We recommend your worktop depth for this style of kitchen is 600mm. If using worktops which are 616mm in depth, carefully cut down the worktop at the back making sure measurements allow for uneven walls/scribing.


When using granite worktops, the depth should be a minimum of 615mm so hobs and sinks have the appropriate spacing at the front and back.

IMPORTANT NOTE: See **Handleless Profile System - Section 2** for further details on batten and spacer fixing.


NOTE: When butting two tops together in an L shape configuration (not hockey stick joint), ensure the finished front edge is removed to take the adjoining end of the other worktop.



Right-hand female joint shown




Right-hand male joint shown



If the corners are being joined at 90° with a mitre joint, identify which ends of the worktops are to be 'male' and 'female'. Following the instructions provided with the worktop jig, use a router to create the necessary joints and joining bolt pockets. Illustrations show the creation of a right hand corner joint. Reverse worktop to create left hand corner joint.






For joining at angles other than 90° please refer to the instructions provided with the worktop jig.



Section 7 - Worktops and backboards

Cutting and fixing

Bolt slots, right-hand female shown




Worktop connector bolts

Once all cutting is complete, bring worktops into position and join together using worktop connector bolts. Apply worktop jointing compound to the mitre joint to create a virtually invisible joint, tighten the connecting bolts as required.



Laminate worktop joining

Run jointing compound along the top and bottom edge of the worktop as shown using the application tool.

Secure the worktop sections together with the jointing bolts, then use the application tool to remove any excess compound from the surface.






Jointing compound application video




Once the worktop is in correct position, secure it to the cabinets by using 40mm CSK screws, (35mm for 22mm worktops), through the pre-drilled holes in the front rails. Then use countersunk screws to secure the worktop to the rear of the carcass through the previously fitted worktop fixing brackets.

Finish any exposed cut edges by applying worktop edging.



40mm CSK screw
(35mm for 22mm worktops)




30mm CSK screw
(25mm for 22mm worktops)



Section 7 - Worktops and backboards

Fitting sink unit



We recommend that the sink is positioned in the worktop before the worktop is secured. Fit the sink to the worktop following the manufacturers instructions.

Use a suitable moisture resistant sealant, such as waterproof varnish or silicone to seal chipboard edges around sink and hob cut-outs.


Handleless Profile System only:

NOTE: When using worktop spacer rails near to wet areas, (ie. sinks), use a water proof varnish to protect the MDF spacer rails.

NOTE: When fitting a sink to your worktop, the cabinet front rail may need cutting at the front to accommodate the bowl.

For Handleless Profile System, see also **Section 2**.

Undermount sink cradle




Undermount sinks being fitted to solid surface worktops or compact laminate, may require a support cradle. This is for where sink clip fixings cannot be used or are not supplied.


Follow the information below for how to create a support cradle using a piece of MDF (or similar).

NOTE: In some applications, the cabinet side panels (top edges) can be rebated to support the sink.


- 1 Measure the cabinet internal aperture.




- 2 Cut MDF and secure to base.




- 3 Use the sink template and cut-out for the sink aperture.




- 4 Router a rebate around the top of the cut out suitable to hold the rim of the sink.




- 5 Use silicone in the rebate and fit the sink.




- 6 Silicone around the rim of the sink and fit the worktop.





Section 7 - Worktops and backboards







Fitting backboards






Cut backboard to required lengths and mitre external joints where appropriate. Apply a suitable adhesive to the rear and underside of each cut section of backboard, following adhesive manufacturers instructions. Fit and allow the adhesive to dry.

Use silicone sealant or the appropriate jointing compound to fill and seal all joints. Use appropriate sealing strip or edging strip to finish any exposed edges.

- Acrylic backboards do not require any special tools for installation.
 - The cutting and fitting of acrylic backboards is identical to a standard backboard.
 - Ensure the panel is supported while cutting
 - Cut with a table or plunge saw, making sure the blade is sharp
 - Socket cut outs can be done with a jigsaw
 - Lightly sand edges once cut, bevelling visible edges to provide a more decorative finish if required
 - Sealer strips are not required for acrylic backboards
 - Double sided tape or silicone can be used to secure backboards depending on the surface
 - If needing to join backboards, butt or mitre joints can be used.
- Important:** Take care when handling the backboards as cut edges of acrylic may be sharp.




Cut upstands to required length and mitre external joints where appropriate. Apply suitable adhesive to the rear and underside of each cut section of upstand, following adhesive manufacturer's instructions. Fit and allow to dry.




Section 8

Door fixing and finishing touches



Hinges


Fitting	page 140
Adjustment	page 140
Upgrade soft-close hinges	page 141
Soft-close de-activation switch	page 142
Magnetic catch - Push to open	page 143
Handle fixing	page 144
Finishing touches	page 144




Section 8 - Door fixings and finishing touches

Fitting


Step 1 - Fit hinge



Step 2 - Fit door





Step 3 - Tighten




Fit the door to the cabinet, aligning the plastic pegs on the hinge plate with the holes in the cabinet. Firmly push into place. Tighten screws on the hinge plate, expanding the pegs to secure.


Adjustment




Depth




Side



Height



Slimline hinge and plate



Section 8 - Door fixings and finishing touches

Upgrade soft-close hinges


Hinge assembly

Fit hinge arms to doors and plates to cabinets using the screws supplied.

95°/110° Hinge - Standard

Integrated soft-close hinge.


NOTE: 95° Hinge used on Integrated Handle ranges.




NOTE: Appliance hinges have a different fixing hole location and doors may require re-spiking to those holes pre-spiked on the back of the door.

170° Hinge - Standard

Soft close damper.




Installation and adjustment



Attachment


Locate at the front and push down at the back, clipping into place.



Removal

Push the clip at the back.

Damper installation




Similar installation for all dampers.

NOTE: Door adjustment should be carried out before this stage.


Attachment

1. Push forward and down at the front.
2. Push down on the back.



Removal

1. Push forward and pull up simultaneously.



Section 8 - Door fixings and finishing touches


Soft-close de-activation switch

NOTE: Some doors may not require two activated soft-close hinges due to their size and weight. If the door is not closing correctly, please de-activate one of the soft closing switches on one of the hinges to improve the soft close action.
Below is a simple guide on where the de-activation switch should be active.


One soft close hinge activated (recommended).



200*




300**



Soft-close activation/
de-activation switch.


Two soft-close hinges activated (recommended).




300




400



450



500




600

*Where applicable.

**On Greenwich ranges only.

The information above is applicable to all standard height, full-height, extra tall and hob wall doors.

NOTE: This information is not applicable to half-height doors and integrated microwave wall units.



Section 8 - Door fixings and finishing touches


Magnetic catch - Push to open

IMPORTANT: When fitting push to open, the hinges and hinge plates supplied with the cabinet will need to be replaced with the **110° unsprung hinges and hinge plates** supplied as part of the magnetic catch pack. These should be fitted to the cabinet in the positions of the existing hinges and hinge plates. **170° unsprung hinges are also available for corner cabinet applications as part of pack HYH8436.**


Adapter plate

- 1 Fit the adapter plate to the hinge plate positions on the opposite side of the hinged door. Use euro screws to secure.


NOTE: If your cabinet does not have hinge plate holes drilled, pilot drill and use two 13mm CSK screws. Adapter should be fitted flush with the front edge of the cabinet and 70mm up from the bottom of the side panel.




- 2 Fit the piston to the adapter plate pushing into place.



- 3 Use the adhesive magnet or screw on magnet, positioning to the back of the door in line with the piston.




- 4 Adjust the position of the piston by turning the end.





631/931 cabinet application

When using the push to open on a 631/931 cabinet application, the piston should be fitted into the bottom shelf front edge, 160mm in from the cabinet side. This is to avoid any clash with the adjoining door.




Side panel edge application


- 1 Carefully drill the front edge of the cabinet. **NOTE:** Drill hole should be a diameter of 10mm x 76mm in depth.
- 2 Fit the piston into the hole. Fit the magnet to the door as shown above.



For wall cabinets with a centre post, place the piston into the front edge of the base panel as shown.

Curved cabinet edge application







Section 8 - Door fixings and finishing touches

Handle fixing

Application examples



Handle fixing

Follow the diagrams to ensure the handle positions are aligned throughout the range and are positioned correctly.

We recommend you fit the frontals to the cabinets before you start marking and drilling handle positions.

NOTE: Always check the drilling centres before any holes are drilled.

IMPORTANT: Be aware of handle clash situations in corner configurations.




1. Measure the handle position on the frontal.

NOTE: When marking drawer fronts make sure holes are 5mm above the centre line of the drawer as shown in the application example.


2. Ensure all spike positions are parallel.

3. Drill the frontal.


4. Secure the handle using the screws provided.




Finishing touches




Hinge hole cover cap




Screw cover cap



5mm Cover cap



Bumpers (x2)



Self-adhesive cover cap


Section 9

Level H contract kitchens




Larder and base cabinet	page 146
Wall cabinet	page 147
Hob wall cabinet	page 148

NOTE: Additional parts required to be fitted to the cabinets to meet the Level H standard.




Section 9 - Level H contract kitchens

Larder and base cabinet



Larder cabinet



Base cabinet **RKC0170**

NOTE: Only with the addition of the back rail, will the larder cabinet be suitable for Level H use.

Assembly

Larder cabinet







Illustration is shown with back panel removed.

- 1** Larder bracket x4
13mm Flange head screw x8





- 2** 13mm Flange head screw x4



Position the rail to the back of the larder cabinet. Make sure the rail is level before securing.

Base cabinet



- 1** 16mm Flange head screw x2
45mm or 50mm CSK screw x2



Place the new support rail 'A' to the back of your unit in the centre. Use a tape measure to ensure the correct location. Once in place use the 45mm or 50mm CSK screws to secure to the base panel and the 16mm flange head screws to secure to the top.

NOTE: Make sure the rail is in the correct position before securing.


- 2** 25mm CSK screw x6
KD block x2




Fit the shelf to your chosen height position.

Once in place position the KD blocks to the underside of the front and back of the shelf ensuring they are in the centre. Secure the KD blocks to the underside of the shelf, front and back, using the 25mm CSK screw x6.

NOTE: Make sure KD blocks are in the centre so the back one secures to the back rail.







Section 9 - Level H contract kitchens

Wall cabinet

RKC0180



Full height wall (720mm)
Width - 800/900/1000mm



Extra tall wall (900mm)
Width - 800/900/1000mm



Assembly

1



720 FH only.

800/900/1000mm Cabinets.





If fitted, carefully remove the back rail.

2




720 FH only.

45mm KD screw x4





Make sure the rail is flush with top and bottom edge.

3




720 FH and
900 Extra tall
units.





Drill through the 2 holes using a 5mm drill bit. These are wall fixing holes. Secure the cabinet to the wall, see **page 110**.

4




900 Extra tall
units.

KD block x2/x3
screw x6/x9




Place the shelves at your preferred height. Position the KD blocks centrally so they secure to the support rail.



Section 9 - Level H contract kitchens

Hob wall cabinet








RKC0172



NOTE: Only with the addition of the replacement hinges, will the hob wall cabinet be suitable for contract use.


Assembly

This cabinet must be fixed into position prior to door fixing.
Refer to cabinet wall fixing, see **page 110**.




Section 10


Integrated handle design



Corner base cabinet fillet fixing	page 150
Jointing plates	page 151
Pull-out larder bracket	page 152
Appliance door application.....	page 153
Curved base decor end and door fixing	page 157




Corner base cabinet fillet fixing




Assembly




- 1** Fit two fixing blocks each side of the fillet top and bottom.




- 2** Position the fillet to the cabinet centre upright and secure.



- 3** Adjoining cabinet fixing position.






Jointing plates


This leaflet shows jointing plate applications and fitting information.

Fitting


Slab and shaker style door applications.




Integrated handle style door applications.




Applications




Small jointing plate applications.
(Typically used on slab and shaker style)
HKC0061




Large jointing plate applications.
(Typically used on integrated handle style)
HKC0062




Dummy Drawer-Line



Dummy Drawer-Line Corner




High Line Corner Base*




High Line Corner Wall*




Larder Doors




Half Height
Hinge holes will need to be drilled in this application.




Dummy Drawer-Line



Dummy Drawer-Line Corner




Larder/Tower Doors



Pull-Out Larder Doors

*Also applies to integrated handle style doors.

NOTE: Some pull-out larder accessories require accessory plates supplied with the product.






Pull out larder bracket

Assembly

Position the bracket and jointing plates to the back of the frontals following the dimensions shown. These dimensions replace the ones shown on the leaflet supplied with the pull-out larder units for bracket fixing, when used with the integrated handle range.

Chamfered and J trim door design






Appliance door application

IMPORTANT NOTICE

The following pages cover the appliance listed below:




LAM8607 - Lamona deluxe fully integrated dishwasher.

Integrated dishwasher and fridge door fixing locations differ between appliance models. Please use the following pages which show door fixing variations. In addition to this, refer to the installation booklet provided with the appliance for more detailed information and specific fixing requirements.

NOTE: Appliance code numbers may be shown for some models.

IMPORTANT NOTICE:

Please ensure care is taken with fixing locations when fitting an integrated handle door to an appliance. Under no circumstances should screws be used towards the top of the door for fixing, as this will damage the integrated handle section of the door as illustrated below.



Dishwasher using Howdens pre-drilled frontols.


The dishwasher door fixing positions to the frontal may clash with the frontal pre-drilled hinge holes.

If this clash does occur and no other fixing positions are available, carefully fit the insert provided to one of the holes, securing with suitable adhesive.


Gently tap the insert into the hole until it sits flush with the surface of the door.


NOTE: Care must be taken not to damage the surface of the door whilst fitting the insert. We recommend the door is laid flat on the surface, with the front face protected with packaging.

The insert may need a pilot hole for the dishwasher bracket fixing screw due to thread type.



NOTE: When fitting a door to a dishwasher where a handle is fitted, ensure the handle screw is countersunk.







Appliance door application

Lamona - LAM8607


Door brackets should be located as per the instruction booklet supplied with the appliance.
Use the screw fixing locations (shown below) in replacement for the ones shown in the instruction booklet.

Standard decor door






Remove the screws located in the 3rd and 6th hole positions from the top edge. Carefully drill through the holes using a 3.5mm bit.




Remove the screws located in the 3rd and 6th hole positions from the top edge. Carefully drill through the holes using a 3.5mm bit.



Back of the dishwasher door illustrated.






Appliance door application

Lamona - Alternative door configurations.


Door brackets should be located as per the instruction booklet supplied with the appliance.
Use the screw fixing locations (shown below) in replacement for the ones shown in the instruction booklet.


Decor drawer frontals



Standard decor door

Back of the dishwasher door illustrated.






Section 10 - Integrated handle design

Appliance door application

NOTE: For all dishwasher applications, care must be taken when fixing the frontal to the appliance. Use the template supplied with the dishwasher for door fixing.


IMPORTANT: Use the DRAWER LINE upper fixing positions. Using the hi-line fixing as shown on the template will damage the integrated handle section (see below).



Lamona - Integrated fridge or freezer applications.


This information replaces the top bracket fixing information shown within the appliance booklets.

Follow the appliance booklets for all other aspects of installation.




Fix the top brackets to the door in the positions shown below. Once in place, fit the door to the appliance and secure using the screws provided.

NOTE: Make sure the bracket is positioned the correct way up. When fitting the door to the appliance, additional washers can be used between the screw head and the bracket to secure.




NOTE: Additional height adjustment for door alignment can be achieved by adjusting the appliance feet.



Section 10 - Integrated handle design

Curved base decor end and door fixing




Assembly

For fixing the legs to the cabinet, see **page 20-21**.



1

Fit battens (supplied with cabinet) to the decor panel.




2

Fit the hinge and plate to the door and decor panel.
Curved base hinge pack required.




3

With the base cabinet laid flat, secure the decor panel and door using screws through the base and top shelf and into the battens.



Section 11

Appliance tower configurations




Cabinet information

How the cabinet is supplied	page 160
Hints and tips for installation.....	page 161
Cabinet modifications - Back panel + additional shelf pack.....	page 162
Standard drawer box - Appliance tower applications.....	page 163
Cabinet modifications - Fitting a top box	page 164
Hints and tips for installation.....	page 165




Double oven

Double oven (including, with warming drawer)	page 166
Double oven with additional appliances and drawer	page 170




Single oven

Single oven	page 172
Single oven with additional appliances and drawer	page 176
Single oven with warming drawer and additional microwave	page 178




Microwaves/compact oven

Microwave/compact oven	page 184
Microwave/compact oven with additional appliances	page 187
Microwave/compact oven with warming drawer	page 189
38cm Microwave - Lamona	page 191
38cm Microwave with 115mm fascia - Lamona	page 192
38cm Microwave and double oven - Lamona.....	page 193
38cm Microwave and single oven - Lamona.....	page 194
38cm Microwave and warming drawer - Lamona.....	page 195
Compact oven and two drawer application	page 196



Tower fridge or freezer options

50/50 Tower fridge/freezer (one appliance) options.....	page 197
70/30 Tower fridge/freezer (one appliance) options.....	page 199
Full height larder fridge/freezer options	page 202




Larder tower options

Larder tower options.....	page 205
---------------------------	----------

Half height frontals

Half height frontals	page 208
----------------------------	----------


NOTE: This section shows the cabinet configurations for appliances. However, please always follow the manual supplied with the appliance for fixing details for the appliance into the cabinet. Different appliances will have different fixing methods and fittings.



Section 11 - Appliance tower configurations




How the cabinet is supplied

The appliance tower will be supplied in one of the configurations shown below depending on the appliance chosen. Adjust the shelves and back panels as required following the following pages.




Standard appliance tower

NOTE: In tall applications, the dimensions shown for cutting the back panel will need to increase by 180mm



Fridge/Freezer tower

NOTE: We recommend that the shelf panel is left in place until the cabinet is level and secured to the wall.





Section 11 - Appliance tower configurations

Hints and tips for installation

The information below relates to the appliance tower installation and modification. Please read the information below before starting the cabinet build.

P If you are installing appliance towers in a run ensure a **30mm gap is left between them for profile fixing.**

IMPORTANT: All dimensions shown for the shelf configurations are measured to the centre of the fixing hole.

Shelves

All load bearing shelves must have KD blocks fitted underneath for extra strength and stability. Secure with 25mm screws.

NOTE: If the appliance being fitted clashes with the KD blocks, use metal ladder brackets as a replacement.

Shelf Brackets

Mid shelves in configurations may be replaced with steel brackets **LAM0012** depending on appliances fitted.

Plinth vents

If using the appliance tower in a fridge or freezer application, the plinth should be fitted with a vent.

Filler rails (part of supplied cabinet)

Cabinet filler rails may require scribing/removing, depending on the appliance fitted. Remove the panel from the shelf to scribe.

Fascia rails (frontal)

Fascia rails may require scribing depending on the appliance fitted.

Appliance sizes

Due to variations in appliance sizes, packing may be required under the appliance to achieve a slightly raised level. Use 'cut off's' from your back panel for this purpose. Screws are provided to secure in place.

Dishwashers and washing machines are not suitable for use within appliance towers.


Leg fixing

Follow the kitchen installation manual section for leg fixing information.

Wall fixing

The appliance tower **MUST** be secured to the wall for extra stability using ladder brackets and screws (supplied in the fittings pack). Wall fixing screws have not been provided with this unit due to different wall types requiring different fixings.

NOTE: Where applicable, secure the tower through the back support panel.



Hinge fixing and adjustment

Follow the kitchen installation manual for all hinge and hinge plate fixing.


Drawer box assembly and installation (where applicable)

Follow the drawer box section for all assembly and installation information.


Fridge door fixing

For kitchen frontals with a centre panel, the bracket fixing will need to be secured only at the end nearest the door edge. Place an additional screw in the third hole along from the front to secure.

Shelf bracket



NOTE: Bracket **LAM0012** can be used as an alternative for the central shelf if required.





Section 11 - Appliance tower configurations


Cabinet modification - Back panel + additional shelf

Appliance towers supplied with a back panel will require the back panel to be modified or removed completely. This is due to the different appliance configurations.


NOTE: As a general rule, the back panel is only required behind a cupboard.
The appliance aperture must not be enclosed due to ventilation.

Remove the staples and slide the back panel from the unit.


Cut panel to the appropriate sizes (see individual tower configuration pages for back panel sizes) and re-fit using the panel pins to secure to the back of the shelf panels.



Double oven example



NOTE: Do not discard any of the cut back panel at this stage. Parts of the back panel may be required for packing under your appliance due to size variations.



Fixing: Secure the shelf into the appliance tower using the VB cams and studs where applicable. Filler rails are secured to the shelf using 45mm screws.

NOTE: If using a tall tower (no top box), the upper back panel size will need to be measured.




Section 11 - Appliance tower configurations

Standard drawer box - Appliance tower applications




NOTE: Only runner fixing holes shown on the panels for extra clarity.

Runner fixing positions


1 Drawer




2 Drawer






3 Drawer




4 Drawer



Drawer front fixing positions







Section 11 - Appliance tower configurations

Cabinet modification - Fitting a top box



Tall towers (one cabinet) can be used in larger tower applications. If using a 180mm top box to make a standard tower tall, please follow the information below for securing the top box to the cabinet.



Standard height
tower **1942mm**



Extra tall height
tower **2122mm**
(includes **180mm**
top box)

1




x3 2.5mm Hole

2



30mm Screw x3



Section 11 - Appliance tower configurations




Hints and tips for installation

If electric or gas appliances are to be built into the cabinets, please ensure you read the appliance tower section and comply with the appliance dimensional requirements before fitting.

Finally fit appliance(s) and make the necessary supply connections. All connections should be made by a qualified person.

If you have a handleless profile kitchen, you will need to drill through the profile to secure the appliance. Infill rails are provided for this application, please see the handleless installation manual.

NOTE: When fitting an appliance between two cabinets, we recommend a rail, (drawer support rail be used), is positioned at the back aligned with the top of the cabinets to ensure the appliance when fitted is stable.




Double ovens fitting between two cabinets.

If more room is required above the appliance to accommodate some Hob/ thin worktop applications, drop the appliance down and use a 45mm fascia rail above to fill the gap. Please note: Plinth will need to be reduced in height for this application and the bottom of the appliance will not align with adjoining frontals.

NOTE: For a lowered built under double oven, secure decor ends to the sides of the cabinets and reduce the height of the plinth. Secure fascia to decor ends using fixing blocks.


NOTE: A 5mm ventilation gap should be left between the oven and fascia.



Standard application

Lowered application
(for some hobs/thin worktops)

*Oven can also be secure to the side panels of the cabinets if decor ends are not possible.




Section 11 - Appliance tower configurations

Double oven


The information below shows the cabinet configurations that can be achieved when installing a double oven. Each overview page is followed by the shelf configurations applicable to the appliance shown.

Standard options

45mm Fascia rails required where indicated




67mm Fascia rails required where indicated




Extra tall options

45mm Fascia rails required where indicated




67mm Fascia rails required where indicated



Fascia rails (frontal): Fascia rails may require scribing depending on the appliance fitted.

* Range dependant.



Section 11 - Appliance tower configurations

Following the information on this page for positioning shelves and back panels.
The dimensions for the shelf positions are to the hole centre.


Double oven


See cabinet modification page 162 for adapting the back panel to suit your tower configuration.

NOTE: Fascia rails may require scribing depending on the appliance fitted.

Shelf configurations are identical for standard height and tall options.

If not using a tall tower cabinet, a 180mm top box should be fitted to the tower to achieve a tall application (Upper door hinge moves into the top box for door fixing).





Section 11 - Appliance tower configurations

Following the information on this page for positioning shelves and runners.
The dimensions for the shelf positions are to the hole centre.

Double oven with warming drawer


See cabinet modification page 162 for adapting the back panel to suit your tower configuration.


NOTE: Fascia rails may require scribing depending on the appliance fitted.

Shelf configurations are identical for standard height and tall options.

If not using a tall tower cabinet, a 180mm top box should be fitted to the tower to achieve a tall application (Upper door hinge moves into the top box for door fixing).

1a





Section 11 - Appliance tower configurations


Following the information on this page for positioning shelves and back panels.
The dimensions for the shelf positions are to the hole centre.


Double oven - Lower fitting

See cabinet modification page 162 for adapting the back panel to suit your tower configuration.

NOTE: Fascia rails may require scribing depending on the appliance fitted.
If not using a tall tower cabinet, a 180mm top box should be fitted to the tower to achieve a tall application (Upper door hinge moves into the top box for door fixing).

1b





Section 11 - Appliance tower configurations

Double oven - With additional appliances and drawer

The information below shows the cabinet configurations that can be achieved when installing a double oven. Each overview page is followed by the shelf configurations applicable to the appliance shown.

Standard options


67mm Fascia rails required where indicated

Double oven
with microwave
(and 1 drawer)



2

Double oven
with compact oven
(and 1 drawer)



2

Extra tall options


67mm Fascia rails required where indicated

Double oven
with microwave
(and 1 drawer)



2


Double oven
with compact oven
(and 1 drawer)



2

Note: This configuration also applies to steam ovens and coffee makers (non LAMONA appliances).

Fascia rails (frontal): Fascia rails may require scribing depending on the appliance fitted.



Section 11 - Appliance tower configurations

Following the information on this page for positioning shelves and back panels.
The dimensions for the shelf positions are to the hole centre.

Double oven with additional appliance and drawer



See cabinet modification page 162 for adapting the back panel to suit your tower configuration.

NOTE: Fascia rails may require scribing depending on the appliance fitted.


Shelf configurations are identical for standard height and tall options.

If not using a tall tower cabinet, a 180mm top box should be fitted to the tower to achieve a tall application (Upper door hinge moves into the top box for door fixing).

2



****NOTE:** When a drawer box is being fitted, use the metal brackets (shown left), as replacement for the KD blocks.




Section 11 - Appliance tower configurations

Single oven

The information below shows the cabinet configurations that can be achieved when installing a single oven. Each overview page is followed by the shelf configurations applicable to the appliance shown.




Standard options

67mm Fascia rails required where indicated



Extra tall options


67mm Fascia rails required where indicated



Fascia rails (frontal): Fascia rails may require scribing depending on the appliance fitted.

*Range dependant.

**Only available as a drawer option.



Section 11 - Appliance tower configurations

Following the information on this page for positioning shelves and back panels.
The dimensions for the shelf positions are to the hole centre.


Single oven

See cabinet modification page 162 for adapting the back panel to suit your tower configuration.


NOTE: Fascia rails may require scribing depending on the appliance fitted.

Shelf configurations are identical for standard height and tall options.

If not using a tall tower cabinet, a 180mm top box should be fitted to the tower to achieve a tall application (Upper door hinge moves into the top box for door fixing).



***NOTE:** Where fascia rails are not been used re-drill side panel for new shelf position to conceal the gap, top of appliance.



Section 11 - Appliance tower configurations

Following the information on this page for positioning shelves and back panels.
The dimensions for the shelf positions are to the hole centre.

Single oven (drawer option)

See cabinet modification page 162 for adapting the back panel to suit your tower configuration.

NOTE: Fascia rails may require scribing depending on the appliance fitted.


Shelf configurations are identical for standard height and tall options.

If not using a tall tower cabinet, a 180mm top box should be fitted to the tower to achieve a tall application (Upper door hinge moves into the top box for door fixing).

3a

*Bottom shelf fixing holes for larder application will require drilling at 711mm (KD blocks not required in larder application).


Spike the holes for the runner fixings using the dimensions shown in the diagram.




3b

*Bottom shelf fixing holes for larder application will require drilling at 720mm (KD blocks not required in larder application).

Spike the holes for the runner fixings using the dimensions shown in the diagram.





Section 11 - Appliance tower configurations

Following the information on this page for positioning shelves and back panels.
The dimensions for the shelf positions are to the hole centre.


Single oven x 2


See cabinet modification page 162 for adapting the back panel to suit your tower configuration.

NOTE: Fascia rails may require scribing depending on the appliance fitted.

Shelf configurations are identical for standard height and tall options.

If not using a tall tower cabinet, a 180mm top box should be fitted to the tower to achieve a tall application (Upper door hinge moves into the top box for door fixing).







Section 11 - Appliance tower configurations

Single oven - With additional appliances and drawer

The information below shows the cabinet configurations that can be achieved when installing a single oven. Each overview page is followed by the shelf configurations applicable to the appliance shown.


Standard options

45mm Fascia rails required where indicated




Extra tall options

45mm Fascia rails required where indicated



NOTE: This configuration also applies to steam ovens and coffee makers (non LAMONA appliances).
Fascia rails (frontal): Fascia rails may require scribing depending on the appliance fitted.
*Range dependant.



Section 11 - Appliance tower configurations

Following the information on this page for positioning shelves and back panels.
The dimensions for the shelf positions are to the hole centre.


Single oven with additional appliances and drawer


See cabinet modification page 162 for adapting the back panel to suit your tower configuration.

NOTE: Fascia rails may require scribing depending on the appliance fitted.

Shelf configurations are identical for standard height and tall options.

If not using a tall tower cabinet, a 180mm top box should be fitted to the tower to achieve a tall application (Upper door hinge moves into the top box for door fixing).






Section 11 - Appliance tower configurations

Single oven - With warming drawer and additional microwave


The information below shows the cabinet configurations that can be achieved when installing a single oven. Each overview page is followed by the shelf configurations applicable to the appliance shown.

Standard options


45mm Fascia rails required where indicated




6



7a




7a




7a

Extra tall options


45mm Fascia rails required where indicated




7



7a




7a



7a

Fascia rails (frontal): Fascia rails may require scribing depending on the appliance fitted.



Section 11 - Appliance tower configurations

Following the information on this page for positioning shelves and back panels.
The dimensions for the shelf positions are to the hole centre.


Single oven with warming drawer


See cabinet modification page 162 for adapting the back panel to suit your tower configuration.

NOTE: Fascia rails may require scribing depending on the appliance fitted.

If not using a tall tower cabinet, a 180mm top box should be fitted to the tower to achieve a tall application (Upper door hinge moves into the top box for door fixing).

6





Section 11 - Appliance tower configurations

Following the information on this page for positioning shelves and back panels.
The dimensions for the shelf positions are to the hole centre.


Single oven with warming drawer (extra tall)


See cabinet modification page 162 for adapting the back panel to suit your tower configuration.

NOTE: Fascia rails may require scribing depending on the appliance fitted.

If not using a tall tower cabinet, a 180mm top box should be fitted to the tower to achieve a tall application (Upper door hinge moves into the top box for door fixing).

7





Section 11 - Appliance tower configurations

Following the information on this page for positioning shelves and back panels.
The dimensions for the shelf positions are to the hole centre.


Single oven with warming drawer and microwave (layout 1)


See cabinet modification page 162 for adapting the back panel to suit your tower configuration.

NOTE: Fascia rails may require scribing depending on the appliance fitted.

Shelf configurations are identical for standard height and tall options.

If not using a tall tower cabinet, a 180mm top box should be fitted to the tower to achieve a tall application (Upper door hinge moves into the top box for door fixing).





Section 11 - Appliance tower configurations

Following the information on this page for positioning the shelves and runners.
The dimensions for the shelf positions are to the hole centre.


Single oven with warming drawer and microwave (layout 2)


See cabinet modification page 162 for adapting the back panel to suit your tower configuration.

NOTE: Fascia rails may require scribing depending on the appliance fitted.

Shelf configurations are identical for standard height and tall options.

If not using a tall tower cabinet, a 180mm top box should be fitted to the tower to achieve a tall application (Upper door hinge moves into the top box for door fixing).





Section 11 - Appliance tower configurations

Following the information on this page for positioning shelves and back panels.
The dimensions for the shelf positions are to the hole centre.


Single oven with warming drawer and microwave (layout 3)

See cabinet modification page 162 for adapting the back panel to suit your tower configuration.

NOTE: Fascia rails may require scribing depending on the appliance fitted.

Shelf configurations are identical for standard height and tall options.

If not using a tall tower cabinet, a 180mm top box should be fitted to the tower to achieve a tall application (Upper door hinge moves into the top box for door fixing).






Microwave/Compact oven

The information below shows the cabinet configurations that can be achieved when installing a microwave/compact oven. Each overview page is followed by the shelf configurations applicable to the appliance shown.


Standard options

45mm Fascia rails required where indicated



Extra tall options

45mm Fascia rails required where indicated



NOTE: This configuration also applies to steam ovens and coffee makers (non LAMONA appliances).
Fascia rails (frontal): Fascia rails may require scribing depending on the appliance fitted.



Section 11 - Appliance tower configurations

Following the information on this page for positioning shelves and back panels.

The dimensions for the shelf positions are to the hole centre.

Microwave/Compact oven


See cabinet modification page 162 for adapting the back panel to suit your tower configuration.

NOTE: Fascia rails may require scribing depending on the appliance fitted.

Shelf configurations are identical for standard height and tall options.

If not using a tall tower cabinet, a 180mm top box should be fitted to the tower to achieve a tall application (Upper door hinge moves into the top box for door fixing).

8





Section 11 - Appliance tower configurations

Following the information on this page for positioning shelves and runners
The dimensions for the shelf positions are to the hole centre.

Microwave/Compact oven (drawer options)

See cabinet modification page 162 for adapting the back panel to suit your tower configuration.

NOTE: Fascia rails may require scribing depending on the appliance fitted.


Shelf configurations are identical for standard height and tall options.

If not using a tall tower cabinet, a 180mm top box should be fitted to the tower to achieve a tall application (Upper door hinge moves into the top box for door fixing).

8a

*Bottom shelf fixing holes for larder application will require drilling at 720mm (KD blocks not required in larder application).


Spike the holes for the runner fixings using the dimensions shown in the diagram.



8b

*Bottom shelf fixing holes for larder application will require drilling at 720mm (KD blocks not required in larder application).

Spike the holes for the runner fixings using the dimensions shown in the diagram.





Section 11 - Appliance tower configurations


Microwave/Compact oven - With additional appliances

The information below shows the cabinet configurations that can be achieved when installing a microwave/compact oven. Each overview page is followed by the shelf configurations applicable to the appliance shown.

Standard options

45mm Fascia rails required where indicated

Microwave with compact oven




9

Extra tall options

45mm Fascia rails required where indicated

Microwave with compact oven



9

NOTE: This configuration also applies to steam ovens and coffee makers (non LAMONA appliances).
Fascia rails (frontal): Fascia rails may require scribing depending on the appliance fitted.



Section 11 - Appliance tower configurations

Following the information on this page for positioning shelves and back panels.
The dimensions for the shelf positions are to the hole centre.

Microwave/Compact oven with additional appliances


See cabinet modification page 162 for adapting the back panel to suit your tower configuration.

NOTE: Fascia rails may require scribing depending on the appliance fitted.

Shelf configurations are identical for standard height and tall options.

If not using a tall tower cabinet, a 180mm top box should be fitted to the tower to achieve a tall application (Upper door hinge moves into the top box for door fixing).

9





Section 11 - Appliance tower configurations

Microwave/Compact oven - With warming drawer

The information below shows the cabinet configurations that can be achieved when installing a microwave/compact oven. Each overview page is followed by the shelf configurations applicable to the appliance shown.

Standard options

Microwave/Compact Oven
with warming drawer



11

Extra tall options


67mm Fascia rails required where indicated

Microwave/Compact Oven
with warming drawer



11

Fascia rails (frontal): Fascia rails may require scribing depending on the appliance fitted.



Section 11 - Appliance tower configurations

Following the information on this page for positioning shelves and back panels.
The dimensions for the shelf positions are to the hole centre.

Microwave/Compact oven with warming drawer

See cabinet modification page 162 for adapting the back panel to suit your tower configuration.

NOTE: Fascia rails may require scribing depending on the appliance fitted.

Shelf configurations are identical for standard height and tall options.

If not using a tall tower cabinet, a 180mm top box should be fitted to the tower to achieve a tall application (Upper door hinge moves into the top box for door fixing).

11

Top back panel
(behind cupboard)
height **565mm**

Back support
panel

Bottom back panel
(behind cupboard)
height **722mm**


1386mm
(top shelf)

711mm
(bottom
shelf)



38cm Microwave - LAMONA


Models:
38cm Microwave



NOTE: For integrated handle doors, use Push to Open pistons or replace the door with a 945mm door and 45mm fascia.

See cabinet modification page 162 for adapting the back panel to suit your tower configuration.
NOTE: Fascia rails may require scribing depending on the appliance fitted.
Shelf configurations are identical for standard height and tall options.
If not using a tall tower cabinet, a 180mm top box should be fitted to the tower to achieve a tall application (Upper door hinge moves into the top box for door fixing).

IMPORTANT:
Dimensions for the shelf positions are to the centre of the stud fixing hole
Re-positioning/drilling of new shelf stud positions may be required






38cm Microwave with 115mm fascia - LAMONA

Models:
38cm Microwave
(with 115mm fascia)

See cabinet modification page 162 for adapting the back panel to suit your tower configuration.

NOTE: Fascia rails may require scribing depending on the appliance fitted.
Shelf configurations are identical for standard height and tall options.
If not using a tall tower cabinet, a 180mm top box should be fitted to the tower to achieve a tall application (Upper door hinge moves into the top box for door fixing).

IMPORTANT:
Dimensions for the shelf positions are to the centre of the stud fixing hole
Re-positioning/drilling of new shelf stud positions may be required






Section 11 - Appliance tower configurations

38cm Microwave and double oven - LAMONA

Models:

38cm Microwave
Double oven




570mm Door
(Tall Option)

Note: Bottom hinge position will need to be drilled in cabinet side for this application.

390mm Door

115mm Fascia

Note: Microwave may need to sit on an additional 18mm shelf as in some applications the microwave fascia sits lower than the main body of the appliance.



NOTE: Bracket LAM0012 can be used as an alternative for the central shelf if required.

1554mm

1033mm

Filler rail may require trimming

MICROWAVE


OVEN

378mm

122mm

138mm

Runner Fixing



See cabinet modification page 162 for adapting the back panel to suit your tower configuration.

NOTE: Fascia rails may require scribing depending on the appliance fitted.

Shelf configurations are identical for standard height and tall options. If not using a tall tower cabinet, a 180mm top box should be fitted to the tower to achieve a tall application (Upper door hinge moves into the top box for door fixing).

IMPORTANT: Dimensions for the shelf positions are to the centre of the stud fixing hole. Re-positioning/drilling of new shelf stud positions may be required. Microwave requires brace for anti-tilt

Top box for tall application

Top back panel (behind cupboard) height **397mm**

Back support panel

Use metal ladder brackets for additional shelf support

Bottom back panel (behind cupboard) height **147mm**

5mm bit


*Bottom shelf fixing positions require drilling (5x12mm hole). Additional shelf support with fixing blocks or metal brackets is recommended.



38cm Microwave and single oven - LAMONA

Models:

38cm Microwave
Single oven




See cabinet modification page 162 for adapting the back panel to suit your tower configuration.

NOTE: Fascia rails may require scribing depending on the appliance fitted.

Shelf configurations are identical for standard height and tall options.
If not using a tall tower cabinet, a 180mm top box should be fitted to the tower to achieve a tall application (Upper door hinge moves into the top box for door fixing).

IMPORTANT:

Dimensions for the shelf positions are to the centre of the stud fixing hole
Re-positioning/drilling of new shelf stud positions may be required





Section 11 - Appliance tower configurations

38cm Microwave and warming drawer - LAMONA

Models:

38cm Microwave
Warming drawer


See cabinet modification page 162 for adapting the back panel to suit your tower configuration.


NOTE: Fascia rails may require scribing depending on the appliance fitted.

Shelf configurations are identical for standard height and tall options.

If not using a tall tower cabinet, a 180mm top box should be fitted to the tower to achieve a tall application (Upper door hinge moves into the top box for door fixing).


IMPORTANT: Dimensions for the shelf positions are to the centre of the stud fixing hole. Re-positioning/drilling of new shelf stud positions may be required. Microwave requires brace for anti-tilt





Section 11 - Appliance tower configurations



Compact oven and two drawer application




- Components required:**
- RKC8/1705 - BUOH cabinet
 - HYH2960 - 600 Drawer box x2
 - 600 BUOH fascia x1 (115mm) - Range specific
 - Appliance tower fascia x1 (141mm) - Range specific
 - RKC8/1820 - Appliance tower mid shelf pack x1
 - KD Fixing blocks and screws x4
 - RKM1820 - BUOH foot pack (must be used for this configuration)

Assembly

1 The dimensions for the shelf position are to the holes for the cam stud.





Section 11 - Appliance tower configurations

50/50 Fridge and freezer (one appliance) options

The information below shows the cabinet configurations that can be achieved when installing a 50/50 fridge/freezer. Each overview page is followed by the shelf configurations applicable to the appliance shown.

Standard options


50/50 Fridge/
freezer
(one appliance)




14

Extra tall options

50/50 Fridge/
freezer
(one appliance)



14



Section 11 - Appliance tower configurations


Following the information on this page for positioning shelves and back panels.
The dimensions for the shelf positions are to the hole centre.

50/50 Fridge/freezer (one appliance) options


See cabinet modification page 162 for adapting the back panel to suit your tower configuration.

NOTE: Shelf configurations are identical for standard height and tall options.


14



NOTE: Filler rail height may require adjusting, before final fixing.



Back support panel and back panel are **NOT USED** in this application.



Section 11 - Appliance tower configurations

70/30 Fridge/freezer (one appliance) options

The information below shows the cabinet configurations that can be achieved when installing a 70/30 fridge/freezer. Each overview page is followed by the shelf configurations applicable to the appliance shown.


Standard options

70/30 Fridge/
freezer
(one appliance)



15

70/30 Fridge/
freezer
(one appliance
BOSCH)



16

NOTE: Appliance requires elevating by using additional base panels.


Extra tall options

70/30 Fridge/
freezer
(one appliance)




15

70/30 Fridge/
freezer
(one appliance
BOSCH)



16

NOTE: Appliance requires elevating by using additional base panels.



Section 11 - Appliance tower configurations

Following the information on this page for positioning shelves and back panels.
The dimensions for the shelf positions are to the hole centre.

70/30 Fridge/freezer (one appliance) options



See cabinet modification page 162 for adapting the back panel to suit your tower configuration.


NOTE: Shelf configurations are identical for standard height and tall options.

15

NOTE: Shelf position may require adjusting dependent on appliance/feet fitted.
Measure the height of the appliance before final top shelf fixing. In addition to this, when fixing the appliance plastic top trim for some fridge/freezers, the fixing holes may require re-drilling to avoid pre-drilled holes in the underside of the cabinet shelf.

NOTE: When fitting hinges to your side panel, make sure the correct hinge hole positions are used, in relation to the door drillings (see below).





Section 11 - Appliance tower configurations

Following the information on this page for positioning shelves and back panels.
The dimensions for the shelf positions are to the hole centre.

70/30 Fridge/freezer (BOSCH one appliance) options

See cabinet modification page 162 for adapting the back panel to suit your tower configuration.


NOTE: Shelf configurations are identical for standard height and tall options.

If not using a tall tower cabinet, a 180mm top box should be fitted to the tower to achieve a tall application (Upper door hinge moves into the top box for door fixing).

16


Cut out the top shelf using the dimensions given, to allow the shelf to fit over the hinge plate.

NOTE: The top shelf position will require drilling.




NOTE: Shelf position may require adjusting dependent on appliance/feet fitted. Measure the height of the appliance before final top shelf fixing. In addition to this, when fixing the appliance plastic top trim for some fridge/freezers, the fixing holes may require re-drilling to avoid pre-drilled holes in the underside of the cabinet shelf.


NOTE: When fitting hinges to your side panel, make sure the correct hinge hole positions are used, in relation to the door drillings (see below).



LH Door





LH/RH Door




RH Door

1833mm



Use shelf off cuts. Secure the base shelves together using 30mm CSK screws.



Section 11 - Appliance tower configurations


Full height larder fridge/freezer options

The information below shows the cabinet configurations that can be achieved when installing a full height larder fridge/freezer. Each overview page is followed by the shelf configurations applicable to the appliance shown.

Standard options

Full height
fridge/freezer
(50/50 door split)

Full height
fridge/freezer
(70/30 door split)



17a


17b

Configurations for
alternative appliances,
(see booklet supplied
with your appliance
for correct cabinet
installaation)

Extra tall options

Full height
fridge/freezer
(50/50 door split)


Full height
fridge/freezer
(70/30 door split)



17a

17b

Configurations for
alternative appliances,
(see booklet supplied
with your appliance
for correct cabinet
installaation)



Section 11 - Appliance tower configurations

Following the information on this page for positioning shelves and back panels.
The dimensions for the shelf positions are to the hole centre.

Full height larder fridge/freezer options


See cabinet modification page 162 for adapting the back panel to suit your tower configuration.

NOTE: Shelf configurations are identical for standard height and tall options.


If not using a tall tower cabinet, a 180mm top box should be fitted to the tower to achieve a tall application (Upper door hinge moves into the top box for door fixing).

17a Alternative appliance configuration

NOTE: Shelf position may require adjusting dependent on appliance/feet fitted. Measure the height of the appliance before final top shelf fixing. In addition to this, when fixing the appliance plastic top trim for some fridge/freezers, the fixing holes may require re-drilling to avoid pre-drilled holes in the underside of the cabinet shelf.





17b Alternative appliance configuration



Back support panel and back panel are **NOT USED** in this application.

NOTE: When fitting hinges to your side panel, make sure the correct hinge hole positions are used, in relation to the door drillings (see below).







Section 11 - Appliance tower configurations

Follow the instructions below for fitting the 70/30 tower cabinet doors to a full height fridge/freezer.




70/30 Fridge/freezer door application





- 1 Hang the doors to the cabinet as shown in the section on the installation manual and secure together with metal plates (see illustrations below).



- 2 Measure, mark and fit brackets to doors.
NOTE: For kitchen frontals with a centre panel, the bracket fixing will need to be secure only at the end nearest the door edge. Place an additional screw in the third hole along from the front to secure.





IMPORTANT: Use these screw positions for **shaker** frontals.



NOTE: For this fixing position, align the fridge door to the slider and mark fixing holes.

- 3 Drill through the two sets of holes pre-marked into the edge of the appliance door. Secure the slider parts of the brackets to the appliance door.





Section 11 - Appliance tower configurations

Larder tower options

The information below shows the cabinet configurations that can be achieved when installing a larder tower. Each overview page is followed by the shelf configurations applicable to the appliance shown.

Standard options

300 Larder tower with 3 drawers




19

500 Larder tower with 2 drawers



18

500 Larder tower with 4 drawers




20

600 Larder tower with 2 drawers



18

600 Larder tower with 3 drawers



19

Extra tall options

300 Larder tower with 3 drawers




19

500 Larder tower with 2 drawers




18

500 Larder tower with 4 drawers




20

600 Larder tower with 2 drawers




18

600 Larder tower with 3 drawers



19



Section 11 - Appliance tower configurations

Following the information on this page for positioning shelves and runners.
The dimensions for the shelf positions are to the hole centre.

Larder tower options with drawers

See cabinet modification page 162 for adapting the back panel to suit your tower configuration.


NOTE: Shelf configurations are identical for standard height and tall options.

If not using a tall tower cabinet, a 180mm top box should be fitted to the tower to achieve a tall application (Upper door hinge moves into the top box for door fixing).

18

*Bottom shelf fixing holes for larder application will require drilling at 720mm (KD blocks not required in larder application).


Spike the holes for the runner fixings using the dimensions shown in the diagram.




19

*Bottom shelf fixing holes for larder application will require drilling at 720mm (KD blocks not required in larder application).

Spike the holes for the runner fixings using the dimensions shown in the diagram.





Section 11 - Appliance tower configurations


Following the information on this page for positioning shelves and runners.
The dimensions for the shelf positions are to the hole centre.


Larder tower options with drawers

See cabinet modification page 162 for adapting the back panel to suit your tower configuration.

NOTE: Shelf configurations are identical for standard height and tall options.
 If not using a tall tower cabinet, a 180mm top box should be fitted to the tower to achieve a tall application (Upper door hinge moves into the top box for door fixing).


20







Section 11 - Appliance tower configurations

Half height frontals




Fridge/freezer application


Pilot drill and fit the brackets to the doors using the screws. **NOTE:** The bracket will automatically space the doors apart. Measure, mark and drill the side hinge hole positions following the dimensions shown.



Door jointing (standard frontals)



Door jointing (integrated handle frontals)






Dishwasher application


Fit the jointing brackets as above.

NOTE: In some dishwasher applications, spacer brackets (not supplied) may be required to ensure frontals sit level with the dishwasher door. The centre jointing brackets may cause the frontal to be raised at the join once the door is fitted to the dishwasher.


Door jointing (standard frontals)



Door jointing (integrated handle frontals)




Door spacing



Section 11 - Appliance tower configurations

Half height frontals


Fridge/freezer application




2

Measure, mark and fit brackets to doors.

NOTE: For kitchen frontals with a centre panel, the bracket fixing will need to be secure only at the end nearest the door edge. Place an additional screw in the third hole along from the front to secure.




IMPORTANT: Use these screw positions for **shaker** frontals.




3

Drill through the two sets of holes pre-marked into the edge of the appliance door. Secure the slider parts of the brackets to the appliance door.




NOTE: For this fixing position, align the fridge door to the slider and mark fixing holes.



Dishwasher application example

NOTE: Follow the dishwasher installation guide for specific fixing information relating to the specific appliance



Back of a dishwasher door illustrated.

Section 12

Midi tower and other appliance applications




Cabinet information

Hints and tips for installation.....	page 212
How the cabinet is supplied.....	page 213
Additional shelf pack.....	page 214
Cabinet modifications.....	page 214



Double oven

Double oven.....	page 215
------------------	----------




Single oven

Single oven.....	page 217
Single oven with warming drawer.....	page 219




Microwaves/compact oven

Microwave/compact oven.....	page 221
Microwave/compact oven with warming drawer.....	page 223



Fridge or freezer option

Fridge or freezer option.....	page 225
-------------------------------	----------




Larder option

Larder option.....	page 227
--------------------	----------

BOSCH appliances

Easy removable plinth.....	page 229
BOSCH washing machine.....	page 230
BOSCH washer dryer.....	page 231

Gas hobs.....	page 232
---------------	----------



Section 12 - Midi tower and other appliance applications

Hints and tips for installation

The information below relates to the midi appliance tower installation and modification. Please read the information below before starting the cabinet build.

IMPORTANT: All dimensions shown for the shelf configurations are measured to the centre of the fixing hole.

Shelves

All load bearing shelves must have KD blocks fitted underneath for extra strength and stability. Secure with 25mm screws.

NOTE: If the appliance being fitted clashes with the KD blocks, use metal larder brackets as a replacement.

Shelf Brackets

Mid shelves in configurations may be replaced with steel brackets LAM0012 depending on appliances fitted.

Plinth vents

If using the appliance tower in a fridge or freezer application, the plinth should be fitted with a vent.

Filler rails (part of supplied cabinet)

Cabinet filler rails may require scribing/removing, depending on the appliance fitted. Remove the panel from the shelf to scribe.

Fascia rails (frontal)

Fascia rails may require scribing depending on the appliance fitted.

Appliance sizes

Due to variations in appliance sizes, packing may be required under the appliance to achieve a slightly raised level. Use 'cut off's' from your back panel for this purpose. Screws are provided to secure in place.

Dishwashers and washing machines are not suitable for use within appliance towers.


Leg fixing

Follow the kitchen installation manual section for leg fixing information.

Wall fixing

The appliance tower **MUST** be secured to the wall for extra stability using larder brackets and screws (supplied in the fittings pack). Wall fixing screws have not been provided with this unit due to different wall types requiring different fixings.

NOTE: Where applicable, secure the tower through the back support panel.



Hinge fixing and adjustment


Follow the kitchen installation manual for all hinge and hinge plate fixing.


Drawer box assembly and installation (where applicable)

Follow the drawer box section for all assembly and installation information.

Fridge door fixing

For kitchen frontals with a centre panel, the bracket fixing will need to be secured only at the end nearest the door edge. Place an additional screw in the third hole along from the front to secure.







Section 12 - Midi tower and other appliance applications


How the cabinet is supplied

The midi appliance tower is supplied in a standard format, with a pre-fitted shelf to the **SINGLE OVEN** configuration, ready for you to tailor the specific appliance requirements.



Single oven format






Section 12 - Midi tower and other appliance applications

Additional shelf pack

Shelf packs are required for certain appliance tower configurations. These are indicated at each section where required and will be included in the relevant sales code.



Fixing:
Secure the shelf into the appliance tower using the VB cams and studs where applicable.
Filler rails are secured to the shelf using 45mm screws.


Cabinet modifications

All midi appliance towers will require the back panel to be modified or removed completely. This is due to the different appliance configurations.


NOTE: As a general rule, the back panel is only required behind a cupboard.
The appliance aperture must not be enclosed due to ventilation.

Remove the staples and slide the back panel from the unit. Cut panel to the appropriate sizes (see tower configuration pages for back panel sizes) and re-fit using the panel pins to secure to the back of the shelf panels.


NOTE: The fixed back support panel may need to be removed for fridge and freezer applications depending on the depth of the appliance.
To remove, use a saw to carefully cut the dowels between the panel and cabinet side.



Single oven example




NOTE: Do not discard any of the cut back panel at this stage. Parts of the back panel may be required for packing under your appliance due to size variations.



Double oven


Standard options

45mm Fascia rails required where indicated



1

Fascia rails (frontal): Fascia rails may require scribing depending on the appliance fitted.



Section 12 - Midi tower and other appliance applications


Following the information on this page for positioning shelves and runners.
The dimensions for the shelf positions are to the hole centre.


Double oven

See cabinet modification page 214 for adapting the back panel to suit your tower configuration.

NOTE: Fascia rails may require scribing depending on the appliance fitted.

1






Single oven


Standard options

45mm Fascia rails required where indicated



2

Fascia rails (frontal): Fascia rails may require scribing depending on the appliance fitted.



Section 12 - Midi tower and other appliance applications


Following the information on this page for positioning shelves and runners.
The dimensions for the shelf positions are to the hole centre.


Singleoven

See cabinet modification page 214 for adapting the back panel to suit your tower configuration.

NOTE: Fascia rails may require scribing depending on the appliance fitted.

1






Single oven with warming drawer

Standard options



3



Section 12 - Midi tower and other appliance applications


Following the information on this page for positioning shelves and runners.
The dimensions for the shelf positions are to the hole centre.

Single oven with warming drawer

See cabinet modification page 214 for adapting the back panel to suit your tower configuration.


NOTE: Fascia rails may require scribing depending on the appliance fitted.


3



Warming drawer shelf positions

The drilling positions for warming drawer application may not be pre-drilled in side panels. If midi appliance tower configuration includes a warming drawer, follow the diagram for marking the correct drilling positions in the side panel as shown.






Microwave/Compact oven

Standard options

45mm and 115mm Fascia rails required where indicated



Fascia rails (frontal): Fascia rails may require scribing depending on the appliance fitted.



Section 12 - Midi tower and other appliance applications


Following the information on this page for positioning shelves and runners.
The dimensions for the shelf positions are to the hole centre.

Microwave/Compact oven

See cabinet modification page 214 for adapting the back panel to suit your tower configuration.

NOTE: Fascia rails may require scribing depending on the appliance fitted.

4






Microwave/Compact oven with warming drawer

Standard options

Microwave oven and
warming drawer



5



Section 12 - Midi tower and other appliance applications


Following the information on this page for positioning shelves and runners.
The dimensions for the shelf positions are to the hole centre.


Microwave/Compact oven with warming drawer

See cabinet modification page 214 for adapting the back panel to suit your tower configuration.

NOTE: Fascia rails may require scribing depending on the appliance fitted.


5






Fridge or freezer option

Standard options



6



Section 12 - Midi tower and other appliance applications

Following the information on this page for positioning shelves and runners.
The dimensions for the shelf positions are to the hole centre.


Fridge or freezer


See cabinet modification page 214 for adapting the back panel to suit your tower configuration.

NOTE: Fascia rails may require scribing depending on the appliance fitted.

IMPORTANT: For this midi appliance tower, the mid shelf will need to be cut at the back to allow for ventilation.


6






Larder option

Standard options



7



Section 12 - Midi tower and other appliance applications


Following the information on this page for positioning shelves and runners.
The dimensions for the shelf positions are to the hole centre.

Larder

See cabinet modification page 214 for adapting the back panel to suit your tower configuration.



NOTE: Fascia rails may require scribing depending on the appliance fitted.

7




Easy removable plinth

- 1 Cut and edge a section of plinth (min 600mm) in front of the appliance.




NOTE: Ventilation is only required in tumble dryer applications


- 2 Cut the plinth section to suit the vent grille being used (if applicable).
NOTE: Ensure sufficient space is left for the magnet positioning at each end.




- 3 Screw fix magnets to each end of the cut plinth section at the back of the plinth.
NOTE: LAM8876 fixing kit and HKC0020




- 4 Screw fix magnets to the back of each end of the main plinth sections




- 5 Position metal plates (x2) to the magnets so half the plate is overlapping the end.



- 6 Fit the vent grille to the cut plinth section and secure in place using the screws supplied.
NOTE: Ventilation is only required in tumble dryer applications




- 7 Fit the plinth vent section to the main plinth aligning the magnets with the metal plates.



View from the reverse of plinth

BOSCH washing machine




IMPORTANT NOTES:

This installation manual should be used in conjunction with the instruction booklet supplied with the appliance for hinge fixing and door.


Installation

- Drill the hinge holes on the LH or RH side of the door depending on the opening preference.
NOTE: Do not drill the hinge hole any deeper than 12mm.
 Follow the appliance instruction booklet for door hanging.
NOTE: For drawer-line door option, use the HKC0020 jointing plate as a replacement for the catch plate supplied (double drilled doors only).


**Hi-line option door drilling
(716 x 597mm)**



**Drawer-line option door drilling
(716 x 597mm)**




NOTE: Double drilled DL doors cannot be fitted.




- Fit fascia rail between the two adjacent cabinets fitting flush with the front and top edge.

Cut fascia to suit



Position the appliance and use the foot adjustment and packing (if necessary) to achieve the correct height of the appliance.

BOSCH washer dryer





IMPORTANT NOTES:


This installation manual should be used in conjunction with the instruction booklet supplied with the appliance for hinge fixing and door location.

Installation

- 1 Drill the hinge holes on the LH or RH side of the door depending on the opening preference.
NOTE: Do not drill the hinge hole any deeper than 12mm.
Follow the appliance instruction booklet for door hanging.




NOTE: Double drilled Drawer-Line doors cannot be fitted.



- 2 Fit fascia rail between the two adjacent cabinets fitting flush with the front and top edge.

Cut fascia to suit



Position the appliance and use the foot adjustment and packing (if necessary) to achieve the correct height of the appliance.



Gas hobs

Gas hob - minimum distance

The minimum distance is from the cutout to the next vertical surface ie; splashback or upstand.




Important: Refer to appliance booklet for specific minimum distance dimensions.




Section 13

Curved units





Curved units

Curved corner post	page 234
Curved base cabinet	page 235
Curved wall cabinet	page 236
Curved plinth - Joining	page 237



Section 13 - Curved units

Curved corner post



Scan the QR code with your smart device to access a short installation video. This video also covers the corner post application with the decorative plinth.



Assembly


- 1 x3 Rails supplied (700mm in length) for both post rail and back rail. Cut and use rails appropriate to the height of your post/decor end (see diagrams below).

Measure and cut post and decor end dependent on cabinet application, making sure allowance is made for any scribing to the wall requirements.


IMPORTANT: To reduce the risk of damage to cut edges due to moisture ingress (where they are exposed to moisture) all raw edges must be sealed using a suitable moisture resistant sealant, such as waterproof varnish or silicone.

2


Secure post rail(s) into place using PVA glue




Screws x3 (25mm) per fixing block



Screws x3/6 (32mm)




Metal spacer brackets for 16mm decor ends
HKC0020




For 16mm decor ends use 2/3 metal brackets to space the decor end away from the the post/cabinet

3

Screws (55mm)







Screws (32mm)




'X' mm

Door


NOTE: Dimension 'X' is dependent upon door thickness. An additional 2mm should be added onto the dimension of the door to allow for door alignment.





Section 13 - Curved units


Curved base cabinet




Assembly

For fixing the legs to your cabinet, see **page 20-21**.


- 1 Fit battens to the decor panel.




- 2 **Curved base soft-close hinge pack required**
Fit the hinge and plate to the door and decor panel.




- 3 With the base cabinet laid flat, secure the decor panel and door using screws through the base and top shelf and into the battens.






Section 13 - Curved units

Curved wall cabinet



Standard wall cabinet






Deep wall cabinet

NOTE: For curved deep wall cabinets, use the cranked hinges supplied with cabinet


Installation

- Position the curved cabinet to the wall and secure through the back panel using suitable wall fixing screws.
NOTE: Wall fixings can be hidden behind the shelf positions as required. Ensure the cabinet is flush with the adjoining unit side and front edges.




2


Secure through the adjoining unit and into the curved wall.



30mm CSK screw




IMPORTANT:
When tiling up to the curved wall cabinet, ensure sufficient gap is left to enable the door to open correctly.



Section 13 - Curved units

Curved plinth - Joining




Corner post cap and cornice/pelmet fixed in the same way.

Assembly


Align the curved plinth section to the side of the curved cabinet base and scribe the end to the wall as required. **Mark and fit plinth clips to the back of the plinth sections as shown.**

IMPORTANT: To reduce the risk of damage to cut edges due to moisture ingress (where they are exposed to moisture) all raw edges must be sealed using a suitable moisture resistant sealant, such as waterproof varnish or silicone.


- 1 Apply a two part adhesive to the adjoining ends of the plinth sections and fit together.
NOTE: Make sure sections are flush.



- 2 Fit a metal plate to the back of the plinths to secure the joint.




- 3 Position the curved plinth assembly to the cabinet run and clip onto the cabinet leg sections.



Section 14


Inclusive kitchens



Inclusive kitchens

Base cabinet wall fixing	page 240
600mm Wall pull down unit	page 241
Adjustable wall bracket	page 242
Leg and plinth fixing	page 243
Castor assembly	page 245
Tower pull-out worktop application	page 246


NOTE: For rise and fall worktop assembly and installation, please see the literature provided with the product.



Section 14 - Inclusive kitchens

Base cabinet wall fixing


Components below not supplied
as SKU items.



Rail


Bracket

HKE0050




Assembly


- 1 Cut a rail to the appropriate length.
Fix rail using suitable wall fixing
screws at regular intervals.




- 2 Fit the brackets to the cabinet
each side using the screws to secure.




- 7 Fix the base of the cabinet
to the rail using metal brackets
and screws to secure.




- 3 Place cabinet to the wall and
mark for wall fixing positions.




- 6 Align the cabinet to the
fitted brackets and secure
with screws.




- 5 Drill fixing locations and
secure the brackets to
the wall using suitable wall
fixings.




- 4 For ease of fixing, remove the
brackets from the cabinet.






Section 14 - Inclusive kitchens

600mm Wall pull down unit





Adjustment & Operation




Mechanism resistance adjustment switch

Use the handle to pull down and lift up




Do not use the accessory for storing unstable fragile items




Make sure there are no objects obstructing the pull down unit from opening

i Handle should always be in a near vertical position when lifting up/down and never horizontal



Adjustable wall bracket



NOTE:

Existing cabinet wall hanging brackets should be left in place, as these are factory fitted and **must not to be removed**. Removal of these brackets could damage the cabinet.

Wall unit can move up and down.
Always maintain 3 positions of contact on the wall bracket.


IMPORTANT:

Maximum weight load capacity per set of brackets is 90kgs.
Existing wall cabinet brackets can be left in place.


Assembly

Ensure back panel pins are flush with surface of the side panel before fitting brackets


- 1 Fit the brackets to the back of the cabinet using the screws provided. Brackets should sit flush against the side panel.



- 2 Mark the standard height of the cabinet on the wall. Fit the wall brackets following the dimensions shown. Carefully hang the cabinet to the wall, hooking onto the brackets at the chosen height.




Use suitable wall fixings depending on the wall construction.



Max height
86mm above standard

Lowest position
125mm below standard


	Two positions up - 86mm	
	One position up - 45mm	
	One position down - 40mm	
	Two positions down - 83mm	
	Three positions down - 125mm	





Leg and plinth fixing

Follow the diagrams for the different types of inclusive leg option and the plinth application.

60mm Leg fixing




Plinth clip




Push plinth up under the protruding section of the clip and against the leg.

Standard plinth modification

Cut a standard plinth in half to use for a 60mm leg application. The height of the cut plinth will allow for 20mm of scribing for uneven floors.








Section 14 - Inclusive kitchens


Leg and plinth fixing

Follow the diagrams for the different types of inclusive leg option and the plinth application.

223mm Leg fixing





Push plinth up under the protruding section of the clip and against the leg.




Custom fit panel modification

Cut a custom fit panel to make the plinth for a 60mm leg application. The height of the cut panel will allow for 20mm of scribing for uneven floors.








Castor assembly




Assembly







NOTE: Make sure castors are fully located onto the pegs, so they click into position.






Tower pull-out worktop application

Single oven tower with pull-out worktop to door and drawer application



When fitting the worktop to the runners, ensure the worktop is positioned 2mm forward from the cabinet to allow for the fitting of bumpers. Use a strong wood glue to secure dowels.


Pull-out shelf



Follow the dimensions below for the positions of the drawer box fixing brackets. Follow the leaflet supplied with your drawer box for pan drawer installation and adjustment.

Drawer front drilling


600 Standard door used for the 600 pan drawer box



NOTE: The above drilling for the drawer front is also applicable for the 600 Fridge or freezer tower.

Section 15


Other useful assembly guides



Other assembly guides


Larder pantry.....	page 248
Inframe kitchens.....	page 250
Larder top box cabinet.....	page 255
Corner larder unit.....	page 257
Tall corner larder unit.....	page 259
Walk in corner larder.....	page 261
Decorative plinth - Corner larder application.....	page 265

NOTE: This section contains some of our popular assembly and installation guides. Some of these may be provided with the specific product item. If this is the case, always use the leaflet supplied with the product as this will be the latest copy.



Section 15 - Other useful assembly guides

Larder pantry




IMPORTANT NOTES:

Larder pantries are constructed using the components shown.
Doors and decor panels are range specific.



Scan the QR code with your smart device to access a digital copy of the kitchen installation manual



Larder Pantry Examples (as stand alone units)

Larders in a run of units would not have decor ends as shown above


Tall larder options can be constructed with the addition of larder top box units and 1400mm tall doors

If fitting a door balcony into a single larder cabinet, the upper shelves will require cutting down to 400mm in depth and shelf fixing holes re-drilled at the front.

Configurations & Components

Cabinet sales options ****59* (Std)

Cabinet sales options ****5A* (Tall)



1000 Larder Pantry

1000 Larder Pantry 2/4 Drawer

Doors and/or drawer fronts have been supplied depending on your larder pantry configuration (Std or Tall)

Other fittings components will also be supplied at part of your sales option




1000mm
2/4 Drawer Base Cabinet x1
(plus drawer boxes
& runner support pack)

OR





1000mm
Base Cabinet x1




Top Cabinet x1
(See leaflet located
further in this section)




Top box Cabinet x2
(if applicable)



Door Balcony x2*
(HYH8147)



Timber Cutlery*
Drawer x1
(HYH82**) (with drawer pantry configurations)



500/600 Larder Pantry 2 Drawer

500/600 Larder Pantry

Doors and/or drawer fronts have been supplied depending on your larder pantry configuration (Std or Tall)



Other fittings components will also be supplied at part of your sales option




500/600mm Larder
Cabinet x1
(plus drawer boxes
if applicable)



Top box Cabinet x1
(if applicable)




Door Balcony* x1
(HYH8147)



Timber Cutlery*
Drawer x1
(HYH82**) (*installation leaflets supplied with product (or scan QR code))

(*installation leaflets supplied with product (or scan QR code))



Section 15 - Other useful assembly guides

Larder pantry

Larder Pantry Assembly


Shown below is the general overview of the larder pantry construction in a stand alone application.




Please ensure unit is secured to the wall using suitable wall fixings depending on the wall construction.

1220mm door (or 1400mm if tall application)

Thick decor end post assembly (if applicable)




Cornice



Top box (if applicable)


Hinge plate fixing positions in a tall application will be located in the top box cabinet




Cabinet centre post would not be in place for drawer applications




Scan the QR code for Door Balcony Instructions



Scan the QR code for Timber Drawer Instructions



Scan the QR code for Top Cabinet Instructions



Step by Step

Pantry construction is identical, other than the cabinet configuration. If constructing a tall pantry, fix the larder top box to the top of the top cabinet

1. Fit legs to the base or larder cabinet

NOTE: Preparation of your top cabinet will be required. See link to leaflet via QR code, or the leaflet with the top cabinet

2. Secure base and top section together (if applicable)

3. If constructing as a stand alone unit, measure, cut and assemble the thick decor end posts with the tower decor ends.

4. Fit the decor end assembly to the sides of the cabinet - Secure from the inside of the cabinets as required.

5. Assemble and fit drawers into the base cabinet (if applicable)


6. Fit the doors and drawer fronts where required - fit handles if required

NOTE: Doors will require jointing plates - HKC0061

7. Fit the plinth and cornice as required

Follow the kitchen installation manual for all wall fixing, drawer/door adjustment and decor accessory assembly.

If fitting a timber cutlery tray or door balcony to your unit, follow the leaflets supplied with the products. These leaflets can be accessed by scanning the QR codes.




Section 15 - Other useful assembly guides

Inframe kitchens



Profile use example



Drawer Line example

IMPORTANT NOTES:


In Frame look is achieved by using the components shown.

Any cut edges should be sealed with a water proof varnish or PVA glue.
Any visible cut edges should be re-edged.

A sharp saw blade **MUST** be used when cutting the profiles/rails.



Scan the QR code with your smart device to access a digital copy of the kitchen installation manual



Components

In Frame Shaker Profile SKU - *****1G

3000 x 75 x 30mm (Hockley Range)
3000 x 77 x 30mm (Shaker Ranges)

Spacer rail (supplied with profile)

InFrame Shaker Appliance Trim SKU - *****1H 596 x 20.5 x 30mm

Optional - Mock Hinge (supplied with screws) SKU - HKC000*




Application example & installation principles


Cut the profiles and trims to frame your kitchen

- Any cut edges should be sealed with a water proof varnish or PVA glue
- Any visible cut edges should be re-edged or sealed
- A sharp saw blade **MUST** be used when cutting the profiles/rails.
- Profiles, when at the end of the run, should be used in conjunction with decor end panels
- Return the top side profile on all cabinets*
- Attach the trim to the bottom of dishwasher doors and BUOH drawer fascias
- Cabinets are spaced 30mm apart
- Worktop is elevated by 30mm
- Use spacer rails (RKC0072) to support worktop
- Ensure the distance between a fitted hob and the underside of a wall unit with profile fitted (where a built in canopy is being used), is a minimum of 750mm

*If not returning the profile above a base or wall, a tower decor end will be required to make a taller base or wall decor end due to the 30mm elevation.



NOTE: If using the decorative plinth with the inframe profile, the profile should not be used at the base of the cabinets.



Section 15 - Other useful assembly guides

Inframe kitchens

Before you begin


Please review to understand the principles and key planning considerations before cutting any profiles to size. Whilst the kitchen installation is no different to a normal installation, cabinet spacing and profile locations must be understood to ensure profiles are cut correctly.

Key fitting & planning considerations




Your CAD plan will have provided the correct amount of profiles and trims required. Due to the elevation of the worktop, additional spacer rails are required to support the worktop. These have been supplied as part of your order - RKC0072.


Worktop spacing




Space between cabinets & end of a run



Returning the profile at the top of a cabinet





Section 15 - Other useful assembly guides

Inframe kitchens

Cutting the profile/trim application




Carefully measure the profiles before cutting.
Profiles are always returned to the wall at the top of the cabinets.
Make sure your cutting blade is sharp.


Fitting profiles to a cabinet

Carefully measure, cut and fit the profiles to the cabinets, securing through the inside of the cabinet and into the profile.

NOTE: Pilot drill the fixing positions before securing with screws. Screw heads can be covered using the self adhesive cover caps dependent on the cabinet interior finish (HKB14**).



NOTE: If using the decorative plinth with the inframe profile, the profile should not be used at the base of the cabinets.




Spacer Rail

SIDE FIXING

Decor End

Profile



30mm csk

Door thickness

B

A

Cabinet

TOP/BOTTOM FIXING

Cabinet




D


Reduce plinth height by 30mm to suit

Central profile fixing

For some kitchens where a 2 drawer application is used, a profile can be adapted and fitted centrally to the cabinet using brackets to secure.

NOTE: The profile will require cutting at each end so it sits around the side panel of the cabinet. The back 'step' section, will also need removing so brackets can secure flush to the back as shown. Ensure the profile is located correctly and level.






Section 15 - Other useful assembly guides

Inframe kitchens

Cutting the profile/trim application

Using the appliance trim - 596mm




Appliance Door Example




Do not run a profile under the Appliance or a BUOH. Use the trim section supplied, cutting to size (if required) for shorter applications.

NOTE: The trim will have a protective film on it. To remove this, carefully score at the back of the trim where the material overlap is.




BUOH Drawer Example



Dishwasher application




Fit a section of profile at the top of the dishwasher, flush with the top of the adjoining cabinets. Secure to the cabinets each side.




Mock hinges

To complete the look of the In Frame Kitchen, mock hinges can be fitted. These locate to the side of the In frame shaker profile, wherever a door hinge would normally be fitted.

IMPORTANT: Screws MUST be fitted flush with the surface of the hinge plate. Any screws not fitted flush may clash with the door edge and cause damage.






Section 15 - Other useful assembly guides

Inframe kitchens


Internal corners

For internal corners, butt the end of the profile to the adjoining finished edge. Drill through profiles and secure using screws into the cabinet front rails.





Corner planning

For 931/631 corners, the wall cabinets should be spaced as the below illustration shows, with no profile between the first & second cabinet.




Appliance at the end of a run

Construct the profiles and decor end panel as shown. Ensure the decor end panel is secured to the wall.




Secure the decor end to the wall using L shape cabinet fixing brackets and suitable wall fixing screws.




Section 15 - Other useful assembly guides

Larder top box cabinet



Corner Larder
Top Cabinet
(Separate shelving pack)




Pantry
Top Cabinet
(Separate shelving pack)

IMPORTANT NOTES:



Scan the QR code with your smart device to access a digital copy of the kitchen installation manual



Fittings not used in the assembly of the product are supplied for installation of the unit and should not be discarded.
The cabinet should be secured to the base cabinet once constructed.
Ensure the cabinet is secured to the wall using the larder brackets.

Internal shelves have a max load weight of 6kgs.
The top of the cabinet max load weight is 24kgs.




NOTE: Cabinet centre post is fitted at the back of the cabinet for transit.



Assembly - Corner Larder Top Cabinet

- 1 Remove the centre post from the cabinet.
NOTE: Retain larder brackets for fixing cabinet to the wall.



- 2 Fit the post to the cabinet, drilling through the top and bottom fixing holes. Secure with screws.




Fit post correct way up with three shelf holes towards the top.




Fit mid shelves
(Supplied separately)



Shelf support x8
(with location pin)



Centre post
shelf support x3






Back shelf
support x3
(no pin)


Assembly - Pantry Top Cabinet

- 1 Remove Shelf and studs from the side panels.

- 2 Cut shelf to 402mm from front edge, then drill through fixing holes as shown.

- 3 Drill through fixing holes in the top of the cabinet.







Section 15 - Other useful assembly guides

Larder top box cabinet

4 Fit mid shelf and lock in position.




5 Fit the shelf pack to the unit in the sequence shown. (Supplied separately)




IMPORTANT: For extra mid shelf stability, secure the shelf at the back. Measure for the mid shelf centre point of the back of the unit, then pilot drill through the back panel and into the back of the mid shelf. Use screws to secure through the rail and into the mid shelf.

Base Panel Removal


In order to create a pantry cabinet with a worktop as the base panel, follow the stages below for how to carefully remove and replace the base panel.




Carefully remove staples from the back of the cabinet at the base.



Cut base panel 10mm in from each side.
NOTE: Be careful when cutting that the end and back panels are not damaged.



Carefully remove final sections of base panel and trim back dowels. Clean away any glue/dust.




Measure, cut and fit required worktop panel, securing with screws or adhesive each side and back.


Integrated Microwave/Coffee Maker housing option

Additional panels will be required to create a suitable aperture. Drill 7mm diameter holes through shelves A & B then fix the vertical panel. Cut and re-drill the mid shelves (see dimensions).




When fitting an appliance, ensure there is adequate ventilation as shown in your appliance installation booklet.





Section 15 - Other useful assembly guides

Corner larder unit



IMPORTANT NOTES:

The kitchen installation manual should be used for information relating to cabinet installation, hinge and door fitting/adjustment




Scan the QR code with your smart device to access a digital copy of the kitchen installation manual



Assembly Overview


Sales code suffix (****59F)



Blanking panels are also required x2 for this assembly (see step by step guide)

RK00601

Plinth section can also be 'stepped back' from the door to align with adjoining units as required.



Corner larder unit

Planning Considerations




Fig. B

Tray space box (using base decor ends)




Fig. C

Corner fillet/infill




Fig. D






Fig. E



Assembly & Installation


Step by Step Guide

- Using the planning considerations (**Fig. A**), position the 1000mm base cabinet into the corner. Once in place secure using the wall brackets as shown in the kitchen installation manual.
 - Fit the top larder cabinet to the base cabinet and secure using the screws provided.
 - Cut the panels to construct the corner fillet/infill panels.
 - Fit the corner fillet section to the base and larder top cabinet using KD blocks to secure (**Fig. C**).
 - Fit the infill panel to the fillet section using screws (**Fig. C**).
- NOTE:** Blanking panels (6mm) should be used top and bottom against the opening of the cabinet which will be next to the adjoining tray space box/wine racks. Secure using screws into the front of the cabinets. A small gap should be left so KD block fixing for the infill panel can be achieved to the tray space box/wine racks.
- Using base decor end panels (and the planning considerations for measurements), construct the tray space unit using screws to secure (**Fig. B**).
 - Secure the wine racks and tray space to the side of the 400mm larder cabinet using screws from the inside of the larder cabinet.
 - Fit the 400mm larder assembly to the base and larder top aligning with the infill panel. Secure the larder to the wall and the infill to the wine rack/tray space using KD blocks.
 - Fit the decor ends to the LH & RH side of the corner larder, securing to the side panels of the cabinets from the inside.
- NOTE:** Scribe panels to the wall as required. Ensure the decor end panels protrude the cabinets by the thickness of the frontals being used with the unit.
- Using a base decor end, cut the top triangular section and secure to the top of the units using joining plates (**Fig. A**).
 - Fit the hinge plates to the LH side of the 1000mm base & larder top and the RH side of the 400mm larder unit (**Fig. D**).
 - Fit the 170° hinges to the doors (**Fig. E**).
 - Fit the doors to the cabinet and adjust (see kitchen installation manual). Use metal plates to join the top and bottom door sections. Fit handles to the doors as required.
 - Cut the wall decor end to make two plinth sections 210mm in height. Secure these to the bottom of each door using screws to secure (see assembly overview).
- NOTE:** Plinth sections will require 'notching' at the back.
Fit cornice and inner plinth sections as required.



Section 15 - Other useful assembly guides

Tall corner larder unit



IMPORTANT NOTES:


The kitchen installation manual should be used for information relating to cabinet installation, hinge and door fitting/adjustment




Scan the QR code with your smart device to access a digital copy of the kitchen installation manual



Assembly Overview





Tall corner larder unit

Planning Considerations




Fig. B

Tray space box (using base decor ends)




Fig. C

Corner fillet/infill




Fig. D






Fig. E



Assembly & Installation


Step by Step Guide

- Using the planning considerations (**Fig. A**), position the 1000mm base cabinet into the corner. Once in place secure using the wall brackets as shown in the kitchen installation manual.
 - Fit the top larder cabinet to the base cabinet and secure using the screws provided.
 - Fit the 500 larder top box to the top of the larder top using screws to secure.
 - Cut the panels to construct the corner fillet/infill panels.
 - Fit the corner fillet section to the base and larder top cabinet using KD blocks to secure (**Fig. C**).
 - Fit the infill panel to the fillet section using screws (**Fig. C**).
- NOTE:** Blanking panels (6mm) should be used top and bottom against the opening of the cabinet which will be next to the adjoining tray space box/wine racks. Secure using screws into the front of the cabinets. A small gap should be left so KD block fixing for the infill panel can be achieved to the tray space box/wine racks.
- Using base decor end panels (and the planning considerations for measurements), construct the tray space unit using screws to secure (**Fig. B**).
 - Secure the wine racks and tray space to the side of the 400mm larder cabinet using screws from the inside of the larder cabinet.
 - Fit the 400 larder top box to the top of the larder cabinet using screws to secure.
 - Fit the 400mm larder assembly to the base and larder top aligning with the infill panel. Secure the larder to the wall and the infill to the wine rack/tray space using KD blocks.
 - Fit the decor ends to the LH & RH side of the corner larder, securing to the side panels of the cabinets from the inside.
- NOTE:** Scribe panels to the wall as required. Ensure the decor end panels protrude the cabinets by the thickness of the frontals being used with the unit.
- Using a base decor end, cut the top triangular section and secure to the top of the top box units using joining plates (**Fig. A**).
 - Fit the hinge plates to the LH side of the 1000mm base & larder top and the RH side of the 400mm larder unit (**Fig. D**).
 - Fit the 170° hinges to the doors (**Fig. E**).
 - Fit the doors to the cabinet and adjust (see kitchen installation manual). Use metal plates to join the top and bottom door sections. Fit handles to the doors as required.
 - Cut the wall decor end to make two plinth sections 210mm in height. Secure these to the bottom of each door using screws to secure (see assembly overview).
- NOTE:** Plinth sections will require 'notching' at the back. Fit cornice and inner plinth sections as required.



Section 15 - Other useful assembly guides

Walk in corner larder



IMPORTANT NOTES:

We recommend this unit is constructed with supporting cabinets on at least one side to ensure rigidity - See planning considerations below

The kitchen installation manual should be used for information on hinge and door fitting/adjustment

Cut panels (where visible), should be re-edged

The interior of the corner larder can be filled with cabinets, see additional unit information

Rail pack supplied at 2055mm for tall applications. Cut to 1875mm for standard applications.
Use the top panel for creating a ceiling to your larder unit. This is supplied for an 800mm opening but should be cut down for 600mm opening application.

Components overview - basic construction

Larder Rail Pack x1 (****855)

Range Specific Tower Decor End x2 (std/tall)


155°Hinge Pack x5 (HKC0029)

Joining Plate x2 (HKC0061 or HKC0062)


Range Specific Wall Decor End x1




Scan the QR code with your smart device to access a digital copy of the kitchen installation manual & installation animation







Manual




Animation



Planning considerations



x2



Section 15 - Other useful assembly guides

Walk in corner larder

Components overview - additional inside options (Example only)

Additional cabinets can be used inside the larder tower as shown below. Cabinets should be secured to the wall and together as shown in the wall cabinet section of the kitchen installation manual. **SKU suffix codes shown below for cabinets required.**

350mm Wall Cabinet x2

FH - ****402 or
Tall - ****459

NOTE: In an 800mm opening application wall cabinets can be 450mm (FH - ****415 or Tall - ****466) using a 62mm spacer/infill requirement each side

Worktop

Range/decor specific

350mm Wall Cabinet x2

FH - ****402

NOTE: In an 800mm opening application wall cabinets can be 450mm (FH - ****415) using a 62mm spacer/infill requirement each side

631 L Shape Corner Wall x1

FH - ****472 or
Tall - RKC1473

Infill panels x2

62mm or 20mm depending on corner opening size
Use wall decor decor end panel

631 L Shape Corner Wall x1

FH - ****472

Plinth x1


Range specific

Cabinet leg pack x4 packs

HKC0082


See foot fixing to the underside of the wall cabinets

800mm Opening



62mm
spacer/infill panel



600mm Opening




20mm
spacer/infill panel

Cutting the top panel - for 600mm opening option only



The top panel has been provided to service an 800 door opening (x2 400 doors). If you're using a 600mm opening, cut the panel along the guidelines pre-marked on the panel, using a circular saw with a sharp saw blade.






Walk in corner larder

Assembly & Installation



Door hinge positions differ in location. Make sure the correct side of panel C is used for door hinge and hinge plate alignment



Step by Step Guide

1. Position the adjoining cabinets to the wall, spacing them 1019mm from the corner* (image A). Secure the cabinets in place using wall fixing brackets, see section 5.

2. Fit decor end panels to the cabinets, fitting them flush with the front edge. Scribe to the wall as required (image A).

3. Secure the decor ends from inside the adjoining cabinets.
NOTE: If one side of the corner pantry does not have an adjoining cabinet, the decor end should be secured using metal brackets on the inside back edge and to the floor (see planning considerations).

4. RAIL PACK APPLICATION (****855)
Cut all four rails to the required length (if applicable)

Important: Rail pack side rails (C) have an identified A face & B face.

A face = Double door opening application

B face = Single door opening application


5. Fit the inner uprights to the decor end with the angled edge to the front. Secure using 30mm screws in four positions (image B).


NOTE: Ensure the upright is flush to the top of the decor end.

6. Fit the side rails to the angled edge of the uprights securing with screws (image B).

NOTE: Position the screws behind where the hinge plates will be located.

If you are not putting cabinets into your corner larder unit, other interior options can be fitted such as shelving. Use decor end panels and battens to achieve your bespoke shelving options.





Walk in corner larder


Assembly & Installation


Top Panel fixing

Fit battens to the wall, 18mm below the top edge of the decor end panels. Secure into the wall using suitable wall fixings.

Fit the top panel to the assembly, resting the panel on the battens on the rails.


NOTE: If fitting wall cabinets to the inside of the unit, the battens will not be required as the top panel will fit/secure to the top of the cabinets.






Section 15 - Other useful assembly guides

Decorative plinth - Corner larder application



PLEASE READ THIS LEAFLET BEFORE INSTALLATION OF THE CORNER LARDER AND DECORATIVE PLINTH. SOME PANEL MODIFICATION WILL NEED TO BE CARRIED OUT PRIOR TO INSTALLATION.



Leaflet demonstrates different decorative plinth profiles

IMPORTANT NOTES:

Decorative plinth should be 'dry fitted' first, before any glue/permanent fixing is carried out.

Cabinets should be fitted and levelled before installation of the plinth.

Plinth sections may require scribing to the contour of the floor.

Any cut edges should be sealed using a waterproof varnish to protect against moisture ingress - see sealant instructions for application.

The highest point of the plinth should be established first (Max height 180mm)

Ensure all dimensions are checked before cutting. Make sure tool blades are sharp.


Follow the leaflet provided with the corner larder & decorative plinth for cabinet and standard plinth installation.

This is also covered in the kitchen installation manual

NOTE: 800 opening shown (x2 400mm larder doors)





Scan the QR code with your smart device to access a short installation animation



Fitting principles

The decorative plinth will require modification to work with the corner larder cabinet. The plinth is secured to the door using brackets, and when the door is opened, folds back into the adjoining cabinet.



Plan view shown




Cutting the plinth (for 800 & 600 openings)


The decorative plinth and plinth rail will require cutting to size. Follow the diagram below for part cutting angles and dimensions (LH section shown).

Plan view shown



Fit the rail and plinth sections together using silicone.






Section 15 - Other useful assembly guides


Decorative plinth - Corner larder application

Adjoining cabinets - Front leg positioning

The adjoining cabinets will require the front leg (closest to the corner larder), moved, so the plinth section does not clash when doors are opening. Follow the diagram below for re-positioning the leg.




Remove the plastic location dowels at the top of the leg section and secure to the base panel of the cabinet using screws.



Cutting the decor ends (side of corner larder)


The side panels (decor ends), of the corner larder will require cutting, to ensure the plinth section (secured to the door), can open freely. Follow the dimensions below for panel cutting.



Joining the plinth to the door

Fully assemble the corner larder and adjoining cabinets. Secure the doors to the cabinet then fit the plinth sections, using the brackets and screws.

NOTE: The plinth sections will open with the doors, with side sections folding back up the adjoining units.



Index

50/50 Tower fridge/freezer (one appliance) options	p197	Extra tall tower cabinet options, (2292mm, including legs)	p12
500mm and 600mm Bi-fold unit	p114	Handleless drawer units	p8
600mm Wall pull down unit - Inclusive kitchens	p241	Midi tower units	p11
631 Standard corner wall cabinet left hand/right hand - Wall fitting... ..	p105	Standard cabinet options - Wall and base	p8
70/30 Fridge/freezer door application	p204	Standard height tower cabinet options, (2112mm, including legs)	p10
70/30 Fridge/freezer (one appliance) options	p199	Care and maintenance information	p5
70/30 Fridge/freezer (BOSCH one appliance) options	p199	Castor assembly - Inclusive kitchens	p245
800/900/1000mm corner cabinets	p27	Clearance dimensions	p104
800/900/1000mm Hi-line and drawer-line corner cabinets	p26	Compact oven and two drawer application	p196
800/900/1000mm Hi-line, drawer-line and larder corner cabinets	p28	Concealed hanging brackets - Deep wall cabinet	p25
900 5 drawer chest	p98	Connecting and levelling - Base cabinets	p30
931 Corner base cabinet	p29	Corner base cabinet centre upright fixing	p24
931 Corner base cabinet - Assembly	p31	Corner base cabinet fillet fixing - Integrated handles	p150
Adapting a rigid cabinet to Handleless,		Corner base cabinet - Asymmetrical fillet	p26
Cabinet modification	p74	Corner base cabinet - Symmetrical fillet	p27
Fittings packs overview	p73	Corner larder	p28
Planning dimensions	p72	Corner wall filler rail	p106
Worktop profile	p75	Cornice,	
Worktop profile corner return	p76	Fixing	p127
Adjustable wall bracket - Inclusive kitchens	p242	Alternative fixing method	p128
Alternative cabinet leg	p22	Curved units,	
Appliance door application - Integrated handle design	p153	Curved base decor end and door fixing - Integrated handle	p157
Appliance tower cabinet,		Curved base cabinet	p235
Fixing to wall and connecting	p117	Curved corner post	p234
Additional shelf pack	p162	Curved plinth - Joining	p237
Cabinet modifications - Back panel	p162	Curved wall cabinet	p236
Cabinet modifications - Fitting a top box	p164	Decor end panels - Fixing	p127
How the cabinet is supplied	p160	Thick decor end post	p129
Installation - Hints and tips	p161/165	Decorative plinth	p123
Standard drawer box	p163	Decorative plinth - Corner larder application	p265
Aventos flap-stay mechanism	p116	Deep wall cabinets - Planning dimensions	p15
Backboards - Fitting	p137	Deep wall cabinet corner - Planning dimensions	p18
Base cabinets,		Deep wall cabinet,	
Cabinet installation fittings	p6	Cabinet adjustment	p108
Connecting and levelling	p30	Concealed hanging brackets - Pre-build	p25
Fixing and connecting	p110	Fixing to wall and adjustment (option 1) (option 2)	p108/109
Fixing brackets, pre-build	p23	Double oven,	
Hob separator plate	p40	Appliance tower	p166
Level H kitchens - Assembly	p146	Midi tower	p215
Sink base unit	p34	Double ovens fitting between two cabinets	p165
Wall fixing	p30	Double oven with additional appliances and drawer	p170
Wall fixing - Inclusive kitchens	p240	Drawer box packs,	
Blanking panel application guide	p33	900 5 drawer chest	p98
BOSCH installation,		Internal drawers - Deep and shallow drawer box assembly	p89
Washing machine	p230	Internal drawers - Installation and application	p90-94
Washer dryer	p231	Internal three drawer application	p90
Bridging cabinet/Half-height wall/Hob wall	p113	Plinth drawer adaptor kit	p101
Built-under oven housing,		Push to open drawers	p96
Assembly	p36	Shallow drawer box	p95
Drawer	p37	Standard 700/800/900/1000 drawer box pack	p81
Leg conversion kit	p39	Standard drawer box - Appliance tower cabinegt	p163
Wall fixing	p30	Standard drawer box pack - Assembly	p78
Cabinet installation fittings	p6	Standard drawer box pack - HL cabinet application	p80
Additional installation components	p7	Under sink drawer	p99
Cabinet leg	p20-21	Upgrade drawer box pack - 800/900/1000 Drawer-line - Soft-close	p88
Cabinet leg, alternative	p22	Upgrade drawer box pack - Non-soft close	p85
Cabinet overview,		Upgrade drawer box pack - Soft-close	p86
Decor units	p8	Upgrade drawer box pack - Soft-close and non-soft close	p83
		Upgrade drawer box pack - Stabiliser kit	p87

Index

Easy removable plinth	p229	Castor assembly	p245
Fillet fixing,		Leg and plinth fixing,	
Corner base cabinet - Integrated Handle	p150	60mm Leg fixing	p243
Corner wall filler rail	p106	223mm Leg fixing	p244
'L' shaped corner wall cabinet	p107	Tower pull-out worktop application	p246
Finishing touches	p144	Wall fixing	p240
Floor mounted wall units - Wall fixing	p30	Integrated handles,	
Full-height larder fridge/freezer options	p202	Jointing plates	p151
Gas hobs	p232	Appliance door application	p153
Half-height frontals,		Corner base cabinet fillet fixing	p150
Appliance application	p208	Curved base decor end and door fixing	p157
Half-height wall/hob wall/bridging cabinet	p113	Pull out larder bracket	p152
Handle fixing	p144	Installation components	p7
Handleless Profile System,		Internal drawers,	
Appliance at the end of a run	p66	Deep and shallow drawer box assembly	p89
Appliance infill application - 452mm and 602mm	p56	Installation and application	p90-94
Base decor panel - Cutting application	p60	Jointing plates - Integrated Handle	p151
Before you begin	p46	Laminate worktop joining	p135
Built under applications	p54	Larder cabinet,	
Built under oven housing (BUOH) profile - 600mm	p54	Fixing to wall and connecting	p117
Drawer application	p61	Level H kitchens - Assembly	p146
Drawer profile corner return	p51	Larder pantry	p248
Drawer profile - Length 3000mm	p49	Larder tower,	
End caps	p55	Appliance tower	p205
End tower profile - 1942mm and 2122mm	p52	Midi tower	p227
External corner post	p58	Leg and plinth fixing - Inclusive kitchens,	
Fittings packs overview	p45	60mm Leg fixing	p243
HL base cabinet for sink application	p64	223mm Leg fixing	p244
Internal corner piece	p55	Level H kitchens,	
Island applications	p57	Base cabinet	p146
Mid tower profile - 1942mm and 2122mm	p53	Hob wall cabinet	p148
Other appliance applications	p64	Larder cabinet	p146
Profile overview	p44	Wall cabinet	p147
Planning dimensions	p16	'L' shaped corner cabinet	p106
Push to open	p67	Corner filler rail	p106
Securing worktops	p65	Fillet fixing	p107
Sink base unit	p68	Magnetic catch - Push to open	p143
Standard drawer application	p63	Microwave 38cm	
Worktop fixing	p65	Microwave 38cm - LAMONA	p191
Worktop profile corner return	p50	Microwave 38cm (with 115mm fascia) - LAMONA	p192
Worktop profile - Length 3000mm	p47	Microwave 38cm and double oven - LAMONA	p193
Hinges,		Microwave 38cm and single oven - LAMONA	p194
Adjustment	p140	Microwave 38cm and warming drawer - LAMONA	p195
Damper installation	p141	Microwave/compact oven,	
Fitting	p140	Appliance tower	p184
Magnetic catch - Push to open	p143	Midi tower	p221
Soft-close de-activation switch	p142	Microwave/compact oven with additional appliances	p187
Upgrade soft-close,		Microwave/compact oven with warming drawer,	
Assembly	p141	Appliance tower	p189
Installation and adjustment	p141	Midi tower	p223
Hints and tips,		Mid shelf support - 800/900/1000 cabinets - Pre-build	p23
Appliance towers - Installation	p161/165	Midi tower fridge or freezer option	p225
General	p5	Midi tower cabinet,	
Midi towers - Installation	p212	Additional shelf pack	p214
Hob separator plate	p40	Cabinet modifications	p214
Hob wall/half-height wall/bridging cabinet	p113	How the cabinet is supplied	p213
Hob wall cabinet,		Installation - Hints and tips	p212
Level H kitchens - Assembly	p148	Other assembly guides,	
Modification for microwave housing	p112	Corner larder unit	p257
Inclusive kitchens,		Decorative plinth - Corner larder application	p265
600mm Wall pull down unit	p241	Inframe kitchens	p250
Adjustable wall bracket	p242		
Base cabinet wall fixing	p240		

Index

Larder pantry.....	p248	HL cabinet application.....	p80
Larder top box cabinet.....	p255	Standard cabinets - Planning dimensions.....	p14
Tall corner larder unit.....	p259	Standard wall cabinet corner - Planning dimensions.....	p17
Walk in corner larder.....	p261	Standard wall cabinet left hand/right hand - Wall fitting.....	p105
Pelmet,		Supplied products.....	p4
Fixing.....	p127	Tall glass wall unit with spice drawer.....	p111
Alternative fixing method.....	p128	Thick decor end post.....	p129
Planning dimensions		Top box - Fitting.....	p164
Adapting a rigid cabinet to Handleless.....	p72	Tower pull-out 5th leg fixing.....	p22
Deep wall cabinets.....	p15	Tower pull-out worktop application - Inclusive kitchens.....	p246
Deep wall cabinet corner.....	p18	Undermount sink cradle.....	p136
Handleless Profile System.....	p16	Under sink drawer.....	p99
Standard cabinets.....	p14	800mm Under sink drawer.....	p100
Standard wall cabinet corner.....	p17	1000mm Under sink drawer.....	p100
Plinth drawer adaptor kit.....	p101	Upgrade drawer box pack,	
Plinths,		800/900/1000 Drawer-line - Soft close.....	p88
Curved - Joining.....	p237	Non-soft close.....	p85
Decorative plinth.....	p123	Soft close.....	p86
Decorative plinth - Corner larder application.....	p265	Soft close and non-soft close.....	p83
Drawer adaptor kit.....	p101	Stabiliser kit.....	p87
Easy removable.....	p229	Wall cabinet,	
Fixing.....	p120	500mm and 600mm Bi-fold unit.....	p114
Inside corner.....	p120	Aventos flap stay mechanism.....	p116
Integrated dishwasher.....	p122	Cabinet adjustment.....	p108
Plinth clip.....	p120	Cabinet installation fittings.....	p6
Plinth drawer adaptor kit.....	p101	Clearance dimensions.....	p104
Plinth vent.....	p122	Corner wall filler rail.....	p106
Return plinths.....	p121	Deep wall cabinets - Fitting (option 1) (option 2).....	p108/109
Sealer strip.....	p122	Fitting legs to wall cabinets - Pre-build.....	p21
Straight run.....	p120	Fixing and connecting.....	p110
Pre-build,		Hob wall cabinet - Modification for microwave housing.....	p112
Alternative cabinet leg.....	p22	Hob wall/Half-height wall/Bridging cabinet.....	p113
Base cabinet, wall fixing brackets.....	p23	'L' shaped corner wall cabinet.....	p106
Cabinet.....	p23	Level H kitchens - Assembly.....	p147
Cabinet leg.....	p20-22	Pre-build.....	p104
Corner base cabinet centre upright fixing.....	p24	Tall glass wall unit with spice drawer.....	p111
Deep wall cabinet - Concealed hanging brackets.....	p25	Wall fixing,	
Fitting legs to wall cabinets.....	p21	600 Built-under oven housing and floor mounted wall units.....	p30
Mid shelf support, 800/900/1000mm cabinets.....	p23	631 Standard corner wall cabinet left hand/right hand.....	p105
Plinth clip.....	p21	Appliance towers.....	p117
Tower pull-out 5th leg fixing.....	p22	Base cabinets.....	p30
Wall cabinets.....	p104	Brackets - Base cabinets.....	p23/30
Wall fixing brackets - Base cabinets.....	p23	Deep wall cabinets - Fixing to wall and adjustment	
Worktop fixing brackets.....	p23	(option 1) (option 2).....	p108/109
Pull-out larder bracket - Integrated Handle.....	p152	Fixing and connecting.....	p110
Push to open drawers.....	p96	Floor mounted wall units - Wall fixing.....	p30
Shelf installation,		Larder.....	p117
Standard wall cabinets.....	p111	'L' shaped corner cabinet.....	p106
Deep wall cabinets.....	p111	Corner wall filler rail.....	p106
Shallow drawer box.....	p95	Deep wall 'L' shaped corner cabinet.....	p106
Single oven,		Fillet fitting.....	p107
Appliance tower.....	p172	Standard 'L' shaped corner cabinet.....	p106
Midi tower.....	p217	Standard wall cabinet left hand / right hand.....	p105
Single oven with additional appliances and drawer.....	p176	Worktop,	
Single oven with warming drawer and additional microwave,		Cutting and fixing.....	p135
Appliance tower.....	p178	Fitting backboards.....	p137
Single oven with warming drawer		Fitting sink unit.....	p136
Midi tower.....	p219	Fixing.....	p134
Sink base unit.....	p34	Fixing bracket, pre-build.....	p23
Sink unit - Fitting.....	p136	Laminating worktop joining.....	p135
Standard drawer box pack,		Planning recommendations (22mm Laminate worktops).....	p133
700/800/900/1000 drawer box.....	p81	Support bars - Application information.....	p132
Assembly.....	p78	Undermount sink cradle.....	p136

