

# SDH3630 Howdens Real Wood Pre-Finished Oak single plank wide (W180mm) pre-finished oak single plank wide



## Key

- F** = FSC®
- P** = PEFC™
- UK** = UK Manufactured
- †** = Subject to availability

| Products                           |                  |
|------------------------------------|------------------|
| Pre-Finished Oak single plank wide | <b>P</b> SDH3630 |
| Solid Oak scotia (L2.1m)           | SDH3052          |
| Pack of 2                          | <b>P</b> SDH3090 |
| Solid Oak threshold strip (970mm)  | <b>F</b> SDH3021 |
| Solid Oak threshold strip (L2.1m)  | <b>F</b> SDH3023 |
| Solid Oak ramp strip (L970mm)      | <b>F</b> SDH3031 |
| Solid Oak L section (L970mm)       | <b>F</b> SDH3041 |

| Construction  |  |
|---------------|--|
| Construction  | Engineered   |
| Surface layer | 2.5mm European Oak Veneer, Universal Grade, Veneer source: European producer |
| Substrate     | Moisture Control HDF - E1 (7.3mm)  |
| Backing       | Spruce - Grade 2/3 (Softwood) (1.2mm)  |
| Finish        | Matt Lacquered   |

| Technical Information |                                  |
|-----------------------|----------------------------------|
| Range                 | Engineered Flooring              |
| Locking system        | Fast Fit System                  |
| Finish                | Matt Lacquered                   |
| Glue / resin          | Urea - Resin                     |
| Moisture content      | 5% - 9%                          |
| Impact resistance     | >1200mm EN 438-2, 12             |
| Abrasion class        | IP 500 revf. falling sand method |
| Reaction to fire      | Cfl - S 1 En ISO 11925-2         |

| Technical Information                  |   |
|--|---|
| Level of use of according to EN 33 9*  | N/A   |
| Suitable for underfloor heating detail | Yes - Electric and radiant if installed as per the instructions (note must not exceed 27 degrees) |
| Thermal conductivity                   | 0.14 W/mK   |
| Effect of castor chairs                | N/A   |
| Resistance to staining                 | Resistant DIN 68861, Group A  |
| Slip resistance                        | 0,5 - 0,7 u   |
| Formaldehyde emission                  | Class E1  |
| Laying detail                          | Must be laid as a floating floor (see instructions)   |

| Dimensions & Packaging      |                                      |
|-----------------------------|--------------------------------------|
| Quantity                    | 6 Full planks or 5 full and 2 halves |
| Volume coverage / pack size | 2.38 m/sq                            |
| Product packed weight       | 21.4 kg                              |

| Care & Installation  |   |
|----------------------|---|
| Care and maintenance | <p>Floor mats are recommended for use at front entrance to the property.</p> <p>Felt pads &amp; castor cups are recommended under chairs and heavy furniture.</p> <p>Move furniture carefully to avoid damaging under chairs and heavy furniture.</p> <p>For general cleaning use soft broom or vacuum cleaners suitable for hard floors.</p> <p>Regular cleaning with a well wrung out cloth/mop is advised</p> <p>Do not use steam mops or cleaners</p> <p>Do not leave any water on the floor, wipe up any spills immediately</p> <p>Do not use cleaning agents such as wax, polish or oil</p> <p>Direct sunlight may have an effect on the colour of the floor over a period of time</p> <p>Sand back and re-lacquer up to 3 times</p> <p>Use the floor exclusively under the recommended conditions in the instructions</p> <p>We recommend that floor mats are used at entrances to the property where timber flooring is installed. This will help avoid abrasive particles damaging the surface.</p> <p>Self-adhesive pads and castor cups should be fitted to furniture to avoid scratching where applicable. Note: Heavy scratching could break the seal on the flooring causing damage</p> <p>General cleaning of the floor should be done using a soft broom or vacuum cleaner. Do not use abrasive cleaners, steel wool or scouring pads, as they will damage the floor</p> <p>For full details please see the fitting instructions supplied with the flooring</p>   |
| Fitting instructions | For full details please see the fitting instructions supplied with the flooring.  |
| Important notes      | <p>As a natural oak product, the knots that appear are a characteristic of natural timber. To keep these knots in place and prevent splitting they are sealed with dark brown filler.</p> <p>Remove all previous floor coverings.</p> <p>Not suitable for use in unheated rooms, damp rooms or bathrooms. Flooring should be kept in the room where it will be laid for 48 hours or more to allow it to acclimatise to the ambient temperature and humidity.</p> <p>Moisture test must be carried out for all mineral based substrates (2.0CM% for cement screed and 0.5 CM% for sulphate screed. A room temperature of 20°C(68°F), a relative humidity of about 50-60% should be maintained.</p> <p>SDH3630 is NOT mixable with SDH3625 due to a change in profile.</p> <p>We recommend that heating should have been operating in the room for at least two weeks to ensure a stable temperature level.</p> <p>Suitable for use with Foam Underlay, High Performance Underlay, Damp Proof Membrane, Paintable Damp Proof Membrane and Bitumen Moisture Barrier Paper.</p> <p>Sealed packs must be stored for at least 48 hours where they are to be laid. Do not open packs until you are ready to install the flooring. Packs are to be laid flat on the floor with at least 50cm between packs and walls. Packs should be stored in a room with a minimum temperature of 18°C.</p> <p>Must leave 15mm expansion gap around the entire floor including cabinet legs, radiator pipes and door frames.</p> <p>Do not install cabinets over the floor.</p> <p>The maximum area without additional expansion joints is 10m width x 10m length.</p> <p>If laying over a stone/mineral sub-floor, lay SDH0910 - Howdens Damp Proof Membrane (at least 0.2mm thick PE foil) first as a "trough" (i.e. lay over the floor and extend ends and sides up the walls for a few centimetres) or SDH0931 Paintable Damp Proof Membrane.</p> <p>For timber based sub-floor, lay Bitumen Moisture Barrier Paper.</p> <p>Suitable with Use SDH0900 Foam Underlay &amp; SDH0909 High Performance Underlay (XPS)*;*not with underfloor heating.</p> |